

AXIS P3364-LVE Quick Reference Guide

Default Network Settings

Default IP Address: 192.168.0.90 (when no DHCP)

Default Username: root

Default Password: [Must be set on first access]

Web Interface: [http://\[camera-ip\]](http://[camera-ip])

Port Configuration

HTTP Port: 80

HTTPS Port: 443

RTSP Port: 554

FTP Port: 21

SNMP Port: 161

Stream URLs

H.264 RTSP: [rtsp://\[ip\]/axis-media/media.amp](rtsp://[ip]/axis-media/media.amp)

MJPEG HTTP: [http://\[ip\]/axis-cgi/mjpg/video.cgi](http://[ip]/axis-cgi/mjpg/video.cgi)

Still Image: [http://\[ip\]/axis-cgi/jpg/image.cgi](http://[ip]/axis-cgi/jpg/image.cgi)

LED Status Indicators

Status LED:

- Green: Normal operation
- Amber: Startup/restoring settings
- Red: Firmware upgrade failure

Network LED:

- Green: 100 Mbit/s connection
- Amber: 10 Mbit/s connection
- Off: No network connection

Power LED:

- Green: Normal operation
- Flashing Green/Amber: Firmware upgrade

Common Configuration Paths

Basic Setup: Setup > Basic Setup

Video Settings: Setup > Video & Audio > Video Stream

Network Config: Setup > System Options > Network > TCP/IP

User Management: Setup > System Options > Security > Users

Storage Setup: Setup > System Options > Storage

Maintenance: Setup > System Options > Maintenance

Factory Reset Methods

Hardware Reset:

1. Disconnect power
2. Hold control button and reconnect power
3. Keep pressed 15-30 seconds until Status LED flashes amber
4. Release button when Status LED turns green

Software Reset:

- Go to Setup > System Options > Maintenance > Default

Emergency Recovery (Failed Firmware)

Windows:

```
cmd
```

```
arp -s [ip-address] [serial-number]
```

```
ping -l 408 -t [ip-address]
```

Linux/Unix:

```
bash
```

```
arp -s [ip-address] [serial-number] temp
```

```
ping -s 408 [ip-address]
```

Common Troubleshooting Commands

IP Assignment via ARP/Ping (within 2 minutes of power-on):

cmd

Windows (run as administrator)

arp -s 192.168.0.125 00-40-8c-18-10-00

ping -l 408 -t 192.168.0.125

Linux/Mac

arp -s 192.168.0.125 00:40:8c:18:10:00 temp

ping -s 408 192.168.0.125

I/O Connector Pinout

Pin 1: 0V DC (Ground)

Pin 2: DC Output (3.3V, max 50mA)

Pin 3: Digital Input (0-40V DC)

Pin 4: Digital Output (0-40V DC, open drain, 100mA)

Audio Connector Pinout

Audio In (Pink 3.5mm):

- Tip: Microphone/Line Input

- Sleeve: Ground

Audio Out (Green 3.5mm):

- Tip: Line Output (Mono)

- Ring: Line Output (Mono)

- Sleeve: Ground

Supported Storage

SD Cards: SD/SDHC/SDXC

File Systems: ext4 (recommended), vFAT

Network Storage: CIFS/SMB shares

Recording Formats: .mkv (Matroska)

Streaming Specifications

Max Resolution: Varies by model

Video Codecs: H.264, MJPEG

Audio Codecs: AAC, G.711, G.726

Max Frame Rate: 25/30 fps (depends on power frequency)

Max Simultaneous Streams: 20 unicast connections

Power Requirements

Power Method: PoE (Power over Ethernet)

PoE Class: Class 3 required for heater and IR illumination

Network Cable: Shielded (STP) recommended

Firmware Information

Current Version Check: Setup > About

Upgrade Path: Setup > System Options > Maintenance

Download Location: www.axis.com/support

Supported Versions: 6.50 and later