

## Using the MX-780

The MX-780 displays the title (Main or device) at the top of the screen. Below the title, the OLED displays the device or command names. All of the hard buttons of the MX-780 are changed to control the functions of the selected device.

The **Title** displays what the main page or device you can control.

Press either of the **Page** buttons to see any other available choices.

The **Volume** and **Mute** buttons always control the sound regardless of what screen is displayed.

The **Transport buttons** (Play, Stop, Skip-, Skip+, FF, REW and Pause) operate when the selected device requires them. When watching Cable TV, use the number keypad to enter channel numbers. When listening to a CD, the number keypad enters track numbers.



The **Light** button backlights all of the buttons.

The **OLED button labels** describe special features for this activity.

The **Channel** and **Previous Channel** buttons will change channels when you have selected devices like CABLE.

The **4 way cursor** buttons enable you to navigate on screen guides and menus with ease.

The **Number keypad** enters numbers for the devices you've selected. When watching Cable TV, use the number keypad to enter channel numbers. When listening to a CD, the number keypad enters track numbers.