

# **MCUXpresso Config Tools User's Guide (IDE)**



# Contents

<b>Chapter 1 Introduction.....</b>	<b>4</b>
1.1 Versions.....	4
<b>Chapter 2 Config Tools User Interface .....</b>	<b>6</b>
2.1 Creating, saving, and opening a configuration.....	6
2.1.1 Creating a new configuration.....	6
2.1.2 Saving a configuration.....	6
2.1.3 Importing sources.....	6
2.1.3.1 Importing configuration.....	7
2.1.3.2 Importing registers.....	7
2.1.4 Restoring configuration from source code.....	9
2.2 Toolbar.....	10
2.2.1 Update project.....	10
2.2.2 Eclipse project selection.....	12
2.2.3 Functional groups.....	13
2.2.3.1 Functional group properties.....	14
2.2.4 Switching the tools.....	14
2.3 Status bar.....	14
2.4 Preferences.....	15
2.5 Configuration preferences.....	16
2.6 Problems view.....	16
2.7 Registers view.....	17
2.8 Log view.....	19
2.9 Config tools overview.....	19
<b>Chapter 3 Pins Tool.....</b>	<b>21</b>
3.1 Pins routing principle.....	21
3.1.1 Beginning with peripheral selection.....	21
3.1.2 Beginning with pin/internal signal selection.....	22
3.2 Workflow.....	22
3.3 Example usage.....	22
3.4 User interface.....	25
3.4.1 Functions.....	26
3.4.2 Package.....	27
3.4.3 Routed Pins view.....	30
3.4.3.1 View controls.....	30
3.4.3.2 Filtering routed pins.....	31
3.4.4 Peripheral Signals view.....	32
3.4.5 Pins table view.....	34
3.4.5.1 Labels and identifiers.....	35
3.4.6 Filtering in the Pins and Peripheral Signals views.....	36
3.4.7 Highlighting and color coding.....	37
3.5 Errors and warnings.....	39
3.5.1 Incomplete routing.....	39
3.6 Code generation.....	39
<b>Chapter 4 Clocks Tool.....</b>	<b>41</b>
4.1 Features.....	41

4.2 User interface overview.....	41
4.3 Clock configuration.....	42
4.4 Global settings.....	43
4.5 Clock sources.....	43
4.6 Setting states and markers.....	43
4.7 Frequency settings.....	44
4.7.1 Pop-up menu commands.....	45
4.7.2 Frequency precision.....	45
4.8 Dependency arrows.....	45
4.9 Details view.....	46
4.10 Clock diagram.....	47
4.10.1 Mouse actions in diagram.....	48
4.10.2 Color and line styles.....	49
4.10.3 Clock model structure.....	49
4.11 Main menu.....	51
4.12 Troubleshooting problems.....	51
4.13 Code generation.....	52
4.13.1 Working with the code.....	53
4.14 Clock Consumers view.....	53

## **Chapter 5 Peripherals Tool..... 55**

5.1 Features.....	55
5.2 Basic Terms and Definitions.....	55
5.3 Workflow.....	55
5.4 User interface overview.....	56
5.5 Common toolbar.....	56
5.6 Documentation view.....	57
5.7 Peripherals view.....	57
5.8 Components view.....	57
5.9 Settings Editor.....	58
5.9.1 Quick selections.....	59
5.9.2 Settings.....	59
5.9.3 Settings Editor header.....	61
5.10 Problems.....	61
5.11 Code generation.....	62

## **Chapter 6 Advanced Features..... 63**

6.1 Switching the processor .....	63
6.2 Exporting the Pins table.....	64
6.3 Tools advanced configuration.....	65
6.4 Generating HTML report.....	65
6.5 Exporting sources.....	65
6.6 Exporting registers.....	66
6.7 Command line execution.....	67
6.7.1 Command line execution - Pins Tool.....	69
6.7.2 Command line execution - Clocks Tool.....	70
6.7.3 Command line execution - Peripherals Tool.....	71
6.7.4 Command line execution - Project Cloner.....	71
6.8 Working offline.....	72

## **Chapter 7 Support..... 73**

# Chapter 1

## Introduction

The MCUXpresso Config Tools set is a suite of evaluation and configuration tools that helps you from first evaluation to production software development. It includes the following tools.

**Table 1. MCUXpresso Config Tools**

Name	Description
<a href="#">Pins Tool</a>	Enables you to configure the pins of a device. Pins Tool enables you to create, inspect, change, and modify any aspect of the pin configuration and muxing of the device.
<a href="#">Clocks Tool</a>	Enables you to configure initialization of the system clock (core, system, bus, and peripheral clocks) and generates the C code with clock initialization functions and configuration structures.
<a href="#">Peripherals Tool</a>	Enable you to configure the initialization for the MCUXpresso SDK drivers.

## 1.1 Versions


The suite of these tools is called MCUXpresso Config Tools. These tools are provided as an online Web application or as a desktop application or as integrated version in MCUXpresso IDE.

### NOTE

The desktop version of the tool contacts the NXP server and fetches the list of the available processors. Once used, the processors data is retrieved on demand.

### TIP

To use the desktop tool in the offline mode, create a configuration for the given processor while online. The tool will then store the processors locally in the user folder and enable faster access and offline use. Otherwise, it is possible to download and export the data using the **Export** menu.



**Figure 1. Desktop version of Pins Tool**

**NXP MCUXpresso Config Tools** Return to Dashboard Config Tool

Pins Views Help

**MK22FN512xxx12** Functional Group BOARD\_InitPins

Pins Peripheral Signals Routed Pins

type filter text

Pin	Pin name	Label	Identifier	GPIO	FTM	SIM	ADC
1	ADC1_SE4a/...	J2[18]/UART...	DEBUG_UAR...	PTE0		CLKOUT32K[...	ADC1_SE4a
2	ADC1_SE5a/...	J2[20]/UART...	DEBUG_UAR...	PTE1			ADC1_SE5a
3	VDD3	P3V3_K22F					
4	VSS4	GND					
5	USB0_DP	USB_DP	USB_DP				
6	USB0_DM	USB_DN	USB_DN				
7	VOUT33	USB_VOUT33	USB_VOUT33				
8	VREGIN	P5V_K22F	USB_VREGIN				
9	ADC0_DP0/A...	J24[1]/ADC0...					ADC0_DP0[...]
10	ADC0_DM0/A...	J24[3]/ADC0...					ADC0_DM0[...]
11	ADC1_DP0/A...	J24[5]/ADC0...	LSENSE_EMI...				ADC1_DP0[...]
12	ADC1_DM0/A...	J24[7]/ADC0...					ADC1_DM0[...]
13	VDDA	P3V3_K22F					
14	VREFH	J2[16]/VREFH					VREFH[...]
15	VREFL	VREFL					VREFL[...]
16	VSSA	VSSA					VSSA[...]
17	VREF_OUT/C...	J2[1]					VREF_OUT[...]
18	DAC0_OUT/C...	J24[11]/DAC...					
19	XTAL32	XTAL32_RTC	XTAL32				ADC0_SE23
20	EXTAL32	EXTAL32_RTC	EXTAL32				
21	VBAT	VBAT					
22	PTA0/UART0...	J11[4]/SWD...		PTA0	FTM0_CH5	FTM0_CH5	
23	PTA1/UART0...	J2[4]/RED_L...	LEDRGB_RED	PTA1	FTM0_CH6	FTM0_CH6	
24	PTA2/UART0...	J1[8]/GREEN...	LEDRGB_GRE...	PTA2	FTM0_CH7	UART0_TX[...]	
25	PTA3/UART0...	J11[2]/SWD...		PTA3	FTM0_CH0	FTM0_CH0	
26	PTA4/LLWU...	J1[10]/LLWU...		PTA4	FTM0_CH1	FTM0_CH1	
27	PTA5/USB_C...	J1[1]/I2S0_T...	AC_I2S_SCL...	PTA5	FTM0_CH2	FTM0_CH2	
28	PTA12/FTM1...	J1[5]/I2S0_T...	AC_I2S_DIN	PTA12	FTM1_CH0[...]		
29	PTA13/LLWU...	J1[3]	AC_I2S_LRCLK	PTA13	FTM1_CH1[...]	FTM1_CH1	
30	VDD30	P3V3_K22F					

Package

MK22FN512VLH12 - LQFP 64 package

The pin diagram shows the MK22FN512VLH12 LQFP 64 package with pins numbered 1 to 64. Pins are color-coded: green for UART, blue for USB, red for I2S, and yellow for other functions. Internal blocks shown include ADC0, ADC1, CMP0, DAC0, DAC1, DMA, EIM, FTM0, FTM1, FTM2, FTM3, GPIOA, GPIOB, GPIOC, GPIOD, I2C0, I2C1, I2S0, I2S1, LPUART0, LPUART1, LPUART2, LPUART3, LPUART4, LPUART5, LPUART6, LPUART7, LPUART8, LPUART9, LPUART10, LPUART11, LPUART12, LPUART13, LPUART14, LPUART15, LPUART16, LPUART17, LPUART18, LPUART19, LPUART20, LPUART21, LPUART22, LPUART23, LPUART24, LPUART25, LPUART26, LPUART27, LPUART28, LPUART29, LPUART30, LPUART31, LPUART32, LPUART33, LPUART34, LPUART35, LPUART36, LPUART37, LPUART38, LPUART39, LPUART40, LPUART41, LPUART42, LPUART43, LPUART44, LPUART45, LPUART46, LPUART47, LPUART48, LPUART49, LPUART50, LPUART51, LPUART52, LPUART53, LPUART54, LPUART55, LPUART56, LPUART57, LPUART58, LPUART59, LPUART60, LPUART61, LPUART62, LPUART63, LPUART64.

Figure 2. Web version of Pins Tool

## Chapter 2

# Config Tools User Interface

## 2.1 Creating, saving, and opening a configuration

In this context, configuration stands for common tools settings stored in an MEX (Microcontrollers Export Configuration) file. This file contains settings of all available tools and can be used in both web and desktop versions.

### 2.1.1 Creating a new configuration

In **Project Explorer** right-click the Eclipse project based on MCUXpresso SDK, and select **MCUXpresso Config Tool > Open Pins**. One of the following actions takes place:

- If the project contains an MEX file in the root folder, the file is opened.
- If the project contains any source file with tool configuration (pin\_mux.c, clock\_config.c and/or peripheral.c), the tool configuration is imported from this file.
- Otherwise, an empty/default configuration for selected processor is created.

---

**NOTE**

The same command can be invoked also from popup menu on the MEX file or from toolbar in **Project Explorer** view.

---

### 2.1.2 Saving a configuration

You can save your configuration by clicking the **Save** button on the toolbar or selecting **File>Save** from the **Main Menu**. The command is enabled only if the configuration is dirty (unsaved) and one of MCUXpresso Config Tool perspective is opened. The configuration is always saved into an MEX file stored in the project root folder. If file doesn't exist, new one is created using current project name.

---

**NOTE**

Configuration is also automatically saved during **Update Project Code** action.

---

### 2.1.3 Importing sources

To import source code files:

1. Select **File > Import...** from the **Main Menu**.
2. Select **MCUXpresso Config Tools>Import Source**.




Figure 3. Import Source wizard

3. Click **Next**.
4. You can select one or more C files to import using the **Browse** button in the **Import Pins Source Files** dialog.
5. Select how to import the files:
  - **Rename** – All files are merged into the current configuration. It imports all the functions only. If the imported function has the same name as an existing one, it is automatically renamed to the indexed one. For example, if BOARD\_InitPins already exists in the configuration then the imported function is renamed to BOARD\_InitPins1.
  - **Overwrite** – All files are merged into the current configuration. It imports all the functions only. If the imported function has the same name as an existing one, then the existing one is replaced with the imported one.
6. Click **Finish**.

**NOTE**

Only C files with valid YAML configuration can be imported. It imports the configuration only, then the whole C file is re-created based on this setting. The rest of the \*.c and \*.dtsi files are ignored.

### 2.1.3.1 Importing configuration

### 2.1.3.2 Importing registers


You can import register configuration from a processor memory dump.

**NOTE**

Currently, register configuration can be imported into the Clocks Tool only.

**NOTE**

A processor memory-dump file in the CSV or S19 format is required for importing register configuration.

**Figure 4.**

To import register configuration, do the following:

1. Select **File>Import...>Import Registers** from the **Main Menu**. Alternatively, click the **Import Registers Configuration** button in the **Registers** view, or drag-and-drop the memory dump file anywhere in the **Registers** view.

**Figure 5.****Import Registers Configuration**



- ### NOTE

### 2.1.4 Restoring configuration from source code

The following is an example of the settings information in the generated source code.

```

/*****
***** Configuration BOARD_BootClockRUN *****
*****/
/* TEXT BELOW IS USED AS SETTING FOR TOOLS *****
!!Configuration
name: BOARD_BootClockRUN
called_from_default_init: true
outputs:
- {id: Bus_clock.outFreq, value: 20.97152 MHz}
- {id: Core_clock.outFreq, value: 20.97152 MHz}
- {id: Flash_clock.outFreq, value: 10.48576 MHz}
- {id: FlexBus_clock.outFreq, value: 10.48576 MHz}
- {id: LPO_clock.outFreq, value: 1 kHz}
- {id: MCGFFCLK.outFreq, value: 32.768 kHz}
- {id: PLLFLLCLK.outFreq, value: 20.97152 MHz}
- {id: System_clock.outFreq, value: 20.97152 MHz}
* BE CAREFUL MODIFYING THIS COMMENT - IT IS YAML SETTINGS FOR TOOLS *****/

```

**Figure 6. Setting Information in the source code**

If this information is not corrupted, it's possible to re-import the clock settings into the tool using the following steps.

1. Select **File > Import...**
2. Select **Clocks Tool / Import Source Files**.
3. Click **Next**.
4. Click **Browse**.
5. Navigate and select the *clock\_config.c* file previously produced by the Clocks Tool.
6. If the settings parse successfully, clock configurations are added into the current global configuration.

## 2.2 Toolbar

The toolbar is located on the top of the window and includes frequently used actions.

### 2.2.1 Update project

To update the generated code in the related toolchain project, click the **Update Project** button. In the dialog, select the tools or files you want to update. If update is not possible, the button is filled with a black square. The reason is displayed in the tooltip.




Figure 7. Update Project Files dialog

To inspect the code difference between the versions, click the **show differences** link.




Figure 8. Show differences

To update the project without opening the **Update Project Files** dialog, clear the **Always show details before Update Project** option.

To access the the **Update Project Files** dialog from the **Update Project** drop-down menu, select **Open Update Project Dialog**.




Figure 9. Update Project drop-down menu

#### NOTE

The generated code is always overwritten.

#### NOTE

Previous version of the file can be retrieved from Eclipse local history.

The **Update Project** action is enabled under following conditions:

- Processor selected in the tool matches with processor selected in the toolchain project
- Core is selected (for multicore processors)

## 2.2.2 Eclipse project selection

You can use the **Eclipse project** drop-down menu to switch between projects.




Figure 10. Eclipse project selection

## 2.2.3 Functional groups

Each configuration can contain several functional groups. These groups represent functions which will be generated into source code. Use the drop-down menu to switch between functional groups and configure them.




Figure 11. Functional groups

Additional buttons can be used on functional groups:



- Toggle "Called from default initialization function" feature (in source code)



- Open the **Functional group properties** dialog

Red/orange background indicates errors/warnings in the configuration.

### 2.2.3.1 Functional group properties




Figure 12. Functional group properties for Pins Tool

In this dialog, you can configure several options for functions and code generation. Each settings is applicable for the selected function. you can specify generated function name, select core (for multicore processors only) that is affecting the generated source code, or write function description (this description will be generated in the C file).

**Set custom #define prefix:** If enabled, it uses the specified prefix for the identifiers in the source code. You can also modify functions order (on the left), the order is applied in the generated code.<sup>[1]</sup>

Configure the **Called from default initialization function** option to set it for the function. If the option is set, the function is called from the default initialization function.

## 2.2.4 Switching the tools

Buttons on the right side of the toolbar represent available tools. Click them to quickly navigate between Clocks, Pins and Peripherals tools.

## 2.3 Status bar

The status bar is visible at the bottom part of the GUI. Status bar indicates error and warning state of the currently selected functional group.

[1] \*if supported by processor

## 2.4 Preferences

To configure preferences, select **Window>Preferences>MCUXpresso Config Tools** from the **Main Menu**. The **Preferences** dialog appears.




Figure 13. Preferences dialog

In this dialog you can set the following:

- **Line ending style** – Select between **Windows (CR + LF)**, **Linux/Mac (LF)**, or **Default (based on host)**.
- **Generate files read-only** – Prevents modifying the source files unintentionally. Generated source files are marked as read-only.
- **Always overwrite files without asking** – Select to update existing files automatically, without prompting.
- **Always show details before Update Project** – Select to review changes before the project is updated.
- **Undo history size** – Enter the number of steps you want to undo. Enter 0 to disable.
- Proxy connection

- **Direct** – Select to connect directly and avoid a proxy connection.
- **Native** – Select to use system proxy configuration for network connection.
- **Work offline** – Select to disable both the connection to NXP cloud and the download of processor/board/kit data.
- **Processor data update** – Select from the following options:
  - **Auto Update** – Select to update the processor data automatically.
  - **Manual** – Select to be update processor data after confirmation.
  - **Disabled** – Select to disable processor data update.
- **Show pin label & identifier table columns (Pins tool)** – Select to show the pin label and the label identifier in the relevant views.
- **Automatically load last configuration on startup** – Select to avoid the startup dialog and load the last used configuration instead.

## 2.5 Configuration preferences

The configuration preferences are general preferences stored within the configuration storage file (MEX).

To configure the preferences related to the configuration, uses popup menu on the Eclipse project, select **Properties** and then **MCUXpresso Config Tools** in the left pane.

The following preferences are available:


- **Validate boot init only** – Select to validate tools dependencies only against 'boot init' function group. When selected, dependencies from all functional groups of all tools must be satisfied in the functional groups marked for default initialization. Clearing this option hides warnings in case the user is using complex scenarios with alternating functional groups within the application code.
- **Generate YAML** – Select to generate YAML into C sources files.
- **Generate extended information into header file** – Select to generate extended information into the header file. For projects created in earlier MCUXpresso versions, this option is selected by default.

### WARNING

When the source does not contain YAML code, it can't be imported.

## 2.6 Problems view

This view displays problems in the tools and the inter-dependencies between the tools.



Level	Issue	Origin	Target	Resource	Type
Error	Routing conflict on 'Route t...	Pins:BOARD_InitPins		#37-I2C0.SCL	Tool problem
Error	Routing conflict on 'Route t...	Pins:BOARD_InitPins		#59-I2C0.SCL	Tool problem
Warning	Peripheral UART1 is not initi...	Pins:BOARD_InitPins	Peripherals: BOARD_InitPeri...	UART1	Validation
Warning	Warning		BOARD_InitPeri...	I2C0	Validation

There is a quick-fix available for the problem, see context menu for details.

Figure 14. Problems view

To open the **Problems** view, select **Views > Problems**.

The table contains the following information:



- **Level** – Lists the severity of the problem: Information, Warning, or Error.
- **Issue** – Description of the problem.
- **Origin** – Information on the dependency source.
- **Target** – Lists the tool that handled the dependency and where it should be fulfilled.
- **Resource** – Lists the resource which is related to the problem,. For example, the signal name, the clock signal, and so on.
- **Type** – The type of the problem. It is either the validation that is checking dependencies between the tools, or the tool problem that describes problem related just to one tool.

### Context-menu



Every problem comes with a context menu accessible by right-clicking the problem row. Use this menu to access information about the problem or to apply a quick fix where applicable.

#### NOTE

Quick fix is only available for problems highlighted with the "lightbulb" icon.

### Filter buttons

The filter buttons are available on the right side of the problems view.

- 
  - Enables the 'Validate boot init only' preference. See [Configuration preferences](#) section for details.
- 
  - Filters messages in the **Problems** view. If selected, only problems for the active tool are displayed. See [Configuration preferences](#) section for details.

## 2.7 Registers view

The **Registers** view lists the registers handled by the tool models. You can see the state of the processor registers that correspond to the current configuration settings and also the state that is in the registers by default after the reset. The values of the registers are displayed in the hexadecimal and binary form. If the value of the register (or bit) is not defined, an interrogation mark "?" is displayed instead of the value.




Figure 15. Registers view

The **Registers** view contains:

- **Peripheral filter** drop-down list – Use to list the registers only for the selected peripheral. Select “all” to list registers for all the peripherals.
- **Show modified registers only** checkbox – Select this option to hide the registers that are left in their after-reset state or are not configured.
- **Text filter** – Use to filter content by text.

The following table lists the color highlighting styles used in the **Registers** view.

Table 2. Color codes

Color	Description
Yellow background	Indicates that the bit-field has been affected by the last change made in the tool.
Gray text color	Indicates the bit-field is not edited and the value is the after-reset value.
Black text	Indicates the bit-fields that the tool modifies.

**NOTE**

This view contains registers for the selected tool. The view uses registers as internal parameters but it might not handle all the register writes needed in the code. The register writes are done inside the SDK functions that are called by the generated code. There might be additional registers accessed in the SDK code during the setup process, and such register writes are not known to the tool and are not displayed in the registers view.

## 2.8 Log view

The **Log** view shows user-specific information about the progress of the tools. The **Log** view can show up to 100 records across all tools in the chronological order.

Each record consists of the timestamp, the name of the tool responsible for the record, the severity level, and the actual message. If no tool name is specified, the records is created by the shared functionality.

The content of the **Log** view can be filtered using the combo boxes to display only specific tool and/or severity level information. Filters in different tools can be set independently.

Buffered log records are cleared using the clear button. This affects **Log** views of all tools.




Figure 16. Log view

## 2.9 Config tools overview

By default, the **Config Tools Overview** icon is located on the left side of the toolbar, and opens a dialog with the following options:

- **Configuration – General Info** – Displays the name of and the path to the MEX file of the current configuration. Click the link to open the folder containing the MEX file. To import additional settings, click the **Import additional settings into current configuration** button.
- **Configuration – HW Info** – Displays the processor, part number, core, and SDK-version information of the current configuration.
- **Project** – Displays the toolchain project information.
- **Pins/Clocks/Peripherals** – Displays basic information about the **Pins**, **Clocks**, and **Peripherals** tools.

#### NOTE

If you have disabled a tool and want to reopen it, click the tool icon in the upper right corner or select it from the Main Menu. The **Config Tools Overview** opens automatically.

To enable/disable the tools, click the toggle button. You can navigate to the tools by clicking their icons. The following information about the tools is also available:

- **Generated code** – Contains the list of source-code files. Click the links to open the files in the **Code Preview** view.
- **Functional groups** – Contains the list of the currently active functional groups. To select the groups in the **Functional groups** tab in the toolbar, select the relevant links.




Figure 17. Config Tools Overview dialog

# Chapter 3

## Pins Tool

The Pins Tool is an easy-to-use tool for configuration of device pins. The Pins Tool software helps create, inspect, change, and modify any element of pin configuration and device muxing.

### 3.1 Pins routing principle

The Pins Tool is designed to configure routing peripheral signals either to pins or to internal signals.

Internal signal is an interconnection node which peripheral signals can be connected to (without any pin interaction). Connecting two peripheral signals to internal signal makes an interconnection of these two peripheral signals.

This routing configuration can be done in either of these views:

- Pins
- Peripheral Signals
- Package
- Routed Pins

The following two sections describe the two methods you can use to define the routing path.

#### 3.1.1 Beginning with peripheral selection

You can select peripheral in the **Routed Pins** view and the **Peripheral Signals** view.

1. Select the **Peripheral**.
2. In **Routed Pins** view, select one of the available **Signals** or expand the peripheral in **Peripheral Signals** view.
3. Selected the desired pin/internal signal.

Items (pins/internal signals) in the **Route to** column in the **Routed Pins** view have following decorators:

- Exclamation mark and default text color indicates that such item selection causes a register conflict or the item cannot be routed to the selected peripheral signal (some other peripheral signal can be).
- Exclamation mark and gray text color indicates that the item cannot be routed to any signal of the selected peripheral. The item is available for different peripheral using the same signal.

#### NOTE

Route to field in Routed Pins view contains items that are connectable to the selected signal (without its channel if applicable). So when selected signal is "GPIO, 6" then the **Route to** provides items connectable to "GPIO".

#### NOTE

In the **Package** view there is no possibility to select pin/internal signal when a peripheral signal is connectable to more pins/internal signals.




Figure 18. Defining routing path

### 3.1.2 Beginning with pin/internal signal selection

You can select a pin or an internal signal in the **Routed Pins** view.

1. Select the pin/internal signal (**Route to**).
2. Select one of the available **Peripherals**. In the **Pins** view, see all available peripherals/signals by clicking on the checkbox in the first column or scroll the columns to the required peripheral type.
3. For the selected peripheral, select one of the available **Signals**.

Items in **Peripheral** column in Routed Pins view have following symbols:

- Exclamation mark and default text color indicates that such item selection can cause a register conflict or the item does not support selected signal.
- Exclamation mark and gray text color indicates that the item cannot be routed to the selected pin/internal signal. The item is available for different pin/internal signal using the same signal.

#### NOTE

In the **Pins** view and the **Package** view you can configure only pins and not internal signals.

## 3.2 Workflow

The following steps briefly describe the basic workflow in the Pins Tool.

1. In the **Pins** view on the left find a pin and peripheral signal in the table and configure the routing by clicking on the signal cell.

#### NOTE

This routing configuration can be similarly done in other Pins views **Peripheral Signals**, **Package**, **Routed Pins**.

2. Optionally, configure the electrical properties in the **Routed pins** view in the middle by selecting required state.

#### NOTE

Source code is automatically generated.

3. Open the **Code Preview** view to inspect the source code.
4. Click the **Update Project** button in the **Toolbar** to update the code.

## 3.3 Example usage

This section lists the steps to create an example pin configuration, which can then be used in a project.

In this example, three pins (**UART3\_RX**, **UART3\_TX** and **PTB20**) on a board are configured.

You can use the generated files with the application code.

1. In the **Pins** view on the left, select the **UART3\_RX** and **TX** signals. For this, you can click into the cells to make them 'green'.




Figure 19. Configure Signals in Pins View

2. In the middle view, called the **Routed Pins** view, select the **Output** direction for the TX and PTB20 signals.

#	Peripheral	Signal	Route to	Label	Identifier	Direction	GPIO initial state	GPIO interrupt	Slew rate	Open drain	Drive strength	Pull select	Pull enable	Passiv
55	FTM3	CH, 6	FTM3_CH6	J1[13]/I2C1_SCL/I2S0_RX_FS	n/a	Not Specified	n/a	n/a	Fast	Disabled	Low	Pulldown	Disabled	Disab
40	GPIOB	GPIO, 17	PTB17	PUSH_BUTTON1	SW3	Input	n/a	Interrupt/DM...	Fast	Disabled	Low	Pulldown	Disabled	Disab
						Input								
						Output								
						Not Specified								

Figure 20. Select Direction

#### NOTE

For GPIO peripherals, you can set the **Direction** by clicking the cell and selecting from the drop-down menu. If you select **Output** you can also set **GPIO initial state** by clicking the cell in the **GPIO initial state** column. If you select **Input** you can also set **GPIO interrupt** by clicking the cell in the **GPIO interrupt** column.

3. The Pins Tool automatically generates the source code for `pin_mux.c` and `pin_mux.h` on the right panel of the **Code Preview** view.

```

/*****
 * This file was generated by the MCUXpresso Config Tools. Any manual edits made to this file
 * will be overwritten if the respective MCUXpresso Config Tools is used to update this file.
 *****/

/* clang-format off */
/*
 * TEXT BELOW IS USED AS SETTING FOR TOOLS *****
!!GlobalInfo
product: Pins v4.0
processor: MK22FN512xxx12
package_id: MK22FN512VLH12
mcu_data: ksdk2_0
processor_version: 0.0.11
board: FRDM-K22F
 * BE CAREFUL MODIFYING THIS COMMENT - IT IS YAML SETTINGS FOR TOOLS *****
 */
/* clang-format on */

#include "fsl_common.h"
#include "fsl_port.h"
#include "fsl_gpio.h"
#include "pin_mux.h"

/* FUNCTION *****
 *
 * Function Name : BOARD_InitBootPins
 * Description   : Calls initialization functions.
 *
 * END *****
void BOARD_InitBootPins(void)
{
}


/* clang-format off */
/*
 * TEXT BELOW IS USED AS SETTING FOR TOOLS *****

```

Figure 21. Generated code

4. You can now copy-paste the content of the source(s) to your application and IDE. Alternatively, you can export the generated files. To export the files, select the menu **File > Export** (in the desktop version) or select the menu **Pins > Export** menu (in the Web version). In the **Export** dialog expand the tree control for the tool you want to export sources for and select the **Export Source Files** option. **Export**, select the **Export Source Files** option.





**Figure 22. Export Source Files**

5. Click **Next** and specify the directory for each respective core (in multicore configuration) where you want to store the exported files for each individual core (in case of multicore configuration).
6. Click **Finish** to export the files.
7. Integrate and use the exported files in your application as source files.

## 3.4 User interface

Pins Tool consists of several views.

## Pins Tool




Figure 23. Pins Tool user interface




Figure 24. Selecting power group

### NOTE

Power Groups are not supported for all processors.

## 3.4.1 Functions

'Functions' are used to group a set of routed pins, and they create code for the configuration in a function which then can be called by the application.

The tool allows to create multiple functions that can be used to configure pin muxing.

#	Peripheral	Signal	Route to	Label	Identifi
26	GPIOA	GPIO, 4	PTA4	SH_U1[9]/SH_J4[3]/SH_INT2_8700/J1[10]/LLWU_P3	ACCEL1
39	GPIOB	GPIO, 16	PTB16	SH_U1[11]/SH_J4[1]/SH_INT1_8700/J1[6]/J8[G1]/SD_CARD_DETECT	ACCEL1
37	I2C0	SCL	I2C0_SCL	SH_J6[3]/SH_U1[4]/SH_U2[11]/SH_J3[4]/SH_I2C_SCL1/SH_SCL1_SCLK/J24[12]/U8[4]/U18[28]/I2C0_SCL	ACCEL1
38	I2C0	SDA	I2C0_SDA	SH_J7[3]/SH_U1[6]/SH_U2[12]/SH_J3[5]/SH_I2C_SDA1/SH_SDA1_MOSI/J24[10]/U8[6]/U18[27]/I2C0_SDA	ACCEL1

Figure 25. Routed Pins view

The usage of pins is indicated by 50% opacity in **Pins**, **Peripheral Signals**, and **Package** views. Each function can define a set of routed pins or re-configure already routed pins.

When multiple functions are specified in the configuration, the package view primarily shows the pins and the peripherals for the selected function. Pins and peripherals for different functions are shown with light transparency and cannot be configured, until switched to this function.

## 3.4.2 Package

The processor package appears in the middle of the Pins Tool window. The processor package shows an overall overview of the package including resource allocation.




Figure 26. Processor package

This view shows Package overview with pins location. In the center are the peripherals.

For BGA packages, use the **Resources** icon to see them.

- Green color indicates the routed pins/peripherals.
- Gray color indicates that the pin/peripheral is not routed.
- Dark Gray color indicates that the pin/peripheral is dedicated. It is routed by default and has no impact on generated code.

The view also shows the package variant and the description (type and number of pins).

The following icons are available in the toolbar:

Table 3. Toolbar options









Icon	Description
	Zoom in package image.

Table continues on the next page...

Table 3. Toolbar options (continued)

Icon	Description
	Zoom out package image.
	Rotate package image.
	Show pins as you can see it from the bottom. This option is available on BGA packages only.
	Show pins as you can see it from the top. This option is available on BGA packages only.
	Show resources. This option is available on BGA packages only.
	Switch package.
	Package legend

**NOTE**

Depending on the processor package selected, not all views are available.

The **Switch package** icon launches **Switch package for the Processor**.




Figure 27. Switch package

The **Switch package for the Processor** dialog shows list of available processor packages, showing package type and number of pins.

### 3.4.3 Routed Pins view

The **Routed Pins** view displays a list of routed pins and allows further configuration. This view also allows the configuration of the electrical properties of pins and displays all the pins. It displays the pad configuration available in a configuration where each pin is associated with the signal name and the function.

#### NOTE

The electrical features are configured only for pins in the table. For example, the routed pins.

The table is empty when the new configuration is created, which means no pin is configured. Each row represents configuration of a single pin and if there are no conflicts, then the code is immediately updated. For Boards/Kits the pins are routed already.

Use the table drop down menu to configure the pin. To configure pins, start from left to right – select the peripheral first, then the required signal, and finally, the routed pin.

See the right part of the table to configure the electrical features.

If the feature is not supported, n/a is displayed.

#	Peripheral	Signal	Route to	Label	Identifier	Direction	GPIO initial state	GPIO interrupt	Slew rate	Open drain	Drive strength	Pull select	Pull enable	Passive filter	Digital filter
5.	FTM3	CH_6	FTM3_CH6	J1[13]/I2C1_SCL/I2S0_RX_FS	<i>n/a</i>	Not Specified	<i>n/a</i>	<i>n/a</i>	Fast	Disabled	Low	Pulldown	Disabled	Disabled	<i>n/a</i>
4.	GPIOB	GPIO_17	PTB17	PUSH_BUTTON1	SW3	Input	<i>n/a</i>	Interrupt on ...	Fast	Disabled	Low	Pulldown	Disabled	Disabled	<i>n/a</i>
2	GPIOE	GPIO_1	PTE1	J2[20]/UART1_RX_TGTMCU	Not Spe...	Output	Logical 1	<i>n/a</i>	Fast	Disabled	Low	Pulldown	Disabled	Disabled	<i>n/a</i>

Figure 28. Routed Pins view

The gray background indicates the read-only items.

The italic value indicates that the value is not configured and it shows the after-reset value and no code is generated, so the configuration relies on the after reset value or the values configured from the different functions.

#### TIP

- The value shown using italic indicates the after-reset value. The real value may be different from the after reset value, if configured in other functions.  
Use the drop-down menu to select the required value.
- If you select the same value as the after-reset value, the tool will always generate code to set this feature.  
Use the drop-down "Reset" value to reset the value to its after-reset state.
- If an item does not support reset to after reset value, the **Reset** menu is not available. The first row shows pin number or coordinate on BGA package.

#### 3.4.3.1 View controls

The following figure illustrates the **Routed pins** view controls.




Figure 29. View controls

**Add / remove rows:**

- To add a new row to the end of table, click on the [+] button.
- To remove the selected row, click on the [x] button.
- To delete a specific row or insert a new row at a given position, right-click and use the pop-up menu commands.

**Add a specific number of rows or clear the table:**

- To add a specific number of rows, specify the exact number of rows.
- To clear the table, type 0.

**Change the order of the rows:**

To change the order of the rows, use the arrow icons to move one row up or down.

**Filter table entries:**

To filter table entries by text, enter the text string in the **type filter text** field.

**Copy-paste rows:**

To copy the row, right-click any cell in the row and choose **Copy**. You can later paste the copied row into the **Routed Pins** view of another functional group or configuration by right-clicking the table area and choosing **Paste**.

### 3.4.3.2 Filtering routed pins

The following image illustrates the filter area of the **Routed Pins** view.




Figure 30. Filter area

To instantly filter rows, type the text or the search phrase in the filter area (type filter text).






**NOTE**

When you enter the search text, it also searches the text in the full pin names displays rows that contain the search text.


### 3.4.4 Peripheral Signals view

The **Peripheral Signals** view shows a list of peripherals and their signals. Only the **Peripheral Signals** and **Pins** view shows the checkbox (allocated) with status.

**Table 4. Status codes**

Color code	Status
	Error
	Configured
	Not configured
	Warning
	Dedicated: Device is routed by default and has no impact on the generated code.





**Figure 31. Peripheral Signals view**

Use the checkbox to route/unroute the selected pins.

To route/unroute multiple pins, click the peripheral and select the options in the **Select signals** dialog.




Figure 32. Select signals dialog

### 3.4.5 Pins table view

The **Pins** table view shows all the pins in a table format.

Pin	Pin name	Label	Identifier	GPIO	FTM	SIM	ADC	FB	UART	SPI
<input checked="" type="checkbox"/>	1	UART1_TX	J2[18]/UART1...	DEBUG_UAR...	PTE0		CLKOUT32K[...	ADC1_SE4a	UART1_TX	SPI
<input checked="" type="checkbox"/>	2	UART1_RX	J2[20]/UART1...	DEBUG_UAR...	PTE1			ADC1_SE5a	UART1_RX	SPI
<input type="checkbox"/>	3	VDD3	P3V3_K22F							
<input type="checkbox"/>	4	VSS4	GND							
<input type="checkbox"/>	5	USB0_DP	USB_DP	USB_DP						
<input type="checkbox"/>	6	USB0_DM	USB_DN	USB_DN						
<input type="checkbox"/>	7	VOUT33	USB_VOUT33	USB_VOUT33						
<input type="checkbox"/>	8	VREGIN	P5V_K22F	USB_VREGIN						
<input checked="" type="checkbox"/>	9	ADC0_DP0/A...	J24[1]/ADC0...				ADC0_DP0[...]			
<input checked="" type="checkbox"/>	10	ADC0_DM0/...	J24[3]/ADC0...				ADC0_DM0[...]			
<input checked="" type="checkbox"/>	11	ADC1_DP0/A...	J24[5]/ADC0...	LSENSE_EMI...			ADC1_DP0[...]			
<input checked="" type="checkbox"/>	12	ADC1_DM0/...	J24[7]/ADC0...				ADC1_DM0[...]			
<input type="checkbox"/>	13	VDDA	P3V3_K22F							
<input checked="" type="checkbox"/>	14	VREFH	J2[16]/VREFH				VREFH[...]			
<input checked="" type="checkbox"/>	15	VREFL	VREFL				VREFL[...]			
<input checked="" type="checkbox"/>	16	VSSA	VSSA				VSSA[...]			
<input checked="" type="checkbox"/>	17	VREF_OUT/C...	J2[1]				VREF_OUT[...]			
<input checked="" type="checkbox"/>	18	DAC0_OUT/...	J24[11]/DAC0...				ADC0_SE23			
<input type="checkbox"/>	19	XTAL32	XTAL32_RTC	XTAL32						
<input type="checkbox"/>	20	EXTAL32	EXTAL32_RTC	EXTAL32						
<input type="checkbox"/>	21	VBAT	VBAT							
<input type="checkbox"/>	22	PTA0/UART0...	J11[4]/SWD_...		PTA0	FTM0_CH5	FTM0_CH5		UART0_CTS_b	
<input type="checkbox"/>	23	PTA1/UART0...	J2[4]/RED_LED	LEDRGB_RED	PTA1	FTM0_CH6	FTM0_CH6		UART0_RX	
<input type="checkbox"/>	24	PTA2/UART0...	J1[8]/GREEN_...	LEDRGB_GRE...	PTA2	FTM0_CH7	UART0_TX[...]		UART0_TX	
<input type="checkbox"/>	25	PTA3/UART0...	J11[2]/SWD_...		PTA3	FTM0_CH0	FTM0_CH0		UART0_RTS_b	
<input type="checkbox"/>	26	PTA4/LLWU_...	J1[10]/LLWU_...		PTA4	FTM0_CH1	FTM0_CH1			
<input checked="" type="checkbox"/>	27	PTA5	J1[1]/I2S0_TX...	AC_I2S_SCLK...	PTA5	FTM0_CH2	FTM0_CH2			
<input type="checkbox"/>	28	PTA12/FTM1...	J1[5]/I2S0_TX...	AC_I2S_DIN	PTA12	FTM1_CH0[...]				
<input type="checkbox"/>	29	PTA13/I2S1_TX...	J1[3]	AC_I2S_I2S1_K	PTA13	FTM1_CH1[...]	FTM1_CH1			

Figure 33. Pins table view

This view shows the list of all the pins available on a given device. The **Pin name** column shows the default name of the pin, or if the pin is routed. The pin name is changed to show appropriate function for selected peripheral if routed. The next columns of the table shows peripherals and pin name(s) on given peripheral. Peripherals with few items are cumulated in the last column.

To route/un-route pin to the given peripheral, click in the cell of the table. Routed pins are marked with checkbox and green color. Colored cells indicate that a pin is routed to given peripherals. If there is conflict in routing, red color is used.

Unroute is possible by clicking on a given cell, or by checkbox in the first column.

Every routed pin appears in the Routed pins table.

When multiple functions are specified in the configuration, the Pins Table view shows pins for selected function primarily. Pins for different functions are shown with light transparency and cannot be configured until switched to this function.

#### TIP

The option to route more signals to a single pin is indicated by an ellipsis (...). The **Multiple Signals Configuration** dialog appears, if clicked.

### 3.4.5.1 Labels and identifiers

It's possible to define label of any pin that can be shown in UI for easy pin identification.

The boards and kits have pre-defined labels. However, it is also possible to define a pin label listed in the **Routed Pins** view. To set/update the **Labels and Identifier** columns visibility, select **Edit > Preferences**.

The pin identifier is used to generate the `#define` in the `pin_mux.h` file. However, it's an optional parameter. If the parameter is not defined, the code for `#define` is not generated. Additionally, you can define multiple identifiers, using the “,” character as a separator. You can also set the identifier by typing it directly into the cell in the **Identifier** column in the **Routed Pins** view.

Pin	Pin name	Label	Identifier	GPIO
49	VSS81	GND		
50	EXTAL0/PTA18/...	U13[16]/RMII_RXCLK	EXTAL0;RMII_RXCLK	PTA18
51	XTAL0/PTA19/F...	GND		PTA19
52	RFSFT h	I3I61/I9I101/D1/RFSFT	RFSFT	

Figure 34. Pin Identifier

In this case it's possible to select from values if the pin is routed. See [Routed pins table](#).

#	Peripheral	Signal	Route to	Label	Identifier	Directi
50	GPIOA	GPIO, 18	PTA18	U13[16]/RMII_R...	EXTAL0	Input
					EXTAL0	
					RMII_RXCLK	
					Not Specified	

Figure 35. Identifier in Routed Pins table

A check is implemented to ensure whether the generated defines are duplicated in the `pin_mux.h` file. These duplications are indicated in the identifier column as errors. See [Identifier errors](#).

#	Peripheral	Signal	Route to	Label	Identifier	Direction	Slew rate	Open drain	Drive strength	Pull select	Pull enable	Passiv
50	FTM0	FLT, 2	FTM0_FLT2	U13[16]/RMII_RXCLK	RMII_RXCLK	Input	Fast	Disabled	Low	Pulldown	Disabled	Disat
28	RTC	XTAL32	XTAL32	Y3[1]/XTAL32_RTC	RMII_RXCLK		n/a	n/a	n/a	n/a	n/a	n/a
78	ADC0	TRG, A	PDB0_EXT...	U8[11]/SW2	EXTAL0							
7	SPI1	PCS3	SPI1_PCS3	J15[G1]/SD_CARD_D...	Not Sp							
92	UART3	RTS	UART3_RT...	J6[8]/RF_WIFI_IRQ	TMR_158							
50	OSC	EXTAL0	EXTAL0	U13[16]/RMII_RXCLK	RMII_RXCLK							

Figure 36. Identifier errors

You can also select the pin to use in a given routing from the **Routed Pins** view. However, the identifier must be a valid C identifier and should be used in the source code.





Figure 37. Pins macros prefix

If multiple functions are used, each individual function can include a special prefix. Check the **Pins > Functional Group Properties > Set custom #define prefix** checkbox to enter prefix of macros in particular function used in the generated code of the `pin_mux.h` file. Entered prefix text must be a C identifier. If unchecked, the **Function name** is used as a default prefix.

### 3.4.6 Filtering in the Pins and Peripheral Signals views

The following image illustrates the filtering controls in the **Pins** and **Peripheral Signals** views.



**Figure 38. Filtering Controls**

Type any text to search across the table/tree. It will search for the pins/peripheral signals containing the specified text. You can also use wildcards "\*" and "?" to help you filter results you want. Use "space" to search for multiple strings at the same time.

### 3.4.7 Highlighting and color coding

It's possible to easily identify routed pins/peripherals in the package using highlighting. By default, the current selection (pin/peripheral) is highlighted in the package view.

- The pin/peripheral is highlighted by yellow border around it in the Package view. If the highlighted pin/peripheral is selected then it has a blue border around it.
- Red indicates that the pin has an error.
- Green indicates that the pin is muxed or used.
- Light grey indicates that the pin is available for mux, but is not muxed or used.
- Dark gray indicates that the pin/peripheral is dedicated. It is routed by default and has no impact on generated code.




Figure 39. Highlighting and color coding

#	Peripheral	Signal	Route to	Label	Identifier	Direction	Slew rate	Open drain	Drive strength
80	CMP0	IN, 0	ADC1_SE4...	J1[7]	n/a	n/a	Fast	Disabled	Low
26	CMP1	IN, 1	VREF_OUT...	J2[17]	n/a	n/a	n/a	n/a	n/a
4	GPIOE	GPIO, 3	PTE3	J15[P3]/SDHC0_C...	Not Specified	Not Specifi...	Fast	Disabled	Low
	CMP1	IN, 0			n/a	n/a	n/a	n/a	n/a
6	UART3	RX	UART3_RX	J15[P1]/SDHC0_D2	Not Specified	Input	Fast	Disabled	Low
6	FTM3	CH, 0	FTM3_CH0	J15[P1]/SDHC0_D2	Not Specified	Not Specifi...	Slow	Disabled	Low
					n/a	n/a	n/a	n/a	n/a

Figure 40. Pins conflicts

#	Peripheral	Signal	Route to	Label	Identifier	Direction	Slew rate
33	GPIOE	GPIO, 26	PTE26	J2[1]/D12[4]/LEDRGB_GREEN	Not Specified	Input	Slow
71	FTM0	CH, 0	FTM0_CH0	J1[5]	n/a	Output	Fast

Figure 41. Warnings

- Package view
  - Click on the peripheral or use the pop-up menu to highlight peripherals:

- and all allocated pins (to selected peripheral).
- or all available pins if nothing is allocated yet.
- Click on the pin or use the pop-up menu to highlight the pin and the peripherals.
- Click outside the package to cancel the highlight.
- **Peripherals / Pins view**
  - The peripheral and pin behaves as described above image.

## 3.5 Errors and warnings

The Pins Tool checks for any conflict in the routing and also for errors in the configuration. Routing conflicts are checked only for the selected function. It is possible to configure different routing of one pin in different functions to allow dynamic pins routing re-configuration.

#	Peripheral	Signal	Route to	Label	Identifier	Direction	Slew rate	Open drain
✖ 1	GPIOE	GPIO, 0	✖PTE0	J15[P8]/SD...	Not Specif...	Not Specifi...	Fast	Disabled
✖ 1	UART1	TX	✖UART1_TX	J15[P8]/SD...	Not Specif...	Not Specifi...	Fast	Disabled
10	USBDCD	DP	USB0_DP	J22[3]/K64...	Not Specif...	Input/Out...	n/a	n/a
⚠ 4	GPIOE	GPIO, 3	PTE3	J15[P3]/SD...	⚠Not Specif...	Output	Fast	Disabled

Figure 42. Error and warnings

If an error or warning is encountered, the conflict in the **Routed Pins** view is represented in the first column of the row and the error/warning is indicated in the cell, where the conflict was created. The first two rows in the figure above show the peripheral/signal where the erroneous configuration occurs. The fourth row shows the warning on the unconfigured identifier while specifying a direction. The detailed error/warning message appears as a tooltip.

For more information on error and warnings color, see the [Highlighting and Color Coding](#) section.

### 3.5.1 Incomplete routing

A cell with incomplete routing is indicated by a red background. To generate proper pin routing, click on the drop down arrow and select the suitable value. A red decorator on a cell indicates an error condition.

#	Peripheral	Signal	Route to	Label	Identifier	Direction	Slew rate	Open drain
1	UART1	TX	UART1_TX	J15[P8]/SD...	Not Specif...	Not Specifi...	Fast	Disabled
10	USBDCD	DP	USB0_DP	J22[3]/K64...	Not Specif...	Input/Out...	n/a	n/a
✖ 4	✖	GPIO, 3	✖ADC0_DM...	J15[P3]/SD...	Not Specif...	n/a	Fast	Disabled

Figure 43. Incomplete routing

The tooltip of the cell shows more details about the conflict or the error, typically it lists the lines where conflict occurs.

## 3.6 Code generation


The tool generates source code that can be incorporated into an application to initialize pins routing. The source code is generated automatically on change or can be generated manually by selecting **Pins > Refresh** from the main menu. The generated code is shown in the **Code Preview** view. It shows all generated files and each file has its own tab.

For multicores, the sources are generated for each core. Appropriate files are shown with @Core #{number} tag.

#### NOTE

The tag name may be different depending on the selected multi-core processor family/type.

You can also copy and paste the generated code into the source files. The view generates code for each function. In addition to the function comments, the tool configuration is stored in a YAML format. This comment is not intended for direct editing and can be used later to restore the pins configuration.



```

/home/Overview Code Preview Registers
pin_mux.c pin_mux.h
/******
 * This file was generated by the MCUXpresso Config Tools. Any ma
 * will be overwritten if the respective MCUXpresso Config Tools is u
 *****/

/* clang-format off */
/*
 * TEXT BELOW IS USED AS SETTING FOR TOOLS *****
!!GlobalInfo
product: Pins v5.0
processor: MK64FN1M0xxx12
package_id: MK64FN1M0VLL12
mcu_data: kSDK2_0
processor_version: 4.0.0
board: FRDM-K64F
pin_labels:
- {pin_num: '90', pin_signal: PTC16/UART3_RX/ENET0_1588_TMR0/FE
- {pin_num: '91', pin_signal: PTC17/UART3_TX/ENET0_1588_TMR1/FE
- {pin_num: '57', pin_signal: PTB9/SPI1_PCS1/UART3_CTS_b/FB_AD20
- {pin_num: '35', pin_signal: PTA1/UART0_RX/FTM0_CH6/JTAG_TDI/E
- {pin_num: '69', pin_signal: PTB23/SPI2_SIN/SPI0_PCS5/FB_AD28, la
- {pin_num: '36', pin_signal: PTA2/UART0_TX/FTM0_CH7/JTAG_TDO/
- {pin_num: '72', pin_signal: ADC0_SE4b/CMP1_IN0/PTC2/SPI0_PCS2
- {pin_num: '73', pin_signal: CMP1_IN1/PTC3/LLWU_P7/SPI0_PCS1/U
- {pin_num: '64', pin_signal: PTB18/CAN0_TX/FTM2_CH0/I2S0_TX_BC
- {pin_num: '65', pin_signal: PTB19/CAN0_RX/FTM2_CH1/I2S0_TX_FS
- {pin_num: '71', pin_signal: ADC0_SE15/PTC1/LLWU_P6/SPI0_PCS3/U
- {pin_num: '80', pin_signal: ADC1_SE4b/CMP0_IN2/PTC8/FTM3_CH4
- {pin_num: '81', pin_signal: ADC1_SE5b/CMP0_IN3/PTC9/FTM3_CH5
- {pin_num: '77', pin_signal: PTC5/I1W11_P9/SPI0_SCK/I2TMR0_ΔIT2

```

Figure 44. Generated code

YAML configuration contains configuration of each pin. It stores only non-default values.

#### TIP

For multicore processors, it will generate source files for each core. If processor is supported by SDK, it can generate BOARD\_InitBootPins function call from main by default. You can specify "Call from BOARD\_InitBootPins" for each function, in order to generate appropriate function call.



# Chapter 4

## Clocks Tool

The Clocks Tool configures initialization of the system clock (core, system, bus, and peripheral clocks) and generates the C code with clock initialization functions and configuration structures.

### 4.1 Features

Following are the features of the Clock Tool:

- Inspects and modifies element configurations on the clock path from the clock source up to the core/peripherals.
- Validates clock elements settings and calculates the resulting output clock frequencies.
- Generates a configuration code using the SDK.
- Modifies the settings and provides output using the table view of the clock elements with their parameters.
- Navigate, modify, and display important settings and frequencies easily in **Diagram** view.
- Edit detailed settings in Details view.
- Inspect the interconnections between peripherals and consuming clocks in Module Clocks view.
- Helps to find clock elements settings that fulfills given requirements for outputs.
- Fully integrated in tools framework along with other tools.
- Shows configuration problems in Problems view and guides the user for the resolution.

### 4.2 User interface overview

The Clocks Tool is integrated and runs with the MCUXpresso Config Tools framework. For documentation on the common interface and menu items, see the Config Tools User Interface chapter.

## Clocks Tool




Figure 45. User interface

## 4.3 Clock configuration

Each clock configuration (functional group) lists the settings for the entire clock system and is a part of the global configuration stored in the MEX file. Initially, after the new clock configuration is created, it's set to reflect the default after-reset state of the processor.

There can be one or more clock configurations handled by the Clocks Tool. The default clock configuration is created with the name "BOARD\_BootClockRUN". Multiple configurations means multiple options are available for the processor initialization.

### NOTE

All clock settings are stored individually for each clock configuration so that each clock configuration is configured independently.

Clocks configurations (functional groups) are presented at the top of the view. You can switch between them by selecting them from the dropdown menu.




Figure 46. Default clock configuration

**NOTE**

The code generation engine of the tool generates function with the name derived from the Clock configuration name.

## 4.4 Global settings

Global settings are settings that influence the entire clock system. It's recommended to set them first. Global settings can be modified in the **Clock Table** view.

**NOTE**

Global settings can be changed at any time.




Figure 47. Global settings

## 4.5 Clock sources

The **Clock Sources** table is located in the **Clocks Table** view. You can also edit the clock sources directly from the **Diagram** view or from the **Details** view.

You can configure the availability of external clock sources (check the checkbox) and set their frequencies. Some sources can have additional settings available when you unfold the node.

If the external crystal or the system oscillator clock is available, check the checkbox in the clock source row and specify the frequency.




Figure 48. External clock source configuration

**NOTE**

Some clock sources remain inactive even though the checkbox is checked. This is because the clock sources functionality depends on other settings like power mode or additional enable/disable setting options. You can hover the cursor on the setting to see a tooltip with information on the element and possible limitations/options.

## 4.6 Setting states and markers

The following states, styles, and markers reflect the information shown in the settings' rows in the settings tables (clock sources, output, details or individual).

Table 5. Setting states and markers

State/Style/Marker	Icon	Description
Error marker		Indicates that there is an error in the settings or something related to it. See the tooltip of the setting for details.
Warning marker		Indicates that there is a warning in the settings or something related to it. See the tooltip of the setting for details.
Lock icon		Indicates that the settings (that may be automatically adjusted by the tool) are locked to prevent any automatic adjustment. If the setting can be locked, they are automatically locked when you change the value. To add/remove the lock manually, use the pop-up menu command <b>Lock/Unlock</b> .  <div style="text-align: center;"><b>NOTE</b></div> The clock element settings that cannot be automatically adjusted by the tool keep their value as is and do not allow locking. These are: clock sources, clock selectors and configuration elements.
Yellow background		Indicates that the field is directly or indirectly changed by the previous user action.
Gray text		Indicates that the value of setting does not actively influence the clock. It is disabled or relates to an inactive clock element. For example, on the clock path following the unavailable clock source or disabled element. The frequency signal also show the text “inactive” instead of frequency. The value is also gray when the value is read-only. In such a state it is not possible to modify the value.

## 4.7 Frequency settings

The Clocks Tool instantly re-calculates the state of the entire clock system after each change of settings from the clock source up to the clock outputs.

The current state of all clock outputs is listed in the **Clock Outputs** view located on the right side of the clock sources. The displayed value can be:

- **Frequency** – Indicates that a clock signal is active and the output is fed with the shown frequency. The tool automatically chooses the appropriate frequency units. In case the number is too long or has more than three decimal places, it's shortened and only two decimal places are shown, followed by an ellipsis ('...'), indicating that the number is longer.
- **“Inactive”** text – Indicates that no clock signal flows into the clock output or is disabled due to some setting.

If you have a specific requirement for an output clock, click on the frequency you would like to set, change it, and press **Enter**.

**Core clock** 100 MHz

Figure 49. Setting the core clock frequency

In case the tool has reached/attained the required frequency, it appears locked and is displayed as follows:

**Core clock** 100 MHz

Figure 50. Tool attains the required frequency

In case the tool is not able to reach/attain the required frequency or some other problem occurs, it's displayed as follows:



Figure 51. Tool encounters problem

The frequency value in square brackets [ ] indicates the value that the tool is actually using in the calculations instead of the value that has been requested.

## NOTE

You can edit or set requirements only for the clock source and the output frequencies. The other values can be adjusted only when no error is reported.

## 4.7.1 Pop-up menu commands

- **Lock/Unlock** – Removes a lock on the frequency which enables the tool to change any valid value that satisfies all other requirements, limits, and constraints.
- **Find Near Valid Value** – Tries to find a valid frequency that lies near the specified value, in case the tool failed in reaching the requested frequency.



Figure 52. Pop-up menu commands

## 4.7.2 Frequency precision

For locked frequency settings (where user requests a specific value) the frequency precision value is also displayed. By default, the value is 0.1% but can be individually adjusted by clicking the value.

Name	Lock	Value	Accuracy
Core clock		21 MHz [20.97... MHz]	±5%

Figure 53. Frequency precision

## 4.8 Dependency arrows

In the **Table** view, the area between the clock sources and the clock output contains arrows directing the clock source to outputs. The arrows lead from the current clock source used for the selected output into all outputs that are using the signal from the same clock source. This identifies the dependencies and the influences when there is change in the clock source or elements on a shared clock path.

Clock Sources				
Name	A...	Value		
FAST_IRCLK		4 MHz		
SLOW_IRCLK		32.768 kHz		
IRC48M		Inactive		

Core clock	20.97... MHz
System clock	20.97... MHz
Bus clock	20.97... MHz
FlexBus clock	20.97... MHz
Flash clock	10.48... MHz

Figure 54. Dependency arrows

## 4.9 Details view

The **Details** view displays and allows you to change clock-element settings information. The information is also updated in real-time based on any changes in the **Clocks Diagram** and **Clocks Table**.

- 

Name	A...	L...	Value
Run Mode			RUN
MCG Mode			PEE (PLL Engaged External)
Core clock			120 MHz
System clock			120 MHz
Bus clock			60 MHz
FlexBus clock			40 MHz
Flash clock			24 MHz
MCGIRCLK			2 MHz
MCGFFCLK			1.56... MHz
OSCERCLK			50 MHz
ERCLK32K			Inactive
RTC_CLKOUT			Inactive
Initialize RTC_CLKOUT			yes
MCG PLL/FLL/IRC48M clock			120 MHz
LPO clock			1 kHz
IRC48MCLK			Inactive
USB FS clock			48 MHz
Initialize USB clock			yes
Trace clock input			120 MHz
Initialize Trace clock			yes
ENET IEEE 15...stamp clock			50 MHz
Initialize E... 1588 clock			yes
ENET RMII clock			50 MHz
Initialize RMII clock			yes

Figure 55. Details view

Figure 56. Details view

In the **Details** view, you can perform the following actions:

- **Display clock-element information** - Point the mouse cursor at the clock element to display general clock-element information.
- **View the clock-element in Clocks Diagram or Clocks Table** - Left-click on a clock element to highlight it in the **Clocks Diagram** or **Clocks Table** views, depending on which is currently active.

- **View detailed clock-element information** - Double-click on a clock element to display element details, as well as highlight the element in **Clocks Diagram** or **Clocks Table**, depending on which is currently active. You can also view element details by clicking the **Open in new window** button in the upper right corner of the **Details** view.
- **Modify clock-element settings** - Left-click in the **Value** column to change clock element value, such as frequency, or select an option from the dropdown menu.
- **Lock/unlock clock elements** - Right-click on a clock element to lock/unlock the element.
- **Filter for active/locked/erroneous clock elements** - Use the buttons in the upper-right corner of the **Details** view to filter for active/locked/erroneous clock elements, or to remove all current filters.

## 4.10 Clock diagram

The clock diagram shows the structure of the entire clock model, including the clock functionality handled by the tool. It visualizes the flow of the clock signal from clock sources to clock output. It's dynamically refreshed after every change and always reflects the current state of the clock model.

At the same time it allows you to edit the settings of the clock elements.

### 4.10.1 Mouse actions in diagram

- **Position the mouse cursor on the element** to see the tooltip with the information on the clock element such as status, description, output frequency, constraints, and enable/disable conditions.
- **Single-click on output frequency or scale** to change output frequency or scale.
- **Single-click on lock** to remove the lock.
- **Double-click on the element** to show its settings in the **Details** view (force to open the view if closed or not visible).
- **Single-click on the element** to show its settings in the **Details** view.
- **Single-click on a selected Clock source** to display a dropdown menu for enabling or disabling the source.
- **Single-click on a selected Clock selector** to display selector input options.






Figure 58. Clocks mouse actions in diagram

- **Right-click on the element, component, or clock output** to see a pop-up menu with the following options.
  - **Edit settings of: {element}** – Invokes the floating view with the settings for a single element.
  - **Edit all settings** – Invokes the floating view with all the settings for an element.
  - **Edit settings on the path to: {clock output}** – Invokes the floating view with the settings for all elements on the clock path leading to the selected clock output.




Figure 59. Floating view

## 4.10.2 Color and line styles

Different color and line styles indicate different information for the element and clock signal paths.

The color and line styles can indicate:

- Active clock path for selected output
- Clock signal path states - used/unused/error/unavailable
- Element states – normal/disabled/error

To inspect colors and style appearance, select **Help > Show diagram legend** from the main menu.

## 4.10.3 Clock model structure

The clock model consists of interconnected clock elements. The clock signal flows from the clock sources through various clock elements to the clock outputs. The clock element can have specific enable conditions that can stop the signal from being passed to the successor. The clock element can also have specific constraints and limits that are watched by the Clocks Tool. To inspect these details, position the cursor on the element in the clock diagram to display the tooltip.

The following are the clock model elements.

- **Clock source** – Produces a clock signal of a specified frequency. If it's an external clock source, it can have one or more related pins.



Figure 60. Clock source

- **Clocks selector (multiplexer)** – Selects one input from multiple inputs and passes the signal to the output.




Figure 61. Clocks selector

- **Prescaler** – Divides or multiplies the frequency with a selectable or fixed ratio.



Figure 62. Prescaler

- **Frequency Locked Loop (FLL)** – Multiplies an input frequency with given factor.




Figure 63. Frequency Locked Loop

- **Phase Locked Loop (PLL)** – Contains pre-divider and thus is able to divide/multiply with a given value.




Figure 64. Phase Locked Loop

- **Clock gate** – Stops the propagation of incoming signal.
- **Clock output** – Marks the clock signal output that has some name and can be further used by the peripherals or other parts of the processor. You can put a lock and/or frequency request.




Figure 65. Clock output

- **Clock component** – Group of clock elements surrounded with a border. The clock component can have one or more outputs. The clock component usually corresponds to the processor modules or peripherals. The component output may behave like clock gates, allowing or preventing the signal flow out of the component.




Figure 66. Clock component

- **Configuration element** – Additional setting of an element. Configuration elements do not have graphical representation in the diagram. They are shown in the setting table for the element or the clock path the element is on.

## 4.11 Main menu

Commands related to the Clocks Tool can be found in the **Clocks** menu and include the following commands:

- **Functional groups** – Invokes the **Functional group properties** dialog.
- **Refresh** – Refreshes each clocks configuration with explicit invocation of code generation.
- **Reset To Board Defaults** – Resets the clock model to board defaults.
- **Reset To Processor Defaults** – Resets the clock model to processor defaults.
- **Unlock All Settings** – Unlocks all locks in all settings.

## 4.12 Troubleshooting problems

It's possible that problems or conflicts occur while working with the Clocks Tool. Such problems and the overall status are indicated in red on the central status bar of the Clocks Tool. The status bar displays global information on the reported problem.

You may encounter any of the following problems:

1. **Requirement(s) not satisfiable:** Indicates that there are one or more locked frequency or frequency constraints for which the tool is not able to find a valid settings and satisfy those requirements.
2. **Invalid settings or requirements:** [*element list*] – Indicates that the value of a settings is not valid. For example: The current state of settings is beyond the acceptable range.

The following are some tips to troubleshoot encountered problems.

1. Find the elements and settings with marked errors in the diagram or tables and see the details in the tooltip.
2. Start with only one locked frequency and let the tool find and calculate other ones. After you are successful you can add more.
3. Go through the locked outputs, if there are any, and verify the requirements (possible errors in the required frequency, wrong units, and so on).
4. If you are OK to have a near around of the requested value, right-click and from the pop-up menu select **Clock output > Find near value**.
5. If you cannot reach the values you need, see the clock paths leading to the clock output you want to adjust and check the selectors if it's possible to switch to another source of clock.


6. Try to remove locks by selecting **Clocks > Unlock All Settings**. In case many changes are required, you can simply reset the model to the default values and start from the beginning. To reset, select **Clocks > Reset to processor defaults**.

You can resolve most of the reported problems using the **Problems** view. Each problem is listed as a separate row. The following options appear when you right-click on a selected row in the **Problems** view.

- **Show problem** - Shows the problem in the **Clocks Diagram** view. If one of the solutions is possible then the pop up is extended by:
  - **Remove lock** - Removes the lock from erroneous element.
  - **Find Near value** - Finds the nearest value.

## 4.13 Code generation

If the settings are correct and no error is reported, the tool's code generation engine instantly re-generates the source code. The resulting code is found in the **Code Preview** view.



```

clock_config.c clock_config.h
/******
 * This file was generated by the MCUXpresso Config Tools. Any manual edits n
 * will be overwritten if the respective MCUXpresso Config Tools is used to upd
 *****/
/*
 * How to setup clock using clock driver functions:
 *
 * 1. CLOCK_SetSimSafeDivs, to make sure core clock, bus clock, flexbus clock
 *    and flash clock are in allowed range during clock mode switch.
 *
 * 2. Call CLOCK_Osc0Init to setup OSC clock, if it is used in target mode.
 *
 * 3. Set MCG configuration, MCG includes three parts: FLL clock, PLL clock and
 *    internal reference clock(MCGIRCLK). Follow the steps to setup:
 *
 *    1). Call CLOCK_BootToXxxMode to set MCG to target mode.
 *
 *    2). If target mode is FBI/BLPI/PBI mode, the MCGIRCLK has been configure
 *       correctly. For other modes, need to call CLOCK_SetInternalRefClkConfig
 *       explicitly to setup MCGIRCLK.
 *
 *    3). Don't need to configure FLL explicitly, because if target mode is FLL
 *       mode, then FLL has been configured by the function CLOCK_BootToXxxM
 *       if the target mode is not FLL mode, the FLL is disabled.
 *
 *    4). If target mode is PEE/PBE/PEI/PBI mode, then the related PLL has been
 *       setup by CLOCK_BootToXxxMode. In FBE/FBI/FEF/FE mode, the PLL cou
 */
Code successfully generated.

```

Figure 67. Code Preview view

## 4.13.1 Working with the code

The generated code is aligned with the SDK. To use the code with the SDK project it's necessary to transfer the code into your project structure.

To transfer the code into your project:

- Copy the content using the COPY command, either by pressing the CTRL+C keys or the pop-up menu after the whole text is selected.
- Use export command.
- Click the **Export** button in **Code Preview** view.
- Click **Update Project Code** in the main toolbar (works only for toolchain project).

## 4.14 Clock Consumers view

The **Clock Consumers** view provides an overview of peripheral instances. It also provides information on clock-clock instance pairing. This view is not editable and is for information only.

---

### NOTE

Information about which peripherals are consuming which output clock is available in the clock output tooltip.

---

Overview Code Previ... Registers Details Clock Cons...			
Consumer	Clocks	Frequency	
▼ ADC0			
Bus Interface Clock	Bus_clock	60 MHz	
Alternate Clock	OSCERCLK	50 MHz	
▼ ADC1			
Bus Interface Clock	Bus_clock	60 MHz	
Alternate Clock	OSCERCLK	50 MHz	
▼ AIPS Clock 0			
System_clock	System_clock	120 MHz	
Bus_clock	Bus_clock	60 MHz	
Flash_clock	Flash_clock	24 MHz	
▼ AIPS Clock 1			
System_clock	System_clock	120 MHz	
Bus_clock	Bus_clock	60 MHz	
Flash_clock	Flash_clock	24 MHz	
▼ AXBS			
Bus Interface Clock	System_clock	120 MHz	
▼ CAN0			
Bus Interface Clock	Bus_clock	60 MHz	
Oscillator Clock	OSCERCLK	50 MHz	
▼ CAU			
Bus Interface Clock	System_clock	120 MHz	
▼ CMP0			
Bus Interface Clock	Bus_clock	60 MHz	
▼ CMP1			
Bus Interface Clock	Bus_clock	60 MHz	
▼ CMP2			
Bus Interface Clock	Bus_clock	60 MHz	

Figure 68. Clock Consumers view

# Chapter 5

## Peripherals Tool

### 5.1 Features

The Peripherals Tool features:

- Configuration of initialization for SDK drivers
- User friendly user interface allowing to inspect and modify settings
- Smart configuration component selection along the SDK drivers used in toolchain project
- Instant validation of basic constraints and problems in configuration
- Generation of initialization source code using SDK function calls
- Multiple functional-group support for initialization alternatives
- Configuration problems are shown in Problems view and marked with decorators in other views
- Integration in MCUXpresso Config Tools framework along with other tools
- Middleware configuration support (USB)

### 5.2 Basic Terms and Definitions

The following are the basic terms and definitions used in the chapter:

- Functional group - represents a group of peripherals that are initialized as a group. The tool generates a C function for each functional group that contains the initialization code for the peripheral instances in this group. Only one functional group can be selected as default initialization, the others are treated as alternatives that are not initialized by default.
- Peripheral instance – occurrence of a peripheral (device) of specific type. For example, UART peripheral has three instances on the selected processor, so there are UART0, UART1 and UART2 devices.
- Configuration component – provides user interface for configuring SDK software component (for example, peripheral driver) and generates code for its initialization.
- Component instance – configuration component can have multiple instances with different settings. (for example, for each peripheral instance like UART0, UART1).
- Component mode – specific use-case of the component instance (for example, TRANSFER mode of DSPI, or interrupt-based mode of communication).

### 5.3 Workflow

The following steps briefly describe the basic workflow in the Peripherals Tool.

1. In the **Peripherals view**, select the peripheral instance you would like to configure (use the checkbox).
2. In case more components are available for use by the peripheral, the **Select component** dialog appears. The **Select component** dialog shows the list of suitable configuration components for the selected peripheral matching the SDK driver for the selected processor.
3. Select the component you want to use and click **OK** to confirm.

- In the settings editor that automatically opens, select the **Component mode** that you would like to use and configure individual settings.

**NOTE**

The selection of the component mode may impact appearance of some settings. Therefore, the selection of the mode should be always the first step.

- Open the **Code Preview** view and see the output source code.

**NOTE**

Note: The source code preview is automatically generated after each change if no error is reported.

- In case you are using a toolchain project, you can use **Update project** command from the toolbar. If not, you can export the source code by selecting **File>Export...** from the **Main Menu**.

**NOTE**

Note: To export the source code, you can also click the **Export** button in the **Code Preview** view.

- Settings can be saved in a MEX format (used for all settings of all tools) by selecting **File>Save** from the **Main Menu**.

## 5.4 User interface overview




Figure 69. User interface

## 5.5 Common toolbar

The common toolbar provides access to commands and selections that are available in context of all MCUXpresso Config Tools. It offers the following items:



- **Update project code** – this button opens update dialog allowing to update generated peripheral initialization code directly within specified toolchain project. This command is available only when the toolchain project has been specified.
- **Functional group selection** – Functional group in the Peripherals Tool represents a group of peripherals that are initialized as a group. The tool generates a C function for each function group that contains the initialization code.
- Function group related icons
  - **Call from default initialization** – sets the current functional group to be initialized by the default initialization function.
  - **Functional group properties** – opens the **Functional group properties** dialog to modify name and other properties of the function group
- **Tool switching icons** – section containing icons of individual tools. Click these icons to switch the currently visible tool.

---

**NOTE**


---

For details on other commands, refer [Toolbar](#)

---

## 5.6 Documentation view

You can display component-specific documentation by opening the **Documentation** view.

To open the **Documentation** view, do the following:

- In the **Peripherals** view, right-click the row and choose **Documentation** from the list.
- In the **Components** view, right-click the component and choose **Documentation** from the list.
- In the **Settings Editor**, click the **Documentation** button next to component name.

## 5.7 Peripherals view

The **Peripherals** view contains a table showing a list of available peripherals on the currently selected processor that can be configured by the Peripherals Tool. In case of multicore processors, the displayed peripherals are also core-specific.

Each instance of a peripheral (for example, UART0) occupies one row. First column contains peripheral name and a checkbox indicating whether the peripheral is used by any component instance.

De-selecting a previously-selected instance disables it. You can enable it by selecting the checkbox, or by clicking the switch in the settings editor of the component instance.

Second column contains a name of component instance handling the peripheral. This name is freely customizable in the settings editor and it is used in generated code.

Double-click on the second column opens the editor for the component instance.

## 5.8 Components view

The components view shows a list of configuration components, sorted by type into **Middleware/Peripheral drivers/Other**. The view displays configuration components differently based on their status:

- **Enabled** - Highlights the configuration component in dark gray.
- **Enabled/with warning** - Highlights the configuration component in dark gray with the alert symbol.
- **Enabled/with error** - Highlights the configuration component in red with the error symbol.

- **Disabled** - Highlights the configuration component in light gray.




Figure 70. Components view

In the **Components** view, you can perform the following actions:

- **Display configuration-component information** - Point the mouse cursor at the configuration component to display general configuration-component information.
- **Open the Settings Editor of the configuration component** - Left-click the configuration component to open its **Settings Editor**.
- **View Configuration component documentation** - Right-click the configuration component and choose **Documentation** from the dropdown menu to view configuration-component documentation. If the configuration component isn't documented, the option is highlighted in gray.
- **Remove the component from configuration** - Right-click the configuration component and choose **Remove** from the dropdown menu.

#### NOTE

If the component has any global settings, a dialog appears prompting you to confirm the removal. If the component doesn't have any global settings, the component is deleted after removing the last instance.

- **Enable/disable the configuration component** - Right-click the configuration component and choose **Enable** or **Disable** to enable/disable the configuration component.
- **Move the configuration component to another functional group** - Right-click the configuration component and choose **Move to** to select from a list of functional groups to move the configuration component to.
- **Copy the configuration component to another functional group** - Right-click the configuration component and choose **Copy to** to select from a list of functional groups to copy the configuration component to.
- **Add new configuration components** - Left-click the **+** button and choose from the list to add a new component. You can filter the list to show only toolchain-project-relevant, or latest version components. You can also click the **+** buttons next to **Middleware/Peripheral drivers/Other** categories to add new components in them directly.
- **Filter configuration components by name** - Type a text string to filter configuration component names in the search bar.

## 5.9 Settings Editor

You can edit peripheral component settings in the **Settings Editor**. Open editors are shown in the central area of the screen, each with its own tab. Multiple editors can be opened at the same time. Changes done in the editor are immediately applied and

kept even if the settings editor is closed. Settings that are disabled are highlighted in gray. In case that a component instance is disabled, all settings are highlighted in gray. Tooltips are displayed for all enabled settings when the mouse cursor is placed at settings.

To open **Settings Editor**, do the following:

- Double-click the component instance in the **Peripherals** or **Components** view to display component instance settings.
- Double-click the component in the **Components** view to display global settings of the component.

## 5.9.1 Quick selections

Settings are grouped to larger groups (config sets) that may provide presets with typical values. The user can use these presets to quickly set the desired typical combination of settings or return to the default state.

Figure 71. Quick selection example

## 5.9.2 Settings

The following settings occur in the editor.

- **Boolean** – Two state setting (yes/no, true/false).

Figure 72. Boolean setting example

- **Integer, Float** – Integer or float number.

Figure 73. Integer/Float setting example

- **String** – Textual input.

Figure 74. String setting example

- **Enumeration** – Selection of one item from list of values.

Figure 75. Enumeration setting example

- **Set** – List of values, multiple of them can be selected.

Figure 76. Set setting example

- **Structure** – Group of multiple settings of different types, may contain settings of any type including nested structures.

Figure 77. Structure setting example

- **Array** – Array of multiple settings of same type – user can add/remove items. The array of simple structures may also be represented as a table grid.

The '+' button adds a new item at the end of array. To rearrange the position or delete an item, click on the menu icon and select one of the following options: Move up, Move down, Move to top, Move to bottom, or Remove.

Figure 78. Array setting example

- **Info** – Read-only information for the user.

Resulting input clock frequency 1 kHz

Figure 79. Array setting example

### 5.9.3 Settings Editor header

All components share the **Settings Editor** header. In the header, you can view and change component information, enable or disable the component, and view component documentation (where applicable).




Figure 80. Settings Editor header

**Settings Editor** header contains the following:

- **Title** - Displays the configuration component title.
- **Name** - Displays the component instance name. This name is used in the generated code in constants and function identifiers. You can change it at any time.
- **Mode** - Displays the required usage for the component instance and influences available settings. Use the dropdown menu to change the mode (where applicable).
- **Peripheral** - Displays the name of the peripheral to be associated with the component instance. Use the dropdown menu to change it.
- **Enable/disable component instance switch** - Use the switch to enable or disable selected component instance. Note that by disabling the instance, you don't remove it from the tools configuration, but prevent its inclusion in the generated code.
- **Documentation button** - Click the button to view configuration component-specific documentation in the **Documentation** view. Note that not all configuration components are documented, therefore not all setting headers contain the **Documentation** icon.

## 5.10 Problems

The tool validates the settings and problems and errors are reported in the [Problems](#) view.

If there is an error related to the setting or component an error decorator is shown next to the element containing an error.




Figure 81. Error decorators

## 5.11 Code generation

The code generation is performed automatically after every change in the configuration.

The Peripherals Tool produces the following C files:

- peripherals.c
- peripherals.h

---

**NOTE**

For multicore processors the peripherals.c/h are generated for each core, containing functional groups associated with that core. This can be configured in functional group properties.

---

These files contain initialization code for peripherals produced by selected configuration components including:

- Constants and functions declaration in header file.
- Initialized configuration structures variables (constants).
- Global variables for the user application that are used in the initialization. For example, handles and buffers.
- Initialization function for each configuration component.
- Initialization function for each functional group. The name of the function is the same as the functional group name. These functions include execution of all assigned components' initialization functions.
- Default initialization function containing call to the function initializing the selected functional group of peripherals.

---

**NOTE**

The prefixes of the global definitions (defines, constants, variables and functions) can be configured in the Properties of the functional group.

---


# Chapter 6

## Advanced Features

### 6.1 Switching the processor

You can switch the processor or the package of the current configuration to a different one. However, switching to a completely different processor may lead to problems, such as inaccessible pin routing or unsatisfiable clock-output frequency. In that case, it's necessary to fix the problem manually. For example, go to the Pins Routing table and re-configure all pins which report an error or conflict. Alternatively, you may need to change the required frequencies on Clock output.

Select **File > Switch processor** menu to change the processor in the selected configuration.



**Figure 82. Switch processor**

Select **File > Switch package** to change the package of the current processor.




Figure 83. Switch package

## 6.2 Exporting the Pins table

To export the Pins table, do the following:

1. Select **File > Export** from the main menu.
2. In the **Export** dialog, select the **Export the Pins in CSV (Comma Separated Values) Format** option.
3. Click **Next**.
4. Select the folder and specify the file name to which you want to export.
5. The exported file contains content of the current Pins view table, plus lists the functions and the selected routed pins.

```
sep=;
Pin;Pin name;GPIO;FTM;ADC;UART;SPI;I2S;LLWU;I2C;CMP;SUPPLY;LPUART;USB;SIM;JTAG;RTC;EWM;Other;Routing for BOARD_InitPins
A1;PTE0/CLKOUT32K;PTE0/CLKOUT32K(GPIOE,GPIO,0);;ADC1_SE4a(ADC1,SEa,4);UART1_TX(UART1,TX);SPI1_PCS1(SPI1,PCS1);;I2C1_SDA(I2C1,SDA);;PTE0
B1;PTE1/LLWU_P0;PTE1/LLWU_P0(GPIOE,GPIO,1);;ADC1_SE5a(ADC1,SEa,5);UART1_RX(UART1,RX);SPI1_SOUT(SPI1,SOUT)/SPI1_SIN(SPI1,SIN);;PTE1/LLWU_P0(
C1;PTD5;PTD5(GPIOD,GPIO,5);FTM0_CH5(FTM0,CH,5);ADC0_SE6b(ADC0,SEb,6);UART0_CTS_b(UART0,CTS);SPI0_PCS2(SPI0,PCS2)/SPI1_SCK(SPI1,SCK);;
D1;USB0_DM;USB0_DM(USB0,DM);;
E1;USB0_DP;USB0_DP(USB0,DP);;
F1;ADC0_DM0/ADC1_DM3;ADC0_DM0/ADC1_DM3(ADC0,DM,0)/ADC0_DM0/ADC1_DM3(ADC0,SE,19)/ADC0_DM0/ADC1_DM3(ADC1,DM,3);;ADC0_DM0/ADC1_
G1;ADC0_DP0/ADC1_DP3;ADC0_DP0/ADC1_DP3(ADC0,DP,0)/ADC0_DP0/ADC1_DP3(ADC0,SE,0)/ADC0_DP0/ADC1_DP3(ADC1,DP,3)/ADC0_DP0/ADC1_DP3(ADC1,SE,3);
H1;VREF_OUT/CMP1_IN5/CMP0_IN5/ADC1_SE18;VREF_OUT/CMP1_IN5/CMP0_IN5/ADC1_SE18(ADC1,SE,18);;VREF_OUT/CMP1_IN5/CMP0_IN5/ADC1_SE18(CMP1,I
A2;PTD7/UART0_TX/FTM0_CH7/FTM0_FLT1/SPI1_SIN;PTD7(GPIOD,GPIO,7);FTM0_CH7(FTM0,CH,7)/FTM0_FLT1(FTM0,FLT,1);UART0_TX(UART0,TX);SPI1_SIN(SPI1
B2;ADC0_SE7b/PTD6/LLWU_P15/SPI0_PCS3/UART0_RX/FTM0_CH6/FTM0_FLT0/SPI1_SOUT;PTD6/LLWU_P15(GPIOD,GPIO,6);FTM0_CH6(FTM0,CH,6)/FTM0_FLT0(FTM0,F
C2;PTD2/LLWU_P13/SPI0_SOUT/UART2_RX/LPUART0_RX/I2C0_SCL;PTD2/LLWU_P13(GPIOD,GPIO,2);;UART2_RX(UART2,RX);SPI0_SOUT(SPI0,SOUT);PTD2/LLWU_P1
D2;VREGIN;VREGIN(USB0,VREGIN);;
E2;VOUT33;VOUT33(USB0,VOUT33);;
F2;ADC1_DM0/ADC0_DM3;ADC1_DM0/ADC0_DM3(ADC1,DM,0)/ADC1_DM0/ADC0_DM3(ADC1,SE,19)/ADC1_DM0/ADC0_DM3(ADC0,DM,3);;
G2;ADC1_DP0/ADC0_DP3;ADC1_DP0/ADC0_DP3(ADC1,DP,0)/ADC1_DP0/ADC0_DP3(ADC1,SE,0)/ADC1_DP0/ADC0_DP3(ADC0,DP,3)/ADC1_DP0/ADC0_DP3(ADC0,SE,3);
H2;DAC0_OUT/CMP1_IN3/ADC0_SE23;DAC0_OUT/CMP1_IN3/ADC0_SE23(ADC0,SE,23);;DAC0_OUT/CMP1_IN3/ADC0_SE23(CMP1,IN,3);;DAC0_OUT/CMP1_I
A3;PTD4/LLWU_P14/SPI0_PCS1/UART0_RTS_b/FTM0_CH4/ENM_IN/SPI1_PCS0;PTD4/LLWU_P14(GPIOD,GPIO,4);FTM0_CH4(FTM0,CH,4);UART0_RTS_b(UART0,RTS);SP
B3;PTD3/SPI0_SIN/UART2_TX/LPUART0_TX/I2C0_SDA;PTD3(GPIOD,GPIO,3);;UART2_TX(UART2,TX);SPI0_SIN(SPI0,SIN);;I2C0_SDA(I2C0,SDA);;LPUART0_TX(
C3;PTD0/LLWU_P12;PTD0/LLWU_P12(GPIOD,GPIO,0);;UART2_RTS_b(UART2,RTS);SPI0_PCS0(SPI0,PCS0/SS);PTD0/LLWU_P12(LLWU,WAKEUP,P12);;LPUART0_RT
D3;PTA0/UART0_CTS_b/FTM0_CH5/JTAG_TCLK/SWD_CLK/E2P_CLK;PTA0(GPIOA,GPIO,0);FTM0_CH5(FTM0,CH,5);UART0_CTS_b(UART0,CTS);;JTAG_TCLK(JT
```

Figure 84. Exported file content



The exported content can be used in other tools for further processing. For example, see it after aligning to blocks in the image below.

##pin#			
Pin :Pin name	:GPIO	:FTM	:ADC
A1 :PTD0/CLKOUT32K	:PTD0/CLKOUT32K(GPIOE,GPIO,0)		:ADC1_SE4a(ADC1,SEa,4)
B1 :PTE1/LLWU_P0	:PTE1/LLWU_P0(GPIOE,GPIO,1)		:ADC1_SE5a(ADC1,SEa,5)
C1 :PTD5	:PTD5(GPIOD,GPIO,5)	:FTM0_CH5(FTM0,CH,5)	:ADC0_SE6b(ADC0,SEb,6)
D1 :USB0_DM			
E1 :USB0_DP			
F1 :ADCO_DM0/ADC1_DM3			:ADCO_DM0/ADC1_DM3(ADCO,DM,0)/ADCO_DM0/ADC
G1 :ADCO_DFO/ADC1_DF3			:ADCO_DFO/ADC1_DF3(ADCO,DF,0)/ADCO_DFO/ADC
H1 :VREF_OUT/CMF1_IN5/CMF0_IN5/ADC1_SE18			:VREF_OUT/CMF1_IN5/CMF0_IN5/ADC1_SE18(ADC1
A2 :PTD7/UART0_TX/FTM0_CH7/FTM0_FLT1/SPI1_SIN	:PTD7(GPIOD,GPIO,7)	:FTM0_CH7(FTM0,CH,7)/FTM0_FLT1(FTM0,FLT,1)	
B2 :ADCO_SE7b/PTD6/LLWU_P15/SPI0_PCS3/UART0_RX/FTM0_CH6/FTM0_FLT0/SPI1_SOUT	:PTD6/LLWU_P15(GPIOD,GPIO,6)	:FTM0_CH6(FTM0,CH,6)/FTM0_FLT0(FTM0,FLT,0)/FTM0_FLT0(FTM0,TRG,2)	:ADC0_SE7b(ADC0,SEb,7)
C2 :PTD2/LLWU_P13/SPI0_SOUT/UART2_RX/LPUART0_RX/I2C0_SCL	:PTD2/LLWU_P13(GPIOD,GPIO,2)		
D2 :VREGIN			
E2 :VOUT33			
F2 :ADC1_DM0/ADCO_DM3			:ADC1_DM0/ADCO_DM3(ADC1,DM,0)/ADC1_DM0/ADC
G2 :ADC1_DFO/ADCO_DF3			:ADC1_DFO/ADCO_DF3(ADC1,DF,0)/ADC1_DFO/ADC
H2 :DAC0_OUT/CMF1_IN3/ADCO_SE23			:DAC0_OUT/CMF1_IN3/ADCO_SE23(ADCO,SE,23)
A3 :PTD4/LLWU_P14/SPI0_PCS1/UART0_RTS_b/FTM0_CH4/ENM_IN/SPI1_FCS0	:PTD4/LLWU_P14(GPIOD,GPIO,4)	:FTM0_CH4(FTM0,CH,4)	
B3 :PTD3/SPI0_SIN/UART2_TX/LPUART0_TX/I2C0_SDA	:PTD3(GPIOD,GPIO,3)		
C3 :PTD0/LLWU_P12	:PTD0/LLWU_P12(GPIOD,GPIO,0)		
D3 :PTA0/UART0_CTS_b/FTM0_CH5/JTAG_TCLK/SWD_CLK/EZP_CLK	:PTA0(GPIOA,GPIO,0)	:FTM0_CH5(FTM0,CH,5)	
E3 :VSS80			
F3 :VSSA			:VSSA(ADCO,SE,30)/VSSA(ADC1,SE,30)/VSSA(AI
G3 :VREFL			:VREFL(ADCO,SE,30)/VREFL(ADC1,SE,30)/VREFL
H3 :XTAL32			
A4 :ADCO_SE5b/PTD1/SPI0_SCK/UART2_CTS_b/LPUART0_CTS_b	:PTD1(GPIOD,GPIO,1)		:ADCO_SE5b(ADCO,SEb,5)
B4 :ADC1_SE6b/PTC10/I2C1_SCL/I2S0_RX_FS	:PTC10(GPIOC,GPIO,10)		:ADC1_SE6b(ADC1,SEb,6)
C4 :VSS9			
D4 :PTA1/UART0_RX/FTM0_CH6/JTAG_TDI/EZP_DI	:PTA1(GPIOA,GPIO,1)	:FTM0_CH6(FTM0,CH,6)	
E4 :VDD81			
F4 :VDDA			:VDDA(ADCO,SE,29)/VDDA(ADC1,SE,29)/VDDA(AI
G4 :VREFH			:VREFH(ADCO,SE,29)/VREFH(ADC1,SE,29)/VREFH

Figure 85. Aligning to block

## 6.3 Tools advanced configuration

Use the `ide\mcuxpressoide.ini` file to configure the processor data directory location. You can define the "com.nxp.mcudata.dir" property to set the data directory location.

For example: `-Dcom.nxp.mcudata.dir=C:/my/data/directory.`

## 6.4 Generating HTML report

Select **Export > Pins/Clocks/Peripherals Tool > Export HTML Report** to generate the report.

## 6.5 Exporting sources

It's possible to export the generated source using the Export wizard.

To launch the Export wizard:

1. Select **File > Export** from the **Main Menu**.
2. Select **Export Source Files**.




Figure 86. Export wizard

3. Click **Next**.
4. Select the target folder where you want to store the generated files.



Figure 87. Select target folder

5. In case of multicore processors, select the cores you want to export.
6. Click **Finish**.

## 6.6 Exporting registers

You can export the content of tool-modified registers data using the Export wizard.

To export registers, follow these steps:

1. Select **File > Export** from the main menu.
2. Select the **Pins Tool > Export Registers** option.
3. Click **Next**.
4. Select the target file path where you want to export modified registers content.

5. Click **Finish**.

## 6.7 Command line execution

This section describes the Command Line Interface (CLI) commands supported by the desktop application.

MCUXpresso Config tools can be executed on command line with these parameters: `mcuxpressoide.exe -noSplash -application com.nxp.swtools.framework.application [tools commands]`.

Notes regarding command line execution:

- Command **-HeadlessTool** is used as a separator of each command chain.
- Each command chain works independently.
- Every chain starts with **-HeadlessTool** command and continues to the next **-HeadlessTool** command, or end. (only exception are commands from framework which doesn't need the **-HeadlessTool** command).
- Commands which don't need the **-HeadlessTool** command, can be placed before the first **-HeadlessTool** if chained, or without **-HeadlessTool** when not chained.
- Commands from each tool are executed in given order.
- Commands from framework **are not executed in given order**.
- The following commands are not executed in given order:
  - ImportProject
  - Export MEX
  - ExportAll
- The application can exit with following codes when unexpected behavior occurs: hen parameter is missing:
  - When parameter is missing: 1
  - When tool error occurs: 2

Command example:

```
-HeadlessTool Clocks -MCU MKL43Z256xxx4 -SDKVersion ksdk2_0 -ExportSrc C:/exports/src -HeadlessTool Pins -MCU MK65FN2M0xxx18 -SDKVersion ksdk2_0 -ExportSrc C:/exports/src -HeadlessTool Peripherals -MCU MK64FX512xxx12 -SDKVersion ksdk2_0 -ExportSrc C:/exports/src
```

The following commands are supported in the **framework**:

**Table 6. Commands supported in the framework**

Command name	Definition and parameters	Description	Restriction	Example
Force language	-nl {lang}	Force set language {lang} is in <a href="#">ISO-639-1</a> standard	Removal of the '.nxp' folder from home directory is recommended, as some text might be cached  Only 'zh' and 'en' are supported	-nl zh

*Table continues on the next page...*

**Table 6. Commands supported in the framework (continued)**

Show console	-consoleLog	Log output is also sent to Java's System.out (typically back to the command shell if any)	None	
Select MCU	-MCU	MCU to be selected by framework	Requires -SDKversion command	-MCU MK64FX512xxx12
Select SDK version	-SDKversion	Version of the MCU to be selected by framework	Requires -MCU command	-SDKversion test_ksdk2_0
Select part number	-PartNum	Select specific package of the MCU	Requires -MCU and -SDKversion commands	-PartNum MK64FX512VLL12
Configuration name	-ConfigName	Name of newly created configuration - used in export	Name is used when new configuration is created by -MCU and -SDKversion commands	-ConfigName "MyConfig"
Select tool	-HeadlessTool	Select a tool that should be run in headless mode	None	-HeadlessTool Clocks
Load configuration	-Load	Load existing configuration from (*.mex) file	None	-Load C:/conf/conf.mex
Export Mex	-ExportMEX	Export .mex configuration file after tools run  Argument is expected as a folder name	None	-MCU xxx -SDKversion xxx -ExportMEX C:/exports/my_config_folder
Export all generated files	-ExportAll	Export generated files (with source code and so on. Code is regenerated before export  Includes -ExportSrc and in framework -ExportMEX Argument is expected as a folder name.  Argument is expected as a folder name	Requires -HeadlessTool command	-HeadlessTool Pins -ExportAll C:/exports/generated
Create new configuration by importing toolchain project	-ImportProject {path}	Creates new configuration by importing toolchain project  Parameter is path to the root of the toolchain project	Requires -HeadlessTool command	-HeadlessTool Pins -ImportProject c:\test\myproject
Specify SDK path	-SDKpath {path}	Specify absolute path to the root directory of the SDK package.	@since v3.0	-SDKpath c:\nxp\SDK_2.0_MKL43Z256xxx4

## 6.7.1 Command line execution - Pins Tool

This section describes the Command Line Interface (CLI) commands supported in the **Pins Tool**.

**Table 7. Commands supported in Pins**

Command name	Definition and parameters	Description	Restriction	Example
Import C files	-ImportC	Import .c files into configuration  Importing is done after loading mex and before generating outputs	Requires -HeadlessTool Pins	-HeadlessTool Pins - ImportC C:/imports/file1.c C:/imports/file2.c
Import DTSI files	-ImportDTSI	Import .dtsi files into configuration  Importing is done after loading mex and before generating outputs	Requires -HeadlessTool Pins	-HeadlessTool Pins - ImportDTSI C:/imports/file1.dtsi C:/imports/file2.dtsi
Export all generated files  (to simplify all exports commands to one command)	-ExportAll	Export generated files (with source code etc.)  Code will be regenerated before export  Includes -ExportSrc, -ExportCSV, -ExportHTML and in framework - ExportMEX  Argument is expected as a folder name	Requires -HeadlessTool Pins	-HeadlessTool Pins - ExportAll C:/exports/generated
Export Source files	-ExportSrc	Export generated source files.  Code will be regenerated before export  Argument is expected as a folder name	Requires -HeadlessTool Pins	-HeadlessTool Pins - ExportSrc C:/exports/src
Export CSV file	-ExportCSV	Export generated csv file.  Code will be regenerated before export  Argument is expected as a folder name	Requires -HeadlessTool Pins	-HeadlessTool Pins - ExportSrc C:/exports/src

*Table continues on the next page...*

**Table 7. Commands supported in Pins (continued)**

Export HTML report file	-ExportHTML	Export generated html report file.  Code will be regenerated before export  Argument is expected as a folder name	Requires -HeadlessTool Pins	-HeadlessTool Pins - ExportHTML C:/exports/html
Export registers	- ExportRegisters	Export registers tab into folder.  Code will be regenerated before export  Argument is expected as a folder name	Requires -HeadlessTool Pins	-HeadlessTool Pins - ExportRegisters C:/exports/regs

## 6.7.2 Command line execution - Clocks Tool

This section describes the Command Line Interface (CLI) commands supported by the **Clocks Tool**.

**Table 8. Commands supported in Clocks**

Command name	Definition and parameters	Description	Restriction	Example
Import C files	-ImportC	Import .c files into configuration  Importing is done after loading mex and before generating outputs	Requires -HeadlessTool Clocks	-ImportC C:/imports/file1.c C:/imports/file2.c
Export all generated files	-ExportAll	Export generated files (with source code and so on. Code is regenerated before export  Includes -ExportSrc and in framework - ExportMEXArgument is expected as a folder name.  Argument is expected as a folder name	Requires -HeadlessTool Clocks	-ExportAll C:/exports/generated

*Table continues on the next page...*

**Table 8. Commands supported in Clocks (continued)**

Export Source files	-ExportSrc	Export generated source files.  Code will be regenerated before export  Argument is expected as a folder name	Requires -HeadlessTool Clocks	-ExportSrc C:/exports/src
Export HTML report file	-ExportHTML	Export generated html report file.  Code will be regenerated before export  Argument is expected as a folder name	Requires -HeadlessTool Clocks	-ExportHTML C:/exports/html

## 6.7.3 Command line execution - Peripherals Tool

This section describes the Command Line Interface (CLI) commands supported by the **Peripherals Tool**.

**Table 9. Commands supported in Peripherals Tool**

Command name	Definition and parameters	Description	Restriction	Example
Export all generated files  (to simplify all exports commands to one command)	-ExportAll	Export generated files (with source code etc.)  Code will be regenerated before export  Includes -ExportSrc, -ExportHTML and in framework -ExportMEX  Argument is expected to be a folder	Requires -HeadlessTool Peripherals	-HeadlessTool Peripherals -ExportAll C:/exports/generated
Export Source files	-ExportSrc	Export generated source files.  Code will be regenerated before export  Argument is expected to be a folder	Requires -HeadlessTool Peripherals	-HeadlessTool Peripherals -ExportSrc C:/exports/src
* for internal commands, internal plugin must be installed into production application				

## 6.7.4 Command line execution - Project Cloner

This section describes the Command Line Interface (CLI) commands supported by the **Project Cloner**.

**Table 10. Commands supported in Project Cloner**

Command name	Definition and parameters	Description	Restriction	Example
Specify SDK path	-SDKpath {path}	Specify absolute path to the root directory of the SDK package	@since v3.0	-SDKpath c:\nxp\SDK_2.0_MKL43Z256xxx4
Clone SDK example project	-PG_clone {board} {example} {toolchain} {wrkspc} {prjName}	<p>Clones specified SDK example project under new name</p> <ol style="list-style-type: none"> <li>1. {board} - subdirectory of the board in SDK package</li> <li>2. {example} - relative path from board sub-dir and name of the example, for example demo_apps/hello_world; use '/' as a path separator</li> <li>3. {toolchain} - id of the toolchain to create project (see toolchains - toolchain - id)</li> <li>4. {wrkspc} - absolute path where new project shall be created, e.g. projects workspace</li> <li>5. {prjName} - name of the new project</li> </ol>	<p>Requires -HeadlessTool PrjCloner and -SDKpath {path}</p> <p>@since v3.0</p>	-HeadlessTool PrjCloner -SDKpath c:\nxp\SDK_2.0_MKL43Z256xxx4 -PG_clone twrk64f120m demo_apps/hello kds c:\tmp exmpl

## 6.8 Working offline

To work offline, you need to first download the processor-specific data. Once the configuration is created for the processor, the internet connection is not needed anymore.



# Chapter 7

## Support

If you have any questions or need additional help, perform a search on the forum or post a new question. Visit <https://community.nxp.com/community/mcuxpresso/mcuxpresso-config> .

#### **How To Reach Us :**

##### **Home Page:**

[nxp.com](http://nxp.com)

##### **Web Support:**

[nxp.com/support](http://nxp.com/support)

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: [nxp.com/SalesTermsandConditions](http://nxp.com/SalesTermsandConditions).

While NXP has implemented advanced security features, all products may be subject to unidentified vulnerabilities. Customers are responsible for the design and operation of their applications and products to reduce the effect of these vulnerabilities on customer's applications and products, and NXP accepts no liability for any vulnerability that is discovered. Customers should implement appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, I2C BUS, ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, Altivec, C-5, CodeTEST, CodeWarrior, ColdFire, ColdFire+, C-Ware, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorIQ, QorIQ Qonverge, Ready Play, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, SMARTMOS, Tower, TurboLink, and UMEMS are trademarks of NXP B.V. All other product or service names are the property of their respective owners. AMBA, Arm, Arm7, Arm7TDMI, Arm9, Arm11, Artisan, big.LITTLE, Cordio, CoreLink, CoreSight, Cortex, DesignStart, DynamIQ, Jazelle, Keil, Mali, Mbed, Mbed Enabled, NEON, POP, RealView, SecurCore, Socrates, Thumb, TrustZone, ULINK, ULINK2, ULINK-ME, ULINK-PLUS, ULINKpro,  $\mu$ Vision, Versatile are trademarks or registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. The related technology may be protected by any or all of patents, copyrights, designs and trade secrets. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© 2016-2018 NXP B.V.

© NXP B.V. 2018.

All rights reserved.

For more information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: [salesaddresses@nxp.com](mailto:salesaddresses@nxp.com)

Date of release: 28 October 2018

Document identifier: MCUXIDECTUG