

TROUBLESHOOTING

Solución de problemas

ENGLISH

Find answers to common questions and troubleshooting here. For additional support, call **1-800-123-LOWE**.

When should I use stabilizer spreader pads?

It is recommended that spreader pads are always used with this equipment, unless a jobsite risk assessment advises otherwise.

When should the Daily Checks be completed?

The daily checks should be completed at the start of each working shift.

How many people can travel in this lift?

The platform is rated to carry a maximum capacity of 475 lbs, which is a maximum of two people plus tools or materials.

ESPAÑOL

Encuentre respuestas a preguntas comunes y solución de problemas aquí. Para soporte adicional, llame al **1-800-123-LOWE**.

¿Cuándo debo usar las almohadillas esparcidoras estabilizadoras?

Se recomienda que siempre se utilicen placas esparcidoras con este equipo, a menos que una evaluación de riesgos en el lugar de trabajo indique lo contrario.

¿Cuándo se deben completar las verificaciones diarias?

Los controles diarios deben completarse al inicio de cada turno de trabajo.