



Above: the other half of the synthesiser PCB Connections is made to the pins in the upper left-hand corner by the keyboard wiring Chiri connector.

ALL UNMARKED DIODES
1N4148