

3D LIDAR INTEGRATION TECHNICAL GUIDE

3D LIDAR INTEGRATION TECHNICAL GUIDE

NaviFloor Robotics, Inc.

Document Version: 2.4

Last Updated: January 11, 2024

Classification: CONFIDENTIAL - Internal Use Only

1. INTRODUCTION AND SCOPE

-

1. This Technical Guide ("Guide") governs the integration requirements and

- - 1 -

2. This document is protected under U.S. and international intellectual property laws.

2. DEFINITIONS

-

1. "LIDAR System" refers to NaviFloor's MS-350X terrain mapping system.

-

2. "Integration Protocol" means the prescribed sequence of hardware installation and software configuration.

-

3. "Calibration Parameters" refers to the specific operational settings and tolerance levels for the LIDAR system.

3. TECHNICAL SPECIFICATIONS

- - 2 -

1. Hardware Requirements

-

Processing Unit: NaviCore X12 or later

-

Minimum RAM: 32GB ECC DDR4

-

Storage: 512GB NVMe SSD

-

Power Supply: 48V DC, 15A continuous

-

2. LIDAR Sensor Specifications

-

Range: 0.1m to 350m

- - 3 -

Accuracy: $\pm 2\text{cm}$ at 100m

-

Field of View: 360° horizontal, 40° vertical

-

Scan Rate: 20Hz nominal

-

Point Cloud Density: 2.0M points/second

4. INTEGRATION PROCEDURES

-

1. Physical Installation

-

Mount LIDAR unit at specified height of 1.2m $\pm 0.05\text{m}$

- - 4 -

Maintain 15° forward tilt angle

-

Secure using M8 bolts torqued to 25Nm

-

Install vibration dampeners per Drawing LID-001-V2

-

2. Software Configuration

-

Install NaviFloor LIDAR Driver Package v4.2.1

-

Configure IP addressing per Section 4.2.1

-

Initialize sensor fusion parameters

- - 5 -

Validate point cloud registration

5. CALIBRATION PROTOCOL

-

1. Initial Calibration

-

Execute geometric calibration routine

-

Perform temporal synchronization

-

Validate sensor alignment

-

Document baseline measurements

- - 6 -

2. Operational Calibration

-

Conduct daily zero-point calibration

-

Weekly full-range verification

-

Monthly accuracy assessment

-

Quarterly complete recalibration

6. SAFETY AND COMPLIANCE

-

1. Safety Requirements

- - 7 -

Class 1 laser safety compliance

-

Emergency shutdown capability

-

Redundant power monitoring

-

Fault detection systems

-

2. Regulatory Compliance

-

IEC 60825-1:2014 laser safety

-

ISO 10218-1:2011 robot safety

- - 8 -

CE marking requirements

-

FCC Part 15 emissions

7. MAINTENANCE AND SUPPORT

-

1. Preventive Maintenance

-

Clean optical surfaces weekly

-

Inspect mounting hardware monthly

-

Verify calibration quarterly

- - 9 -

Update firmware as released

-

2. Troubleshooting

-

Follow diagnostic flowchart TD-350-1

-

Log all error codes

-

Document corrective actions

-

Maintain service records

8. PROPRIETARY RIGHTS AND CONFIDENTIALITY

- - 10 -

1. All technical information contained herein is proprietary to NaviFloor Robotics, Inc.

-

2. No part of this document may be reproduced, distributed, or transmitted without written permission from NaviFloor Robotics, Inc.

9. DOCUMENT CONTROL

-

1. Revision History

-

v2.4: January 2024 - Updated calibration protocols

-

v2.3: October 2023 - Added new safety requirements

-

v2.2: July 2023 - Updated software specifications

-

v2.1: April 2023 - Initial release

-

2. Distribution Control

This document is controlled and maintained by NaviFloor Technical Documents Department.

10. CERTIFICATION

The undersigned hereby certifies that this Technical Guide has been reviewed and approved for release.

—

Dr. Elena Kovacs

Chief Research Officer

NaviFloor Robotics, Inc.

Date: January 11, 2024

^^

End of Document

