

AMR LOAD CAPACITY CALCULATION GUIDE

AMR LOAD CAPACITY CALCULATION GUIDE

Document ID: TECH-LC-2023-11

Version: 3.2

Effective Date: January 15, 2024

Classification: Confidential & Proprietary

1. PURPOSE AND SCOPE

-

1. This Load Capacity Calculation Guide ("Guide") establishes the standardi

- - 1 -

2. This Guide applies to all NaviFloor Series 2000 and 3000 AMR models of

2. DEFINITIONS

-

1. "Base Load Capacity" means the maximum theoretical load that an AMR

-

2. "Dynamic Load Factor" means the adjustment coefficient accounting for r

-

3. "Environmental Coefficient" means the adjustment factor for operational s

-

4. "Safety Margin" means the mandatory reduction percentage applied to the

3. BASE LOAD CAPACITY DETERMINATION

-

1. The Base Load Capacity (BLC) shall be calculated using the following formula

$$\text{BLC} = (\text{MP} \times \text{SF}) - \text{RW}$$

Where:

MP = Maximum Platform Rating

SF = Structural Factor (0.85)

RW = Robot Weight

-

2. The Base Load Capacity must be verified through static load testing conducted

4. DYNAMIC LOAD ADJUSTMENTS

-

1. The Dynamic Load Factor (DLF) shall be applied based on operational pa

a) Standard Movement (0-1.2 m/s): $DLF = 1.0$

b) Enhanced Speed (1.3-2.0 m/s): $DLF = 0.85$

c) Rapid Transit (2.1-3.0 m/s): $DLF = 0.70$

-

2. For operations involving inclines:

-

0-2° incline: No adjustment

-

2-5° incline: Reduce DLF by 0.15

- - 4 -

>5° incline: Prohibited unless specifically authorized

5. ENVIRONMENTAL CONSIDERATIONS

-

1. The Environmental Coefficient (EC) shall be applied based on surface con

Surface Type Coefficient

----- -----

Smooth Concrete 1.0

Epoxy Coating 0.95

Metal Grating 0.90

Textured Surface 0.85

- - 5 -

2. Additional environmental factors requiring adjustment:

-

Wet conditions: Reduce EC by 0.2

-

Uneven surfaces: Reduce EC by 0.15

-

Temperature extremes: Consult Technical Bulletin TB-2023-09

6. FINAL LOAD CAPACITY CALCULATION

-

1. The Final Load Capacity (FLC) shall be calculated as:

$$\text{FLC} = \text{BLC} \times \text{DLF} \times \text{EC} \times 0.9$$

^^^ - 6 -

Where 0.9 represents the mandatory Safety Margin.

-

2. The calculated FLC must be rounded down to the nearest 50kg increment.

7. IMPLEMENTATION REQUIREMENTS

-

1. Load capacity calculations must be:

-

Performed by qualified personnel

-

Documented in the Fleet Management System

-

Reviewed quarterly or upon environmental changes

-

Validated by a NaviFloor certified technician

-

2. Documentation Requirements:

-

Calculation worksheets

-

Environmental assessment records

-

Validation certificates

-

Quarterly review logs

8. SAFETY PROTOCOLS

-

1. Emergency Override Procedures:

-

Load capacity limits are hard-coded

-

Override requires Level 2 authorization

-

All overrides must be logged and reported

-

2. The AMR shall automatically prevent:

-

Loading beyond calculated capacity

- - 9 -

Operation outside approved parameters

-

Movement when improperly loaded

9. DISCLAIMER AND LIABILITY

-

1. This Guide contains proprietary information of NaviFloor Robotics, Inc. a

-

2. NaviFloor Robotics, Inc. assumes no liability for damages resulting from:

-

Incorrect capacity calculations

-

Unauthorized modifications

-

Operation outside specified parameters

-

Failure to follow safety protocols

10. DOCUMENT CONTROL

-

1. This Guide shall be reviewed annually and updated as required.

-

2. Change History:

-

v3.2: Updated dynamic load factors (2024-01-15)

- - 11 -

v3.1: Added environmental coefficients (2023-09-20)

-

v3.0: Major revision incorporating Series 3000 AMRs (2023-06-01)

11. CERTIFICATION

The undersigned hereby certifies that this Guide has been reviewed and approved for implementation.

—

Dr. Elena Kovacs

Chief Research Officer

NaviFloor Robotics, Inc.

Date: January 15, 2024
