

Maintenance and care

6

6-1. Maintenance and care

Cleaning and protecting
the vehicle exterior..... 440

Cleaning and protecting
the vehicle interior..... 444

6-2. Maintenance

Maintenance
requirements..... 447

General maintenance..... 450

Emission inspection and
maintenance (I/M)
programs..... 454

6-3. Do-it-yourself maintenance

Do-it-yourself service
precautions 455

Hood 457

Positioning a floor jack 459

Engine compartment..... 460

Tires 473

Tire inflation pressure 487

Wheels 490

Air conditioning filter..... 492

Wireless remote control/
electronic key battery 494

Checking and replacing
fuses 499

Light bulbs..... 502