







## If a warning light turns on or a warning buzzer sounds

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by your Toyota dealer.

### Warning light and warning buzzer list

Warning light	Warning light/Details/Actions
 (U.S.A.)  (Red) (Canada)	<b>Brake system warning light</b> Indicates that: <ul style="list-style-type: none"> <li>• The brake fluid level is low; or</li> <li>• The brake system is malfunctioning</li> </ul> → <b>Immediately stop the vehicle in a safe place and contact your Toyota dealer. Continuing to drive the vehicle may be dangerous.</b>
 (If equipped) (Yellow)	<b>Brake system warning light</b> Indicates a malfunction in the electric parking brake → <b>Have the vehicle inspected by your Toyota dealer immediately.</b>
	<b>High coolant temperature warning light (warning buzzer)*1</b> Indicates that the engine coolant temperature is too high → <b>Immediately stop the vehicle in a safe place.</b> <b>Handling method (→P. 567)</b>
	<b>Charging system warning light*1</b> Indicates a malfunction in the vehicle's charging system → <b>Immediately stop the vehicle in a safe place and contact your Toyota dealer.</b>
	<b>Low engine oil pressure warning light (warning buzzer)*1</b> Indicates that the engine oil pressure is too low → <b>Immediately stop the vehicle in a safe place and contact your Toyota dealer.</b>