



Fast-forwarding and reversing files

Press and hold  or .

Repeat play

Pressing  (RPT) changes modes in the following order:

File repeat → Folder repeat* → Off.




*: Available except when RDM (random playback) is selected

Random playback

Pressing  (RDM) changes modes in the following order:

1 folder random → All folders random → Off.



Playing and pausing files

Press  (>||).

Switching the display

Press .

Each time  is pressed, the display changes in the following order:

Track no./Elapsed time → Folder name → File name → Album title (MP3 only) → Track title → Artist name.