





### Using the head-up display

Select  on the multi-information display (→P. 117) and then .

#### ◆ Enabling/disabling the head-up display

Press  to enable/disable the head-up display.

#### ◆ Changing the head-up display settings

Press and hold  to change the following settings:

##### ■ Eco Driving Indicator/Tachometer

Select to display Eco Driving Indicator/tachometer/no content.

##### ■ Display brightness/position

Select to adjust the brightness and position of the head-up display.

##### ■ Display content

Select to enable/disable the following items:

- Route guidance to destination (if equipped)
- Driving assist system status
- Compass (if equipped)

##### ■ Display angle

Select to adjust the angle of the head-up display.