







Warning light	Warning light/Details
	<b>SRS warning light</b> Indicates a malfunction in: <ul style="list-style-type: none"><li>• The SRS airbag system; or</li><li>• The front passenger occupant classification system; or</li><li>• The seat belt pretensioner system.</li></ul>
<div><div><b>ABS</b></div><div>(U.S.A.)</div><div></div><div>(Canada)</div></div>	<b>ABS warning light</b> Indicates a malfunction in: <ul style="list-style-type: none"><li>• The ABS; or</li><li>• The brake assist system.</li></ul>
<div></div> <div>(Comes on in yellow)</div>	<b>Cruise control indicator light</b> Indicates a malfunction in the cruise control system. →P. 199
<div></div> <div>(Comes on)</div>	<b>Slip indicator light</b> Indicates a malfunction in: <ul style="list-style-type: none"><li>• VSC system; or</li><li>• TRAC system.</li></ul>
	<b>Electric power steering system warning light (warning buzzer)</b> Indicates a malfunction in the EPS system.
<div><div><b>BSM</b></div><div>(Comes on)</div></div>	<b>BSM warning light (if equipped)</b> Indicates a malfunction in the Blind Spot Monitor.
<div></div> <div>(Flashes in yellow for 15 seconds.)</div>	<b>Smart key system indicator light (if equipped)</b> Indicates a malfunction in the smart key system.