

Items	Parts and tools
Engine oil level (→P. 355)	<ul style="list-style-type: none">• “Toyota Genuine Motor Oil” or equivalent• Rag or paper towel• Funnel (used only for adding engine oil)
Fuses (→P. 389)	<ul style="list-style-type: none">• Fuse with same amperage rating as original
Light bulbs (→P. 401)	<ul style="list-style-type: none">• Bulb with same number and wattage rating as original• Phillips-head screwdriver• Flathead screwdriver• Wrench
Radiator and condenser (→P. 361)	—
Tire inflation pressure (→P. 375)	<ul style="list-style-type: none">• Tire pressure gauge• Compressed air source
Washer fluid (→P. 366)	<ul style="list-style-type: none">• Water or washer fluid containing antifreeze (for winter use)• Funnel (used only for adding water or washer fluid)