






Warning light	Warning light/Details/Actions
	<p><b>RCD OFF indicator*<sup>1</sup></b>            When a buzzer sounds:            Indicates a malfunction in the RCD (Rear Camera Detection) function            → <b>Have the vehicle inspected by your Toyota dealer immediately.</b>            When a buzzer does not sound:            Indicates that the function temporarily cannot be used due to the camera being dirty, etc.            → <b>Clear the dirt, etc.</b></p>
	<p><b>Slip indicator</b>            Indicates a malfunction in:            • The VSC (Vehicle Stability Control) system;            • The TRAC (Traction Control) system; or            • The ABS            The light will flash when the VSC or the TRAC system is operating.            → <b>Have the vehicle inspected by your Toyota dealer immediately.</b></p>
	<p><b>Low fuel level warning light</b>            ► For 2WD models            Indicates that remaining fuel is approximately 2.4 gal. (9.1 L, 2.0 Imp. gal.)            ► For AWD models            Indicates that remaining fuel is approximately 2.2 gal. (8.2 L, 1.8 Imp. gal.)            → <b>Refuel the vehicle.</b></p>
	<p><b>Driver's and front passenger's seat belt reminder light (warning buzzer)*<sup>3</sup></b>            Warns the driver and/or front passenger to fasten their seat belts            → <b>Fasten the seat belt.</b>  <b>If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.</b></p>
	<p><b>Rear passengers' seat belt reminder lights (warning buzzer)*<sup>4</sup></b>            Warns the rear passengers to fasten their seat belts.            → <b>Fasten the seat belt.</b></p>