






### ■ **BSM (Blind Spot Monitor) (if equipped) (→P. 330)**


Press  to enable/disable the Blind Spot Monitor function.

| Item | Settings | Details   |
|------|----------|---|
| BSM  | On       | Select to enable/disable the Blind Spot Monitor function. |
|      | Off      |   |


Press and hold  to change the settings of the following item:

| Item  | Settings   | Details   |
|---|--|---|
| Outside rear view mirror indicator brightness                         | Bright   | Select to change the brightness of the outside rear view mirror indicators. |
|   | Dim  |   |
| Notification timing for presence of approaching vehicle (sensitivity) |  Early  | Select to change the notification timing for an approaching vehicle.        |
|   |  Middle |   |
|   |  Late   |   |
|   | Only when vehicle detected in blind spot   |   |

### ■ **RCTA (Rear Cross Traffic Alert) (if equipped) (→P. 345)**

Press  to enable/disable the Rear Cross Traffic Alert function.

| Item | Settings | Details   |
|------|----------|---|
| RCTA | On       | Select to enable/disable the Rear Cross Traffic Alert function. |
|      | Off      |   |

Press and hold  to change the settings of the following item:

| Item               | Settings   | Details   |
|--------------------|------------|---|
| RCTA buzzer volume | 1 (Low)    | Select to change the volume of the RCTA buzzer. |
|                    | 2 (Medium) |   |
|                    | 3 (Loud)   |   |