







**Stop the vehicle immediately.**

The following warning indicates the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact your Toyota dealer.

Warning light	Warning light/Details
	<b>Charging system warning light</b> Indicates a malfunction in the vehicle's charging system.
	<b>Low engine oil pressure warning light</b> Indicates that the engine oil pressure is too low.
<b>Type A</b>  <b>Type B</b> 	<b>High engine coolant temperature warning light (the rightmost segment of the engine coolant temperature display flashes)</b> Indicates that the engine is almost overheating. (→P. 459)

**Have the vehicle inspected by your Toyota dealer immediately.**

Failure to investigate the cause of the following warnings may lead to the system operating abnormally and possibly cause an accident. Have the vehicle inspected by your Toyota dealer immediately.

Warning light	Warning light/Details
 (U.S.A.)  (Canada)	<b>Malfunction indicator lamp</b> Indicates a malfunction in: <ul style="list-style-type: none"><li>• The electronic engine control system; or</li><li>• The electronic throttle control system; or</li><li>• The electronic automatic transmission control system.</li></ul>