

## Driving

# 4

### 4-1. Before driving

Driving the vehicle.....	194
Cargo and luggage .....	203
Vehicle load limits .....	206
Trailer towing.....	207
Dinghy towing .....	208

### 4-2. Driving procedures

Engine (ignition) switch (vehicles without a smart key system).....	209
Engine (ignition) switch (vehicles with a smart key system).....	211
Automatic transmission .....	217
Turn signal lever.....	223
Parking brake .....	224
Electric parking brake.....	225
Brake Hold .....	229

### 4-3. Operating the lights and wipers

Headlight switch .....	231
AHB (Automatic High Beam) .....	236
Windshield wipers and washer .....	240

### 4-4. Refueling

Opening the fuel tank cap .....	244
------------------------------------	-----

### 4-5. Using the driving support systems

Toyota Safety Sense 2.5+ .....	248
PCS (Pre-Collision System).....	254
LTA (Lane Tracing Assist) .....	270
RSA (Road Sign Assist)....	285
Dynamic radar cruise control with full-speed range.....	290
Dynamic radar cruise control .....	306
Driving assist systems .....	322
BSM (Blind Spot Monitor).....	330
Intuitive parking assist.....	336
RCTA (Rear Cross Traffic Alert) .....	345
RCD (Rear Camera Detection) .....	354
PKSB (Parking Support Brake) .....	360
Parking Support Brake function (static objects) .....	368
Parking Support Brake function (rear-crossing vehicles).....	372
Driving mode select switches .....	375

### 4-6. Driving tips

Winter driving tips .....	377
---------------------------	-----