


| Interior buzzer | Exterior buzzer | Warning light | Warning light/Details | Correction procedure |
|-----------------|-----------------|--|---|--|
| Once | — |  (Flashes in yellow for 30 seconds.) | Smart key system indicator light <ul style="list-style-type: none">• When the doors were unlocked with the mechanical key and then the “ENGINE START STOP” switch was pressed, the electronic key could not be detected in the vehicle.• The electronic key could not be detected in the vehicle even after the “ENGINE START STOP” switch was pressed two consecutive times. | Touch the electronic key to the “ENGINE START STOP” switch while depressing the brake pedal. |

■ SRS warning light

This warning light system monitors the airbag sensor assembly, front airbag sensors, side and curtain shield airbag sensors, curtain shield airbag sensors, driver's seat belt buckle switch, front passenger occupant classification system (ECU and sensors), “AIR BAG ON” indicator light, “AIR BAG OFF” indicator light, front passenger's seat belt buckle switch, seat belt pretensioner assemblies, airbags, interconnecting wiring and power sources.
(→P. 100)

■ Front passenger detection sensor, passenger seat belt reminder and warning buzzer

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash and the warning buzzer to sound even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.