

Items to initialize

The following items must be initialized for normal system operation after such cases as the battery being reconnected, or maintenance being performed on the vehicle:

Item	When to initialize	Reference
Message indicating maintenance is required (on some models)	<ul style="list-style-type: none">• After the maintenance is performed	P. 448
Tire pressure warning system	<ul style="list-style-type: none">• When the tire inflation pressure is changed such as when changing traveling speed or load weight• When the tire inflation pressure is changed such as when the tire size is changed• When rotating the tires• After performing the transmitter ID code registration procedure	P. 475