

















Warning lights

Warning lights inform the driver of malfunctions in the indicated vehicle's systems.

* ₁		Brake system warning light (→P. 528)	* ₂		Inappropriate pedal operation warning light (→P. 529)
(U.S.A.)					
* ₁		Brake system warning light (→P. 528)		Parking brake indicator (→P. 529)	
(Canada)			(U.S.A.)		
(Red)					
* ₁		Brake system warning light (→P. 528)		Parking brake indicator (→P. 529)	
(If equipped)			(Canada)		
(Yellow)					
* ₁		Malfunction indicator lamp (→P. 529)	* _{1, 3}		Brake hold operated indicator (→P. 529)
(U.S.A.)			(If equipped)		
* ₁		Malfunction indicator lamp (→P. 529)	* ₁		Electric power steering system warning light (→P. 530)
(Canada)			(Red/yellow)		
* ₁		SRS warning light (→P. 529)		LTA indicator (→P. 530)	
			(Yellow)		
* ₁		ABS warning light (→P. 529)	* ₁		PCS warning light (→P. 530)
(U.S.A.)			(Flashes or illuminates)		
* ₁		ABS warning light (→P. 529)	* _{1, 3}		PKSB OFF indicator (→P. 530)
(Canada)			(If equipped)		

2

Instrument cluster