









■ Switching the door unlock function (vehicles with a smart key system)


It is possible to set which doors the entry function unlocks using the wireless remote control.

- 1
- Turn the engine switch off.
- 2
- When the indicator light on the key surface is not on, press and hold  ,  or  for approximately 5 seconds while pressing and holding  .

The setting changes each time an operation is performed, as shown below.  
(When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step 2.)

Multi-information display	Unlocking function	Beep
<div><div>*1</div><div>*2</div><div></div></div>	<div>Holding the driver's door handle unlocks only the driver's door.</div> <div>Holding the front passenger's door handle unlocks all the doors.</div>	<div>Exterior: Beeps 3 times</div> <div>Interior: Pings once</div>
<div><div>*1</div><div>*2</div><div></div></div>	<div>Holding either front door handle unlocks all the doors.</div>	<div>Exterior: Beeps twice</div> <div>Interior: Pings once</div>

- \*1: 4.2-inch display
- \*2: 7-inch display

To prevent unintended triggering of the alarm, unlock the doors using the wireless remote control and open and close a door once after the settings have been changed. (If a door is not opened within 60 seconds after  is pressed, the doors will be locked again and the alarm will automatically be set.)

In case that the alarm is triggered, immediately stop the alarm. (→P. 83)

3

Operation of each component