


■Warning lights


**BRAKE**

Brake system warning light

or




P. 420




Charging system warning light

P. 421




Low engine oil pressure warning light

P. 421


  
CHECK

Malfunction indicator lamp

or



P. 421




SRS warning light

P. 421


**ABS**

ABS warning light

or




P. 421




Cruise control indicator light\*<sup>1</sup>

P. 421




Slip indicator light

P. 421




Tire pressure warning light

P. 423




Low windshield washer fluid warning light

P. 423




Open door warning light

P. 423




Low fuel level warning light

P. 423



Driver's/front passenger's seat belt reminder light

P. 423



Electric power steering system warning light

P. 421

**BSM**

BSM warning light

P. 421