

## Alarm

### The alarm

The alarm uses light and sound to give an alert when an intrusion is detected.

The alarm is triggered in the following situations when the alarm is set:

- ▶ Vehicles without a smart key system
  - A locked door is unlocked or opened in any way other than using the wireless remote control or key. (The doors will lock again automatically.)
  - The trunk is opened in any way other than using the wireless remote control.
  - The hood is opened.
- ▶ Vehicles with a smart key system
  - A locked door is unlocked or opened in any way other than using the entry function, wireless remote control or mechanical key. (The doors will lock again automatically.)
  - The trunk is opened in any way other than using the entry function or wireless remote control.
  - The hood is opened.

### Setting the alarm system

Close the doors, trunk and hood, and lock all the doors. The system will be set automatically after 30 seconds.

The indicator light changes from being on to flashing when the system is set.

