

A photograph of a white LEGO EV3 robot with a grey top. The robot has two large black wheels on the sides and a central grey control panel. Red arrows point to specific features: the top of the robot for the USB port, a button below the screen for 'Return', a button to the right for 'Power', and the central joystick for 'Direction'.

パソコンとの接続用
USBポートはここ

「戻る」ボタン

「電源」ボタン

「方向」ボタン

EV3

