

## 3.0 Settings Menu

### 3.1 Settings Menu Order

### 3.2 Navigation of Settings

### 3.3 VIZIO Test (Hidden) Menu

	Settings Menu Requirement	Notes
1	TV settings are either adjusted from the Settings menu on the TV using the IR remote or from the SmartCast Mobile app.	TV settings is known as the sidebar.
2	When SmartCast Mobile app is used to adjust the system settings, the order is the same as the Settings menu displayed on the TV.	Differences are only as required for settings as per limitation of the app.
3	When a system setting is changed using SmartCast Mobile app, a notification displays confirming the change has been completed with exception that changes to most parental control settings do NOT display a notification on the TV.	
4	When SmartCast Mobile app is used to adjust the value of a slider, the adjustment is also annunciated on the TV with a slider (no notification in this case).	
5	When the MENU or gear key is first pressed, the header for the menu is Settings.	
6	The default selected setting is the top setting (Bluetooth Headphones) if no selection previously made. Thereafter All Settings launches with the last used setting selected.	
7	<p>TV Settings Timeout and Dismissal:</p> <ul style="list-style-type: none"> <li>For all skus, after the last key press timer starts. After 1 minute of screen quiescence the sidebar is dismissed. <ul style="list-style-type: none"> <li>During one 1 minute timer, if another key press the restart the 1 minute timer.</li> <li>Tuner Scan complete then 1 minute timer starts.</li> </ul> </li> <li>For OLED sidebar timeout is after 1 minute of quiescence to prevent screen burn.</li> <li>A key press that displays another UI takes down the sidebar including: <ul style="list-style-type: none"> <li>INPUT, PIC, MIC, WIDE, HOME, partner keys <ul style="list-style-type: none"> <li>PIC key dismisses Quick and deep links to Picture mode.</li> </ul> </li> </ul> </li> <li>A key press that does not take down sidebar (TV Settings or Quick) <ul style="list-style-type: none"> <li>no dismissal with VOLUME or MUTE keys</li> <li>INFO displays the input change control which displays concurrently with sidebar (no overlap)</li> <li>CC notifications and closed captions do not take down TV settings or Quick.</li> </ul> </li> <li>For System Info after 5 minutes timer then sidebar is dismissed.</li> <li>Sidebar timeout timer is paused if Talk Back is voicing, restarts after Talk Back is quiet.</li> </ul>	<p>1 minute timeout does not apply:</p> <ul style="list-style-type: none"> <li>During tuner scan.</li> <li>System Info (system info timeout after 5 minutes).</li> <li>Hidden menu</li> <li>non-customer facing ODM/SOC menus including factory menus</li> <li>Talk Back voicing</li> </ul>

8	If a setting, option or name exceeds the maximum of 15 characters for input name or 24 characters for TV name or does not fit then add ellipses to indicate the name is incomplete.	
9	If Loki has not received values from DTV service the first time leave setting blank (not a 0).	This applies to Quick menu an

### 3.1 Settings Menu Order

	Sub menu	Definition	Notes
1	Bluetooth Headphones	Configures the Bluetooth Headphones settings.	1. No timeout with tuner scan 2. No timeout with System Info.
2	Picture	Configures the picture settings.	
3	Audio	Configures the audio settings.	
4	Network	Configures and tests the network connection for the TV.	
5	TV Channels	Configures the tuner and parental controls.	
6	Accessibility	Configures closed captions, video description, talk back and zoom mode for all models with SmartCast TV.	
7	System	Configures menu language, time and timers, TV and input names, power mode, CEC, system PIN, mobile devices, voice remote and for applicable skus, the OLED panel.	
8	Admin & Privacy	Supports administrative tasks including reboot TV, system information, check for updates and reset to defaults. Configures viewing data, DAI settings and store demo. Displays the VIZIO privacy policy.	
9	User Manual	downloads and displays the user manual app.	

### 3.2 Navigation of Settings

	Definition	Notes
1	A highlighted setting can be changed in two ways	
2	A press of the LEFT/RIGHT keys toggles the options displayed right of the setting in the the sidebar menu.	Setting is immediately changed.
3	<p>A press of UP/DOWN navigates up and down in a menu.</p> <ul style="list-style-type: none"> <li>A press of Up at top setting wraps to bottom setting. Examples: <ul style="list-style-type: none"> <li>Bluetooth Headphones in main menu wraps to User Manual</li> <li>Picture header in Picture menu wraps to Picture Mode Edit</li> </ul> </li> <li>A press of Down at bottom setting wraps to top setting. Examples: <ul style="list-style-type: none"> <li>User Manual in main menu wraps to Bluetooth Headphones</li> </ul> </li> </ul>	
4	<p>Alternatively, a press of OK key opens the specific setting.</p> <ul style="list-style-type: none"> <li>The setting name becomes the menu header</li> </ul>	<p>For example, in Picture menu,</p> <ul style="list-style-type: none"> <li>Picture mode is highlighted</li> </ul>

	<ul style="list-style-type: none"> <li>options displayed in the menu below.</li> <li>The first option is selected &amp; highlighted.</li> <li>A press of the UP or DOWN key highlights the next option above or below.</li> <li>To change to the highlighted setting press OK key.</li> <li>The setting menu closes and the originating menu reopens with the setting and new option highlighted.</li> </ul>	<ul style="list-style-type: none"> <li>press of OK key opens the Picture Mode options menu</li> <li>current picture mode option highlighted</li> <li>A press of the DOWN key highlights the next picture mode.</li> <li>A press of OK switches to the highlighted option</li> <li>Returns to the Picture menu with Picture mode highlighted.</li> </ul>
5	<p>If a carat is displayed the corresponding arrow navigates:</p> <ul style="list-style-type: none"> <li>Left carat for header, then left arrow key takes back to All Settings main menu</li> <li>Right carat for a setting, then right arrow opens the menu for the setting</li> </ul>	<p>For example,</p> <ul style="list-style-type: none"> <li>Picture highlighted with left carat, left arrow returns to main menu with Picture highlighted.</li> <li>Advanced settings highlighted with right carat, right arrow opens Advanced Settings submenu</li> <li>Input Name highlighted with right carat, right arrow opens the Input Name with soft keyboard.</li> </ul>
6	<p>Under specific conditions, if a setting is noted as “not available”, then the setting cannot be selected or used. The setting is grayed out and not sent to the SmartCast app until the condition is relieved.</p>	<p>Gray out is not used in SmartCast mobile.</p> <p>Gray out is not used in Set and Forget settings (e.g. Digital Audio under TV Channels).</p>

### 3.3 VIZIO Test (Hidden) Menu

	Menu	Definition	Notes
1	VIZIO Test menu AKA Hidden menu	Access to functions intended for use by engineering.	<p>To access the VIZIO Test menu, press</p> <ul style="list-style-type: none"> <li>Press MENU or gear icon</li> <li>Press LEFT</li> <li>Press RIGHT</li> <li>Press PLAY or UP</li> </ul>