



## **ONTAP NAS drivers**

Astra Trident

NetApp  
February 12, 2024

# Table of Contents

- ONTAP NAS drivers ..... 1
  - ONTAP NAS driver overview ..... 1
  - Prepare to configure a backend with ONTAP NAS drivers ..... 2
  - ONTAP NAS configuration options and examples ..... 10

# ONTAP NAS drivers

## ONTAP NAS driver overview

Learn about configuring an ONTAP backend with ONTAP and Cloud Volumes ONTAP NAS drivers.

### ONTAP NAS driver details

Astra Trident provides the following NAS storage drivers to communicate with the ONTAP cluster. Supported access modes are: *ReadWriteOnce* (RWO), *ReadOnlyMany* (ROX), *ReadWriteMany* (RWX), *ReadWriteOncePod* (RWOP).



If you are using Astra Control for protection, recovery, and mobility, read [Astra Control driver compatibility](#).

Driver	Protocol	volumeMode	Access modes supported	File systems supported
ontap-nas	NFS SMB	Filesystem	RWO, ROX, RWX, RWOP	"", nfs, smb
ontap-nas-economy	NFS SMB	Filesystem	RWO, ROX, RWX, RWOP	"", nfs, smb
ontap-nas-flexgroup	NFS SMB	Filesystem	RWO, ROX, RWX, RWOP	"", nfs, smb

### Astra Control driver compatibility

Astra Control provides seamless protection, disaster recovery, and mobility (moving volumes between Kubernetes clusters) for volumes created with the `ontap-nas`, `ontap-nas-flexgroup`, and `ontap-san` drivers. See [Astra Control replication prerequisites](#) for details.



- Use `ontap-san-economy` only if persistent volume usage count is expected to be higher than [supported ONTAP volume limits](#).
- Use `ontap-nas-economy` only if persistent volume usage count is expected to be higher than [supported ONTAP volume limits](#) and the `ontap-san-economy` driver cannot be used.
- Do not use `ontap-nas-economy` if you anticipate the need for data protection, disaster recovery, or mobility.

### User permissions

Astra Trident expects to be run as either an ONTAP or SVM administrator, typically using the `admin` cluster user or a `vsadmin` SVM user, or a user with a different name that has the same role.

For Amazon FSx for NetApp ONTAP deployments, Astra Trident expects to be run as either an ONTAP or SVM

administrator, using the cluster `fsxadmin` user or a `vsadmin` SVM user, or a user with a different name that has the same role. The `fsxadmin` user is a limited replacement for the cluster admin user.



If you use the `limitAggregateUsage` parameter, cluster admin permissions are required. When using Amazon FSx for NetApp ONTAP with Astra Trident, the `limitAggregateUsage` parameter will not work with the `vsadmin` and `fsxadmin` user accounts. The configuration operation will fail if you specify this parameter.

While it is possible to create a more restrictive role within ONTAP that a Trident driver can use, we don't recommend it. Most new releases of Trident will call additional APIs that would have to be accounted for, making upgrades difficult and error-prone.

## Prepare to configure a backend with ONTAP NAS drivers

Understand the requirements, authentication options, and export policies for configuring an ONTAP backend with ONTAP NAS drivers.

### Requirements

- For all ONTAP backends, Astra Trident requires at least one aggregate assigned to the SVM.
- You can run more than one driver, and create storage classes that point to one or the other. For example, you could configure a Gold class that uses the `ontap-nas` driver and a Bronze class that uses the `ontap-nas-economy` one.
- All your Kubernetes worker nodes must have the appropriate NFS tools installed. See [here](#) for more details.
- Astra Trident supports SMB volumes mounted to pods running on Windows nodes only. Refer to [Prepare to provision SMB volumes](#) for details.

### Authenticate the ONTAP backend

Astra Trident offers two modes of authenticating an ONTAP backend.

- Credential-based: This mode requires sufficient permissions to the ONTAP backend. It is recommended to use an account associated with a pre-defined security login role, such as `admin` or `vsadmin` to ensure maximum compatibility with ONTAP versions.
- Certificate-based: This mode requires a certificate installed on the backend for Astra Trident to communicate with an ONTAP cluster. Here, the backend definition must contain Base64-encoded values of the client certificate, key, and the trusted CA certificate if used (recommended).

You can update existing backends to move between credential-based and certificate-based methods. However, only one authentication method is supported at a time. To switch to a different authentication method, you must remove the existing method from the backend configuration.



If you attempt to provide **both credentials and certificates**, backend creation will fail with an error that more than one authentication method was provided in the configuration file.

### Enable credential-based authentication

Astra Trident requires the credentials to an SVM-scoped/cluster-scoped admin to communicate with the ONTAP backend. It is recommended to make use of standard, pre-defined roles such as `admin` or `vsadmin`.

This ensures forward compatibility with future ONTAP releases that might expose feature APIs to be used by future Astra Trident releases. A custom security login role can be created and used with Astra Trident, but is not recommended.

A sample backend definition will look like this:

#### YAML

```
---
version: 1
backendName: ExampleBackend
storageDriverName: ontap-nas
managementLIF: 10.0.0.1
dataLIF: 10.0.0.2
svm: svm_nfs
username: vsadmin
password: password
```

#### JSON

```
{
  "version": 1,
  "backendName": "ExampleBackend",
  "storageDriverName": "ontap-nas",
  "managementLIF": "10.0.0.1",
  "dataLIF": "10.0.0.2",
  "svm": "svm_nfs",
  "username": "vsadmin",
  "password": "password"
}
```

Keep in mind that the backend definition is the only place the credentials are stored in plain text. After the backend is created, usernames/passwords are encoded with Base64 and stored as Kubernetes secrets. The creation/updating of a backend is the only step that requires knowledge of the credentials. As such, it is an admin-only operation, to be performed by the Kubernetes/storage administrator.

### Enable certificate-based Authentication

New and existing backends can use a certificate and communicate with the ONTAP backend. Three parameters are required in the backend definition.

- `clientCertificate`: Base64-encoded value of client certificate.
- `clientPrivateKey`: Base64-encoded value of associated private key.
- `trustedCACertificate`: Base64-encoded value of trusted CA certificate. If using a trusted CA, this parameter must be provided. This can be ignored if no trusted CA is used.

A typical workflow involves the following steps.

## Steps

1. Generate a client certificate and key. When generating, set Common Name (CN) to the ONTAP user to authenticate as.

```
openssl req -x509 -nodes -days 1095 -newkey rsa:2048 -keyout k8senv.key  
-out k8senv.pem -subj "/C=US/ST=NC/L=RTP/O=NetApp/CN=vsadmin"
```

2. Add trusted CA certificate to the ONTAP cluster. This might be already handled by the storage administrator. Ignore if no trusted CA is used.

```
security certificate install -type server -cert-name <trusted-ca-cert-  
name> -vserver <vserver-name>  
ssl modify -vserver <vserver-name> -server-enabled true -client-enabled  
true -common-name <common-name> -serial <SN-from-trusted-CA-cert> -ca  
<cert-authority>
```

3. Install the client certificate and key (from step 1) on the ONTAP cluster.

```
security certificate install -type client-ca -cert-name <certificate-  
name> -vserver <vserver-name>  
security ssl modify -vserver <vserver-name> -client-enabled true
```

4. Confirm the ONTAP security login role supports cert authentication method.

```
security login create -user-or-group-name vsadmin -application ontapi  
-authentication-method cert -vserver <vserver-name>  
security login create -user-or-group-name vsadmin -application http  
-authentication-method cert -vserver <vserver-name>
```

5. Test authentication using certificate generated. Replace <ONTAP Management LIF> and <vserver name> with Management LIF IP and SVM name. You must ensure the LIF has its service policy set to default-data-management.

```
curl -X POST -Lk https://<ONTAP-Management-  
LIF>/servlets/netapp.servlets.admin.XMLrequest_filer --key k8senv.key  
--cert ~/k8senv.pem -d '<?xml version="1.0" encoding="UTF-8"?><netapp  
xmlns="http://www.netapp.com/filer/admin" version="1.21"  
vfiler="<vserver-name>"><vserver-get></vserver-get></netapp>'
```

6. Encode certificate, key and trusted CA certificate with Base64.

```
base64 -w 0 k8senv.pem >> cert_base64
base64 -w 0 k8senv.key >> key_base64
base64 -w 0 trustedca.pem >> trustedca_base64
```

## 7. Create backend using the values obtained from the previous step.

```
cat cert-backend-updated.json
{
  "version": 1,
  "storageDriverName": "ontap-nas",
  "backendName": "NasBackend",
  "managementLIF": "1.2.3.4",
  "dataLIF": "1.2.3.8",
  "svm": "vserver_test",
  "clientCertificate": "Faaaakkkkeeee...Vaaalllluuuuueeee",
  "clientPrivateKey": "LS0tFaKE...0VaLuES0tLS0K",
  "storagePrefix": "myPrefix_"
}

#Update backend with tridentctl
tridentctl update backend NasBackend -f cert-backend-updated.json -n
trident
```

NAME	STORAGE DRIVER	UUID
NasBackend	ontap-nas	98e19b74-aec7-4a3d-8dcf-128e5033b214

## Update authentication methods or rotate credentials

You can update an existing backend to use a different authentication method or to rotate their credentials. This works both ways: backends that make use of username/password can be updated to use certificates; backends that utilize certificates can be updated to username/password based. To do this, you must remove the existing authentication method and add the new authentication method. Then use the updated backend.json file containing the required parameters to execute `tridentctl update backend`.

```
cat cert-backend-updated.json
{
  "version": 1,
  "storageDriverName": "ontap-nas",
  "backendName": "NasBackend",
  "managementLIF": "1.2.3.4",
  "dataLIF": "1.2.3.8",
  "svm": "vserver_test",
  "username": "vsadmin",
  "password": "password",
  "storagePrefix": "myPrefix_"
}

#Update backend with tridentctl
tridentctl update backend NasBackend -f cert-backend-updated.json -n
trident

+-----+-----+-----+
+-----+-----+
|      NAME      | STORAGE DRIVER |          UUID          |
STATE | VOLUMES |
+-----+-----+-----+
+-----+-----+
| NasBackend | ontap-nas      | 98e19b74-aec7-4a3d-8dcf-128e5033b214 |
online |          9 |
+-----+-----+-----+
+-----+-----+
```



When rotating passwords, the storage administrator must first update the password for the user on ONTAP. This is followed by a backend update. When rotating certificates, multiple certificates can be added to the user. The backend is then updated to use the new certificate, following which the old certificate can be deleted from the ONTAP cluster.

Updating a backend does not disrupt access to volumes that have already been created, nor impact volume connections made after. A successful backend update indicates that Astra Trident can communicate with the ONTAP backend and handle future volume operations.

## Manage NFS export policies

Astra Trident uses NFS export policies to control access to the volumes that it provisions.

Astra Trident provides two options when working with export policies:

- Astra Trident can dynamically manage the export policy itself; in this mode of operation, the storage administrator specifies a list of CIDR blocks that represent admissible IP addresses. Astra Trident adds node IPs that fall in these ranges to the export policy automatically. Alternatively, when no CIDRs are specified, any global-scoped unicast IP found on the nodes will be added to the export policy.
- Storage administrators can create an export policy and add rules manually. Astra Trident uses the default



export policy unless a different export policy name is specified in the configuration.

## Dynamically manage export policies

Astra Trident provides the ability to dynamically manage export policies for ONTAP backends. This provides the storage administrator the ability to specify a permissible address space for worker node IPs, rather than defining explicit rules manually. It greatly simplifies export policy management; modifications to the export policy no longer require manual intervention on the storage cluster. Moreover, this helps restrict access to the storage cluster only to worker nodes that have IPs in the range specified, supporting a fine-grained and automated management.



Do not use Network Address Translation (NAT) when using dynamic export policies. With NAT, the storage controller sees the frontend NAT address and not the actual IP host address, so access will be denied when no match is found in the export rules.

### Example

There are two configuration options that must be used. Here's an example backend definition:

```
---
version: 1
storageDriverName: ontap-nas
backendName: ontap_nas_auto_export
managementLIF: 192.168.0.135
svm: svm1
username: vsadmin
password: password
autoExportCIDRs:
- 192.168.0.0/24
autoExportPolicy: true
```



When using this feature, you must ensure that the root junction in your SVM has a previously created export policy with an export rule that permits the node CIDR block (such as the default export policy). Always follow NetApp recommended best practice to dedicate an SVM for Astra Trident.

Here is an explanation of how this feature works using the example above:

- `autoExportPolicy` is set to `true`. This indicates that Astra Trident will create an export policy for the `svm1` SVM and handle the addition and deletion of rules using `autoExportCIDRs` address blocks. For example, a backend with UUID `403b5326-8482-40db-96d0-d83fb3f4daec` and `autoExportPolicy` set to `true` creates an export policy named `trident-403b5326-8482-40db-96d0-d83fb3f4daec` on the SVM.
- `autoExportCIDRs` contains a list of address blocks. This field is optional and it defaults to `["0.0.0.0/0", "::/0"]`. If not defined, Astra Trident adds all globally-scoped unicast addresses found on the worker nodes.

In this example, the `192.168.0.0/24` address space is provided. This indicates that Kubernetes node IPs that fall within this address range will be added to the export policy that Astra Trident creates. When Astra Trident registers a node it runs on, it retrieves the IP addresses of the node and checks them against the

address blocks provided in `autoExportCIDRs`. After filtering the IPs, Astra Trident creates export policy rules for the client IPs it discovers, with one rule for each node it identifies.

You can update `autoExportPolicy` and `autoExportCIDRs` for backends after you create them. You can append new CIDRs for a backend that is automatically managed or delete existing CIDRs. Exercise care when deleting CIDRs to ensure that existing connections are not dropped. You can also choose to disable `autoExportPolicy` for a backend and fall back to a manually created export policy. This will require setting the `exportPolicy` parameter in your backend config.

After Astra Trident creates or updates a backend, you can check the backend using `tridentctl` or the corresponding `tridentbackend` CRD:

```
./tridentctl get backends ontap_nas_auto_export -n trident -o yaml
items:
- backendUUID: 403b5326-8482-40db-96d0-d83fb3f4daec
  config:
    aggregate: ""
    autoExportCIDRs:
    - 192.168.0.0/24
    autoExportPolicy: true
    backendName: ontap_nas_auto_export
    chapInitiatorSecret: ""
    chapTargetInitiatorSecret: ""
    chapTargetUsername: ""
    chapUsername: ""
    dataLIF: 192.168.0.135
    debug: false
    debugTraceFlags: null
    defaults:
      encryption: "false"
      exportPolicy: <automatic>
      fileType: ext4
```

As nodes are added to a Kubernetes cluster and registered with the Astra Trident controller, export policies of existing backends are updated (provided they fall in the address range specified in `autoExportCIDRs` for the backend).

When a node is removed, Astra Trident checks all backends that are online to remove the access rule for the node. By removing this node IP from the export policies of managed backends, Astra Trident prevents rogue mounts, unless this IP is reused by a new node in the cluster.

For previously existing backends, updating the backend with `tridentctl update backend` will ensure that Astra Trident manages the export policies automatically. This will create a new export policy named after the backend's UUID and volumes that are present on the backend will use the newly created export policy when they are mounted again.



Deleting a backend with auto-managed export policies will delete the dynamically created export policy. If the backend is re-created, it is treated as a new backend and will result in the creation of a new export policy.

If the IP address of a live node is updated, you must restart the Astra Trident pod on the node. Astra Trident will then update the export policy for backends it manages to reflect this IP change.

## Prepare to provision SMB volumes

With a little additional preparation, you can provision SMB volumes using `ontap-nas` drivers.



You must configure both NFS and SMB/CIFS protocols on the SVM to create an `ontap-nas-economy` SMB volume for ONTAP on-premises. Failure to configure either of these protocols will cause SMB volume creation to fail.

### Before you begin

Before you can provision SMB volumes, you must have the following.

- A Kubernetes cluster with a Linux controller node and at least one Windows worker node running Windows Server 2019. Astra Trident supports SMB volumes mounted to pods running on Windows nodes only.
- At least one Astra Trident secret containing your Active Directory credentials. To generate secret `smbcreds`:

```
kubectl create secret generic smbcreds --from-literal username=user
--from-literal password='password'
```

- A CSI proxy configured as a Windows service. To configure a `csi-proxy`, refer to [GitHub: CSI Proxy](#) or [GitHub: CSI Proxy for Windows](#) for Kubernetes nodes running on Windows.

### Steps

1. For on-premises ONTAP, you can optionally create an SMB share or Astra Trident can create one for you.



SMB shares are required for Amazon FSx for ONTAP.

You can create the SMB admin shares in one of two ways either using the [Microsoft Management Console Shared Folders snap-in](#) or using the ONTAP CLI. To create the SMB shares using the ONTAP CLI:

- a. If necessary, create the directory path structure for the share.

The `vserver cifs share create` command checks the path specified in the `-path` option during share creation. If the specified path does not exist, the command fails.

- b. Create an SMB share associated with the specified SVM:

```
vserver cifs share create -vserver vserver_name -share-name
share_name -path path [-share-properties share_properties,...]
[other_attributes] [-comment text]
```

c. Verify that the share was created:

```
vserver cifs share show -share-name share_name
```



Refer to [Create an SMB share](#) for full details.

2. When creating the backend, you must configure the following to specify SMB volumes. For all FSx for ONTAP backend configuration options, refer to [FSx for ONTAP configuration options and examples](#).

Parameter	Description	Example
smbShare	You can specify one of the following: the name of an SMB share created using the Microsoft Management Console or ONTAP CLI; a name to allow Astra Trident to create the SMB share; or you can leave the parameter blank to prevent common share access to volumes.  This parameter is optional for on-premises ONTAP.  This parameter is required for Amazon FSx for ONTAP backends and cannot be blank.	smb-share
nasType	<b>Must set to smb.</b> If null, defaults to nfs.	smb
securityStyle	Security style for new volumes.  <b>Must be set to ntfs or mixed for SMB volumes.</b>	ntfs or mixed for SMB volumes
unixPermissions	Mode for new volumes. <b>Must be left empty for SMB volumes.</b>	""

## ONTAP NAS configuration options and examples

Learn to create and use ONTAP NAS drivers with your Astra Trident installation. This section provides backend configuration examples and details for mapping backends to StorageClasses.

### Backend configuration options

See the following table for the backend configuration options:

Parameter	Description	Default
version		Always 1
storageDriverName	Name of the storage driver	"ontap-nas", "ontap-nas-economy", "ontap-nas-flexgroup", "ontap-san", "ontap-san-economy"
backendName	Custom name or the storage backend	Driver name + "_" + dataLIF

Parameter	Description	Default
managementLIF	<p>IP address of a cluster or SVM management LIF</p> <p>A fully-qualified domain name (FQDN) can be specified.</p> <p>Can be set to use IPv6 addresses if Astra Trident was installed using the IPv6 flag. IPv6 addresses must be defined in square brackets, such as [28e8:d9fb:a825:b7bf:69a8:d02f:9e7b:3555].</p> <p>For seamless MetroCluster switchover, see the <a href="#">MetroCluster example</a>.</p>	"10.0.0.1", "[2001:1234:abcd::fefe]"
dataLIF	<p>IP address of protocol LIF.</p> <p>We recommend specifying dataLIF. If not provided, Astra Trident fetches data LIFs from the SVM. You can specify a fully-qualified domain name (FQDN) to be used for the NFS mount operations, allowing you to create a round-robin DNS to load-balance across multiple data LIFs.</p> <p>Can be changed after initial setting. Refer to <a href="#">Update dataLIF after initial configuration</a>.</p> <p>Can be set to use IPv6 addresses if Astra Trident was installed using the IPv6 flag. IPv6 addresses must be defined in square brackets, such as [28e8:d9fb:a825:b7bf:69a8:d02f:9e7b:3555].</p> <p><b>Omit for Metrocluster.</b> See the <a href="#">MetroCluster example</a>.</p>	Specified address or derived from SVM, if not specified (not recommended)
svm	<p>Storage virtual machine to use</p> <p><b>Omit for Metrocluster.</b> See the <a href="#">MetroCluster example</a>.</p>	Derived if an SVM managementLIF is specified
autoExportPolicy	<p>Enable automatic export policy creation and updating [Boolean].</p> <p>Using the autoExportPolicy and autoExportCIDRs options, Astra Trident can manage export policies automatically.</p>	false
autoExportCIDRs	<p>List of CIDRs to filter Kubernetes' node IPs against when autoExportPolicy is enabled.</p> <p>Using the autoExportPolicy and autoExportCIDRs options, Astra Trident can manage export policies automatically.</p>	["0.0.0.0/0", ":::0"]

Parameter	Description	Default
labels	Set of arbitrary JSON-formatted labels to apply on volumes	""
clientCertificate	Base64-encoded value of client certificate. Used for certificate-based auth	""
clientPrivateKey	Base64-encoded value of client private key. Used for certificate-based auth	""
trustedCACertificate	Base64-encoded value of trusted CA certificate. Optional. Used for certificate-based auth	""
username	Username to connect to the cluster/SVM. Used for credential-based auth	
password	Password to connect to the cluster/SVM. Used for credential-based auth	
storagePrefix	Prefix used when provisioning new volumes in the SVM. Cannot be updated after you set it	"trident"
limitAggregateUsage	Fail provisioning if usage is above this percentage.  <b>Does not apply to Amazon FSx for ONTAP</b>	"" (not enforced by default)
limitVolumeSize	Fail provisioning if requested volume size is above this value.  Also restricts the maximum size of the volumes it manages for qtrees and LUNs, and the qtreesPerFlexvol option allows customizing the maximum number of qtrees per FlexVol.	"" (not enforced by default)
lunsPerFlexvol	Maximum LUNs per Flexvol, must be in range [50, 200]	"100"
debugTraceFlags	Debug flags to use when troubleshooting. Example, {"api":false, "method":true}  Do not use debugTraceFlags unless you are troubleshooting and require a detailed log dump.	null
nasType	Configure NFS or SMB volumes creation.  Options are nfs, smb or null. Setting to null defaults to NFS volumes.	nfs

Parameter	Description	Default
nfsMountOptions	<p>Comma-separated list of NFS mount options.</p> <p>The mount options for Kubernetes-persistent volumes are normally specified in storage classes, but if no mount options are specified in a storage class, Astra Trident will fall back to using the mount options specified in the storage backend's configuration file.</p> <p>If no mount options are specified in the storage class or the configuration file, Astra Trident will not set any mount options on an associated persistent volume.</p>	""
qtreesPerFlexvol	Maximum Qtrees per FlexVol, must be in range [50, 300]	"200"
smbShare	<p>You can specify one of the following: the name of an SMB share created using the Microsoft Management Console or ONTAP CLI; a name to allow Astra Trident to create the SMB share; or you can leave the parameter blank to prevent common share access to volumes.</p> <p>This parameter is optional for on-premises ONTAP.</p> <p>This parameter is required for Amazon FSx for ONTAP backends and cannot be blank.</p>	smb-share
useREST	<p>Boolean parameter to use ONTAP REST APIs. <b>Tech preview</b></p> <p>useREST is provided as a <b>tech preview</b> that is recommended for test environments and not for production workloads. When set to <code>true</code>, Astra Trident will use ONTAP REST APIs to communicate with the backend. This feature requires ONTAP 9.11.1 and later. In addition, the ONTAP login role used must have access to the <code>ontap</code> application. This is satisfied by the pre-defined <code>vsadmin</code> and <code>cluster-admin</code> roles.</p> <p>useREST is not supported with MetroCluster.</p>	false

## Backend configuration options for provisioning volumes

You can control default provisioning using these options in the `defaults` section of the configuration. For an example, see the configuration examples below.

Parameter	Description	Default
spaceAllocation	Space-allocation for LUNs	"true"

Parameter	Description	Default
spaceReserve	Space reservation mode; "none" (thin) or "volume" (thick)	"none"
snapshotPolicy	Snapshot policy to use	"none"
qosPolicy	QoS policy group to assign for volumes created. Choose one of qosPolicy or adaptiveQosPolicy per storage pool/backend	""
adaptiveQosPolicy	Adaptive QoS policy group to assign for volumes created. Choose one of qosPolicy or adaptiveQosPolicy per storage pool/backend.  Not supported by ontap-nas-economy.	""
snapshotReserve	Percentage of volume reserved for snapshots	"0" if snapshotPolicy is "none", otherwise ""
splitOnClone	Split a clone from its parent upon creation	"false"
encryption	Enable NetApp Volume Encryption (NVE) on the new volume; defaults to false. NVE must be licensed and enabled on the cluster to use this option.  If NAE is enabled on the backend, any volume provisioned in Astra Trident will be NAE enabled.  For more information, refer to: <a href="#">How Astra Trident works with NVE and NAE</a> .	"false"
tieringPolicy	Tiering policy to use "none"	"snapshot-only" for pre-ONTAP 9.5 SVM-DR configuration
unixPermissions	Mode for new volumes	"777" for NFS volumes; empty (not applicable) for SMB volumes
snapshotDir	Controls access to the .snapshot directory	"false"
exportPolicy	Export policy to use	"default"
securityStyle	Security style for new volumes.  NFS supports mixed and unix security styles.  SMB supports mixed and ntfs security styles.	NFS default is unix.  SMB default is ntfs.



Using QoS policy groups with Astra Trident requires ONTAP 9.8 or later. It is recommended to use a non-shared QoS policy group and ensure the policy group is applied to each constituent individually. A shared QoS policy group will enforce the ceiling for the total throughput of all workloads.

## Volume provisioning examples

Here's an example with defaults defined:



```

---
version: 1
storageDriverName: ontap-nas
backendName: customBackendName
managementLIF: 10.0.0.1
dataLIF: 10.0.0.2
labels:
  k8scluster: dev1
  backend: dev1-nasbackend
svm: trident_svm
username: cluster-admin
password: <password>
limitAggregateUsage: 80%
limitVolumeSize: 50Gi
nfsMountOptions: nfsvers=4
debugTraceFlags:
  api: false
  method: true
defaults:
  spaceReserve: volume
  qosPolicy: premium
  exportPolicy: myk8scluster
  snapshotPolicy: default
  snapshotReserve: '10'

```

For `ontap-nas` and `ontap-nas-flexgroups`, Astra Trident now uses a new calculation to ensure that the FlexVol is sized correctly with the `snapshotReserve` percentage and PVC. When the user requests a PVC, Astra Trident creates the original FlexVol with more space by using the new calculation. This calculation ensures that the user receives the writable space they requested for in the PVC, and not lesser space than what they requested. Before v21.07, when the user requests a PVC (for example, 5GiB), with the `snapshotReserve` to 50 percent, they get only 2.5GiB of writeable space. This is because what the user requested for is the whole volume and `snapshotReserve` is a percentage of that. With Trident 21.07, what the user requests for is the writeable space and Astra Trident defines the `snapshotReserve` number as the percentage of the whole volume. This does not apply to `ontap-nas-economy`. See the following example to see how this works:

The calculation is as follows:

```

Total volume size = (PVC requested size) / (1 - (snapshotReserve
percentage) / 100)

```

For `snapshotReserve` = 50%, and PVC request = 5GiB, the total volume size is  $2/.5 = 10\text{GiB}$  and the available size is 5GiB, which is what the user requested in the PVC request. The `volume show` command should show results similar to this example:

Vserver	Volume	Aggregate	State	Type	Size	Available	Used%
		_pvc_89f1c156_3801_4de4_9f9d_034d54c395f4	online	RW	10GB	5.00GB	0%
		_pvc_e8372153_9ad9_474a_951a_08ae15e1c0ba	online	RW	1GB	511.8MB	0%

2 entries were displayed.

Existing backends from previous installs will provision volumes as explained above when upgrading Astra Trident. For volumes that you created before upgrading, you should resize their volumes for the change to be observed. For example, a 2GiB PVC with `snapshotReserve=50` earlier resulted in a volume that provides 1GiB of writable space. Resizing the volume to 3GiB, for example, provides the application with 3GiB of writable space on a 6 GiB volume.

## Minimal configuration examples

The following examples show basic configurations that leave most parameters to default. This is the easiest way to define a backend.



If you are using Amazon FSx on NetApp ONTAP with Trident, the recommendation is to specify DNS names for LIFs instead of IP addresses.

### ONTAP NAS economy example

```
---
version: 1
storageDriverName: ontap-nas-economy
managementLIF: 10.0.0.1
dataLIF: 10.0.0.2
svm: svm_nfs
username: vsadmin
password: password
```

### ONTAP NAS Flexgroup example

```
---
version: 1
storageDriverName: ontap-nas-flexgroup
managementLIF: 10.0.0.1
dataLIF: 10.0.0.2
svm: svm_nfs
username: vsadmin
password: password
```

## MetroCluster example

You can configure the backend to avoid having to manually update the backend definition after switchover and switchback during [SVM replication and recovery](#).

For seamless switchover and switchback, specify the SVM using `managementLIF` and omit the `dataLIF` and `svm` parameters. For example:

```
---
version: 1
storageDriverName: ontap-nas
managementLIF: 192.168.1.66
username: vsadmin
password: password
```

## SMB volumes example

```
---
version: 1
backendName: ExampleBackend
storageDriverName: ontap-nas
managementLIF: 10.0.0.1
nasType: smb
securityStyle: ntfs
unixPermissions: ""
dataLIF: 10.0.0.2
svm: svm_nfs
username: vsadmin
password: password
```

## Certificate-based authentication example

This is a minimal backend configuration example. `clientCertificate`, `clientPrivateKey`, and `trustedCACertificate` (optional, if using trusted CA) are populated in `backend.json` and take the base64-encoded values of the client certificate, private key, and trusted CA certificate, respectively.

```
---
version: 1
backendName: DefaultNASBackend
storageDriverName: ontap-nas
managementLIF: 10.0.0.1
dataLIF: 10.0.0.15
svm: nfs_svm
clientCertificate: ZXR0ZXJwYXB...ICMgJ3BhcGVyc2
clientPrivateKey: vciwKIyAgZG...0cnksIGRlc2NyaX
trustedCACertificate: zcyBbaG...b3Igb3duIGNsYXNz
storagePrefix: myPrefix_
```

## Auto export policy example

This example shows you how you can instruct Astra Trident to use dynamic export policies to create and manage the export policy automatically. This works the same for the `ontap-nas-economy` and `ontap-nas-flexgroup` drivers.

```
---
version: 1
storageDriverName: ontap-nas
managementLIF: 10.0.0.1
dataLIF: 10.0.0.2
svm: svm_nfs
labels:
  k8scluster: test-cluster-east-1a
  backend: test1-nasbackend
autoExportPolicy: true
autoExportCIDRs:
- 10.0.0.0/24
username: admin
password: password
nfsMountOptions: nfsvers=4
```

## IPv6 addresses example

This example shows managementLIF using an IPv6 address.

```
---
version: 1
storageDriverName: ontap-nas
backendName: nas_ipv6_backend
managementLIF: "[5c5d:5edf:8f:7657:bef8:109b:1b41:d491]"
labels:
  k8scluster: test-cluster-east-1a
  backend: test1-ontap-ipv6
svm: nas_ipv6_svm
username: vsadmin
password: password
```

## Amazon FSx for ONTAP using SMB volumes example

The smbShare parameter is required for FSx for ONTAP using SMB volumes.

```
---
version: 1
backendName: SMBBackend
storageDriverName: ontap-nas
managementLIF: example.mgmt.fqdn.aws.com
nasType: smb
dataLIF: 10.0.0.15
svm: nfs_svm
smbShare: smb-share
clientCertificate: ZXR0ZXJwYXB...ICMgJ3BhcGVyc2
clientPrivateKey: vciwKIyAgZG...0cnksIGRlc2NyaX
trustedCACertificate: zcyBbaG...b3Igb3duIGNsYXNz
storagePrefix: myPrefix_
```

## Examples of backends with virtual pools

In the sample backend definition files shown below, specific defaults are set for all storage pools, such as spaceReserve at none, spaceAllocation at false, and encryption at false. The virtual pools are defined in the storage section.

Astra Trident sets provisioning labels in the "Comments" field. Comments are set on FlexVol for ontap-nas or FlexGroup for ontap-nas-flexgroup. Astra Trident copies all labels present on a virtual pool to the storage volume at provisioning. For convenience, storage administrators can define labels per virtual pool and group volumes by label.

In these examples, some of the storage pools set their own `spaceReserve`, `spaceAllocation`, and `encryption` values, and some pools override the default values.

## ONTAP NAS example

```
---
version: 1
storageDriverName: ontap-nas
managementLIF: 10.0.0.1
svm: svm_nfs
username: admin
password: <password>
nfsMountOptions: nfsvers=4
defaults:
  spaceReserve: none
  encryption: 'false'
  qosPolicy: standard
labels:
  store: nas_store
  k8scluster: prod-cluster-1
region: us_east_1
storage:
- labels:
  app: msoffice
  cost: '100'
  zone: us_east_1a
  defaults:
    spaceReserve: volume
    encryption: 'true'
    unixPermissions: '0755'
    adaptiveQosPolicy: adaptive-premium
- labels:
  app: slack
  cost: '75'
  zone: us_east_1b
  defaults:
    spaceReserve: none
    encryption: 'true'
    unixPermissions: '0755'
- labels:
  department: legal
  creditpoints: '5000'
  zone: us_east_1b
  defaults:
    spaceReserve: none
    encryption: 'true'
    unixPermissions: '0755'
- labels:
  app: wordpress
```

```
    cost: '50'
    zone: us_east_1c
    defaults:
      spaceReserve: none
      encryption: 'true'
      unixPermissions: '0775'
- labels:
  app: mysqldb
  cost: '25'
  zone: us_east_1d
  defaults:
    spaceReserve: volume
    encryption: 'false'
    unixPermissions: '0775'
```



## ONTAP NAS FlexGroup example

```
---
version: 1
storageDriverName: ontap-nas-flexgroup
managementLIF: 10.0.0.1
svm: svm_nfs
username: vsadmin
password: <password>
defaults:
  spaceReserve: none
  encryption: 'false'
labels:
  store: flexgroup_store
  k8scluster: prod-cluster-1
region: us_east_1
storage:
- labels:
  protection: gold
  creditpoints: '50000'
  zone: us_east_1a
  defaults:
    spaceReserve: volume
    encryption: 'true'
    unixPermissions: '0755'
- labels:
  protection: gold
  creditpoints: '30000'
  zone: us_east_1b
  defaults:
    spaceReserve: none
    encryption: 'true'
    unixPermissions: '0755'
- labels:
  protection: silver
  creditpoints: '20000'
  zone: us_east_1c
  defaults:
    spaceReserve: none
    encryption: 'true'
    unixPermissions: '0775'
- labels:
  protection: bronze
  creditpoints: '10000'
  zone: us_east_1d
  defaults:
```

```
spaceReserve: volume  
encryption: 'false'  
unixPermissions: '0775'
```

## ONTAP NAS economy example

```
---
version: 1
storageDriverName: ontap-nas-economy
managementLIF: 10.0.0.1
svm: svm_nfs
username: vsadmin
password: <password>
defaults:
  spaceReserve: none
  encryption: 'false'
labels:
  store: nas_economy_store
region: us_east_1
storage:
- labels:
  department: finance
  creditpoints: '6000'
  zone: us_east_1a
  defaults:
    spaceReserve: volume
    encryption: 'true'
    unixPermissions: '0755'
- labels:
  protection: bronze
  creditpoints: '5000'
  zone: us_east_1b
  defaults:
    spaceReserve: none
    encryption: 'true'
    unixPermissions: '0755'
- labels:
  department: engineering
  creditpoints: '3000'
  zone: us_east_1c
  defaults:
    spaceReserve: none
    encryption: 'true'
    unixPermissions: '0775'
- labels:
  department: humanresource
  creditpoints: '2000'
  zone: us_east_1d
  defaults:
    spaceReserve: volume
```

```
encryption: 'false'
unixPermissions: '0775'
```

## Map backends to StorageClasses

The following StorageClass definitions refer to [Examples of backends with virtual pools](#). Using the `parameters.selector` field, each StorageClass calls out which virtual pools can be used to host a volume. The volume will have the aspects defined in the chosen virtual pool.

- The `protection-gold` StorageClass will map to the first and second virtual pool in the `ontap-nas-flexgroup` backend. These are the only pools offering gold level protection.

```
apiVersion: storage.k8s.io/v1
kind: StorageClass
metadata:
  name: protection-gold
provisioner: csi.trident.netapp.io
parameters:
  selector: "protection=gold"
  fsType: "ext4"
```

- The `protection-not-gold` StorageClass will map to the third and fourth virtual pool in the `ontap-nas-flexgroup` backend. These are the only pools offering protection level other than gold.

```
apiVersion: storage.k8s.io/v1
kind: StorageClass
metadata:
  name: protection-not-gold
provisioner: csi.trident.netapp.io
parameters:
  selector: "protection!=gold"
  fsType: "ext4"
```

- The `app-mysqldb` StorageClass will map to the fourth virtual pool in the `ontap-nas` backend. This is the only pool offering storage pool configuration for `mysqldb` type app.

```

apiVersion: storage.k8s.io/v1
kind: StorageClass
metadata:
  name: app-mysqldb
provisioner: csi.trident.netapp.io
parameters:
  selector: "app=mysqldb"
  fsType: "ext4"

```

- The protection-silver-creditpoints-20k StorageClass will map to the third virtual pool in the ontap-nas-flexgroup backend. This is the only pool offering silver-level protection and 20000 creditpoints.

```

apiVersion: storage.k8s.io/v1
kind: StorageClass
metadata:
  name: protection-silver-creditpoints-20k
provisioner: csi.trident.netapp.io
parameters:
  selector: "protection=silver; creditpoints=20000"
  fsType: "ext4"

```

- The creditpoints-5k StorageClass will map to the third virtual pool in the ontap-nas backend and the second virtual pool in the ontap-nas-economy backend. These are the only pool offerings with 5000 creditpoints.

```

apiVersion: storage.k8s.io/v1
kind: StorageClass
metadata:
  name: creditpoints-5k
provisioner: csi.trident.netapp.io
parameters:
  selector: "creditpoints=5000"
  fsType: "ext4"

```

Astra Trident will decide which virtual pool is selected and will ensure the storage requirement is met.

## Update dataLIF after initial configuration

You can change the data LIF after initial configuration by running the following command to provide the new backend JSON file with updated data LIF.

```
tridentctl update backend <backend-name> -f <path-to-backend-json-file-  
with-updated-dataLIF>
```



If PVCs are attached to one or multiple pods, you must bring down all corresponding pods and then bring them back up in order for the new data LIF to take effect.

## Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.