

axis_uart_rx.v

AUTHORS

JAY CONVERTINO

DATES

2021/06/24

INFORMATION

Brief

UART RX to AXIS bus.

License MIT

Copyright 2021 Jay Convertino

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

axis_uart_rx

```
module axis_uart_rx #(
    parameter
    PARITY_ENA
    =
    0,
    parameter
    PARITY_TYPE
    =
    0,
    parameter
    STOP_BITS
```

```

    =
    1,
    parameter
    DATA_BITS
    =
    8,
    parameter
    DELAY
    =
    0
) ( input aclk, input arstn, output parity_err, output frame_err, output [DATA]

```

AXIS UART, simple UART with AXI Streaming interface.

Parameters

PARITY_ENA parameter	Enable Parity for the data in and out.
PARITY_TYPE parameter	Set the parity type, 0 = even, 1 = odd, 2 = mark, 3 = space.
STOP_BITS parameter	Number of stop bits, 0 to crazy non-standard amounts.
DATA_BITS parameter	Number of data bits, 1 to crazy non-standard amounts.
DELAY parameter	Delay in rx data input.

Ports

aclk	Clock for AXIS
arstn	Negative reset for AXIS
parity_err	Indicates error with parity check (active high)
frame_err	Indicates error with frame (active high)
m_axis_tdata	Output data from UART RX
m_axis_tvalid	When active high the output data is valid
m_axis_tready	When set active high the output device is ready for data.
uart_clk	Clock used for BAUD rate generation
uart_rstn	Negative reset for UART, for anything clocked on uart_clk
uart_ena	Enable UART data processing from RX.
uart_hold	Output to hold clock till in receive state.
rxdata	receive for UART (input from TX)