

pisov

AUTHORS

JAY CONVERTINO

DATES

2025/04/15

INFORMATION

Brief

PISO (parallel in serial out) The idea is to keep this core simple, and let the control logic be handled outside of this core.

License MIT

Copyright 2025 Jay Convertino

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

pisov

```
module piso #(
  parameter
  BUS_WIDTH
  =
  1,
  parameter
  COUNT_AMOUNT
  =
  0,
  parameter
  DEFAULT_RESET_VAL
  =
  0,
```

```

parameter
DEFAULT_SHIFT_VAL
=
0
) ( input wire clk, input wire rstn, input wire ena, input wire rev, input v

```

parallel in serial out

Parameters

BUS_WIDTH	width of the parallel data input in bytes.
COUNT_AMOUNT	If anything other than zero, the dcount and data output will use this value instead of the BUS_WIDTH size.
DEFAULT_RESET_VAL	Value that serial out will have after reset, default 0. Anything else will be 1.
DEFAULT_SHIFT_VAL	Value that will be shifted into the parallel output shift register. Default 0, anything else will be 1.

Ports

clk	global clock for the core.
rstn	negative synchronus reset to clk.
ena	enable for core, use to change output rate. Enable serial shift output.
rev	reverse, 0 is MSb first out, 1 is LSB first out.
load	load parallel data into core. Reset for next data message to send. This can be done at any time.
pdata	parallel data input, registered at load only.
sdata	serialized data output.
dcount	Number of bits to shift out. When the count hits zero, the parallel data register is empty and last bit is output on sdata.