



Equipment Type:	Microhardness Tester (Vickers and Knoop)
Model:	ALPHA MHT-1000Z
Electrical Requirements:	110/220 Volts (single-phase)
Frequency:	50/60 Hz
Manual Revision Date:	April 24, 2024

Please read this instruction manual carefully and follow all installation, operating and safety guidelines.

Please read this instruction manual carefully and follow all installation, operating and safety guidelines.

Contents

	PAGE
Warranty	ii
1.0 Product Description	1
2.0 Unpacking, Shipping and Installation	3
3.0 Safety Guidelines	14
4.0 Operation	15
5.0 Maintenance	19
6.0 Trouble Shooting	20
7.0 Spare Parts	21
8.0 Microhardness Testing Basics	27

WARRANTY

Terms and Conditions applying to all PACE Technologies Products

1. LIMITED WARRANTY AND DISCLAIMER:

PACE Technologies microscopes and hardness testers are warranted for one year from the purchase date to be free from defects in material and workmanship under correct use, normal operating conditions, and proper application. PACE Technologies obligation under this warranty shall be limited to the repair or exchange, at PACE Technologies option, of any PACE Technologies Product or part which proves to be defective as provided herein. PACE Technologies reserves the right to either inspect the product at Buyer's location or require it to be returned to the factory for inspection. Buyer is responsible for freight to and from factory on all warranty claims. The above warranty does not extend to goods damaged or subjected to accident, abuse or misuse after release from PACE Technologies warehouse, nor goods altered or repaired by anyone other than specifically authorized PACE Technologies representatives. PACE Technologies shall not in any way be responsible for the consequences of any alteration, modification or misuse unless previously approved in writing by an officer of PACE Technologies. Note: Corrosion is considered a maintenance issue and not a warranty issue.

PACE TECHNOLOGIES MAKES NO EXPRESS WARRANTIES OTHER THAN THOSE WHICH ARE SPECIFICALLY DESCRIBED HEREIN. Any description of the goods sold hereunder, including any reference to Buyer's specifications and any description in catalogs, circulars and other written material published by PACE Technologies, is the sole purpose of identifying such goods and shall not create an express warranty that the goods shall conform to such description.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED. THERE ARE NO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE. THIS WARRANTY STATES PACE TECHNOLOGIES ENTIRE AND EXCLUSIVE LIABILITY AND BUYER'S EXCLUSIVE REMEDY FOR ANY CLAIM FOR DAMAGES IN CONNECTIONS WITH PACE TECHNOLOGIES PRODUCTS. PACE TECHNOLOGIES WILL IN NO EVENT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, NOR FOR ANY SUM IN EXCESS OF THE PURCHASE PRICE.

2. LIABILITY CAP:

PACE Technologies maximum aggregate liability for loss and damage arising under, resulting from or in connection with the supply or use of the Equipment and Consumables provided under this purchase, or from the performance or breach of any obligation (s) imposed hereunder, whether such liability arises from any one or more claims or actions for breach of contract, tort, (including negligence), delayed completion, warranty, indemnity, strict liability or otherwise, unless otherwise limited by the terms hereof, shall be limited to one hundred percent (100%) of the purchase price.

3. DELIVERY:

Customer assumes and shall bear the risk of all loss or damage to the Products from every cause whatsoever, whether or not insured, and title to such Products shall pass to Customer upon PACE Technologies delivery of the Products to the common carrier of Pace Technologies choice, or the carrier specified in writing by Customer, for shipment to Customer. Any claims for breakage, loss, delay, or damage shall be made to the carrier by the Customer and Pace Technologies will render customer reasonable assistance in prosecuting such claims.

4. ACCEPTANCE:

Customer shall inspect the Products promptly upon receipt of delivery. Unless customer objects in writing within thirty (30) business days thereafter, customer shall be deemed to have accepted the Products. All claims for damages, errors, or shortage in Products delivered shall be made by Customer in writing within such five (5) business day period. Failure to make any claim timely shall constitute acceptance of the Products.

5. PAYMENT:

Customer agrees to provide timely payment for the Products in accordance with the terms of payment set forth on the reverse side hereof or in any proposal submitted herewith. If any payment is not paid on or before its due date, Customer shall pay interest on such late payment from the due date until paid at the lesser of 12% per annum or the maximum rate allowed by law.

6. DEFAULT:

If Buyer is in default (including, but not limited to, the failure by Buyer to pay all amounts due and payable to Seller) under the work or purchase order or any other agreement between Buyer and Seller, Buyer's rights under the warranty shall be suspended during any period of such default and the original warranty period will not be extended beyond its original expiration date despite such suspension of warranty rights.

7. MISCELLANEOUS PROVISIONS:

This agreement has been made in and shall be governed by the laws of the State of Arizona. All disputes arising under or relating to the purchase of the equipment shall be brought and resolved solely and exclusively in the State of Arizona, Pima County. These terms and conditions and the description of the Products on the reverse side hereof or in any proposal submitted herewith constitute the entire agreement and understanding of the parties with respect to this sale and supersede all prior and contemporaneous agreements or understandings, inducements or representations, expressed or implied, written or oral, between the parties with respect hereto. Any term or provision of this Agreement may be amended, and any observance of any term of this Agreement may be waived, only by a writing signed by the party to be bound. The waiver by a party of any breach shall not be deemed to constitute a waiver of any other breach. Should suit be brought on this Agreement, the prevailing party shall be entitled to recover its reasonable attorneys' fees and other costs of suit including costs and attorneys' fees incurred on appeal or in collection of any judgment. All claims for damages, errors, or shortage in Products delivered shall be made by Customer in writing within such five (5) business day period. Failure to make any claim timely shall constitute acceptance of the Products.

8. RESTOCKING FEE:

All Returns are subject to a restocking charge equal to 15% (fifteen percent) of the Invoice, unless the Goods are proved to be non-conformed by PACE Technologies.

1.0 Product Description

1.1 General Description



The HV-1000Z is a Microhardness tester for testing metallographic specimens.

The HV-1000Z is a variable load Microhardness tester with a load range of 10 grams to 1000 grams and has a auto turret for switching between the indenter and the objectives.

1.2 Technical Specifications

Electrical specifications:	220V single-phase (50/60 Hz)
Test forces:	0.098N(10gf) 0.245N(25gf) 0.49N(50gf) 0.9807N(100gf) 1.961N(200gf) 2.942N(300gf) 4.903N(500gf) 9.807N(1000gf)
Magnification:	100X, 400X
Dwell time of test force:	1-60 seconds
Max. height of specimen:	65 mm (2.6-inches)
Loading:	Automatic loading and unloading
Weight:	Approx. 55 lbs (25 kg)
Dimensions (WxHxD):	Approx. 16.5" x 7" x 18.5" (420 mm x 180 mm x 470 mm)
Working temperature:	70° - 85°F (23 - 28°C)

2.0 Unpacking, Shipping and Installation

2.1 Unpacking

Unit is delivered in a box. Unpack and check for completeness of parts.

Measures WxHxD: 21"x17"x21" (530x430x530 mm)

Weight: Approximately 75 lbs (35 kg)

2.2 Shipping

When moving box, lift with handles.



! **Caution:** Heavy equipment. Take care to avoid bodily injury.

2.3 Installation

! Install unit carefully! Improper installation voids warranty.

The **HV-1000Z** should be placed on a flat stable vibration free surface.

2.3.1 Remove shipping securing string and tape


Remove shipping ties



Remove indenter securing tape




2.3.2 Install leveling feet




2.3.3 Remove shipping securing tape from weight holder


Remove shipping tape





Remove weight stack cover



2.3.4 Remove shipping securing screws for Loading lever




Shipping securing
screws




Remove shipping
securing screws

2.3.5 Weight load stack



Weight stack


Weight holder



Weight holder
with stack of
weights




2.3.5.1 Installing weight stack



Align weight stack
so that it fits into
groove at the bottom
of the holder

-Rotate to make
sure it is in place

Replace
weight stack
cover





Test load selector
knob to make sure it
rotates freely



2.3.6 Installing filar eyepiece

Remove cap
from eyepiece
tube




Attach filar eyepiece /
measurement device



Plug in
communication
cable

2.3.7 Installing camera



-Insert c-mount adapter into port and attach camera.



To center image in camera
the following adjustment
may need to be made by
moving lever shown. First
remove filar and unscrew
lens, lever is inside.

2.3.8 Installing stage

Lower stage
height and attach
stage



Tighten set screw




2.3.9 Leveling unit

Place bubble level on
stage and adjust feet
height to level the unit



2.3.10 Installing digital camera (optional)

- Remove MHT top panel.
- Remove plastic cover on lens splitter
- Screw in camera adapter
- Replace MHT cover plate
- Screw on camera



Remove plastic cover and screw in camera adapter

Remove plastic cover and screw in camera adapter



Screw on camera





2.3.10.1 Aligning light path for camera

- If the light path for the camera is off center it can be adjusted by adjusting the angle of the prism
- Remove filar
- Unscrew eyepiece lens
- With a screwdriver move lever left or right to adjust



Remove filar and unscrew eyepiece lens



Camera / eyepiece splitter prism adjustment (prism shown out of unit above)

2.3.10.2 Focusing Digital camera to filar eyepieces


- Focus through filar eyepieces
- Adjust focal length of camera adapter to match focus



Loosen locking nut and adjust focal length, tighten to lock in place

2.3.11 Replacing Indenter

2.3.11.1 Remove Indenter




Loosen screw and
remove indenter

2.3.11.2 Install Indenter

With turret in the indenting position
(indenter forward)


-Align red dot on indenter so it is
facing forward for proper alignment
(note for Knoop indenters the some
additional adjustment may be required
to align the indenter)



After loading indenter - run a
sample indent to properly set
the indenter

2.3.11.3 Aligning the indenter with the objectives

To align the indenter with the objective there
are three set screws on the objective.
-remove the turret plastic cover (three screws)
-Adjust the set screws (note if the indenter is
too far off it may need to be rotated in 90
degree increments for Vickers or 180 degrees
for Knoop)



Adjustment set screws - may
require loosening one side
while tightening the other

2.3.12 Calibrating Measurements

The unit has been calibrated before shipment, however, if it is necessary to recalibrate the unit the magnification of the image (optics) will need to be changed.

Prior to adjusting the optics it is recommended that the following be checked first:


1. Verify that the filar is pushed all the way into the light tube
2. Verify that the light tube is not loose (turn clockwise to tighten)
3. Verify that the unit level (use bubble leveler)
4. Verify that the load stack is hanging free and weight stack arm crossbar is positioned in the loading arm slot
5. Check that the indenter is not binding in its holder.
6. Focus the eyepiece so the filar lines are in sharp focus.

2.3.12.1 Calibrating Procedure

Step 1. remove
filar from light
tube



Step 2. remove
light tube cover
plate



Step 3. Unscrew light
tube

Step 4. Adjust sleeve on light tube.

Example:

To increase the measured hardness turn the locking ring clockwise so the tube threads deeper into the prism (shorter tube length). As an approximation 1/2 turn of the ring changes the measured value by about 2% (1000 gram load, 1/2 turn increased hardness from 405-415)



Step 5. reverse procedure to
reinstall and retest hardness.
Repeat procedure until calibrated.

3.0 Safety Guidelines

3.1 Warning Sign

! This sign points to special safety features on the machine.

3.2 Safety Precautions

! Careful attention to this instruction manual and the recommended safety guidelines is essential for the safe operation of the **HV-1000Z**.

! Proper operator training is required for operation of the **HV-1000Z**. Any unauthorized mechanical and electrical change, as well as improper operation, voids all warranty claims. All service issues need to be reported to the manufacturer / supplier.

! Operate unit as specified in this manual.

! Disconnect power before opening unit.

! Lower stage to avoid damaging indenter or lens when not in use.

! Cover unit with dust cover when not in use to eliminate dust contamination.

3.3 Emergency Statement

Always follow proper operational guidelines and avoid contact with lubricants and abrasives.

4.0 Operation

STEPS FOR HV-1000Z OPERATION IN BRIEF


(Please see explanation of important points on next pages before proceeding)

1. Mount the sample so it is flat on the stage. For non-parallel mounts a leveling vice is recommended (optional)
2. Turn on the HV-1000Z (allow the auto turret to calibrate itself before beginning any operation). Focus on an edge of the sample and then move to the location for the indentation, Adjust intensity of light (L- and L+), set Filar to ZERO (press CLR to zero), select the Load and enter the Dwell Time
3. Press Start to make Indentation. Note: The auto turret will automatically rotate the indenter into place, apply the load and then rotate back to the 40X objective.
4. Measure D1 / D2 (for Vickers) (PRESS BUTTON ON FILAR TO ACCEPT), rotate the Filar micrometer counter-clockwise, measure D2 (PRESS BUTTON ON FILAR TO ACCEPT), and the rotate to original position clockwise). For Knoop measure only the major axis, D1 is measured (PRESS BUTTON ON FILAR TO ACCEPT). NOTE THE FIRST INDENT IS NOT RECORDED INTO MEMORY AS IT IS COMMON PRACTICE FOR THE FIRST INDENT TO BE USED TO SET THE INDENTOR.
5. Note the HV or HK value
6. If the measurement is bad, press (DEL) and re-measure indent.
7. If more impressions need to be taken, move stage to relevant location and go to step 3
8. PRT to print results or to send to Hyper Terminal
9. Lower stage and remove the sample and/or leveling vice. Switch the instrument off.



Sample Leveler
(optional)

Measurement button



Please read this instruction manual carefully and follow all installation, operating and safety guidelines.

PRECAUTIONS

Clamp the sample properly on the self-leveling vice. This will make the sample exactly perpendicular to the indenter.

Important : This is very important as a tilted sample can damage the indenter. it is also very important to have a flat specimen. A rounded specimen will have varying height as it moves and can touch and damage the indenter.

The stage should be at its lowest position before placing the leveling vice on the stage. The stage can be lowered to its lowest position by rotating the focusing handle in the counter-clockwise direction.

Important : Take utmost care to insure that the sample or the leveling vice does not touch the indenter or the optics as this may damage the indenter

Switch on the HV-1000Z and focus the specimen under 10x objective (Care should be taken to see that the indenter is not touching any part of the sample or the leveling vice when you index the indenter / objective)


Important : When raising the stage to get the sample in focus, always look at the sample as it is raised from the side (NOT from the eyepiece) and stop raising it when there is a gap on approximately 0.1 mm between the sample and the objective

Index the indenter over the sample (Care should be taken to insure that the indenter is not touching any part of the sample or the self leveling vice when you index the indenter / objective)

Next swing the 40x objective into place and make sure that the indenter again does not touch anything when being indexed. Focus if necessary

Important : When raising the stage to get the sample in focus, always look at the sample as it is raised from the side (NOT from the eyepiece) and stop raising it when there is a gap on approximately 0.1 mm between the sample and the objective tip. Then view through the eyepiece and lower the stage to do the fine focusing

4.1 Control Panel



Setting DATE: To set the date, immediately after the date shows on the display after the WELCOME, press the TIME+ or TIME- key. Set the year and press SPEC TIME+ , set the month, press SPEC TIME+ to adjust the day. To exit date field press SPEC.

CLR	The CLR key is used to reset the filar to zero
PRT	The PRT key is used to print or connect the interface; the key serves to print the data of the present test or send them to the COM interface of a PC through RS232. Note: see Appendix for setting up Hyper Terminal to PC
L+	The L+ key is used to increase the intensity of the light. A continuous tone indicates the maximum intensity has been reached.
L-	The L- key is used to reduce the intensity of the light. A continuous tone indicates that the intensity of the light is at a minimum.
START	The START key is used to begin the test
DEL	Delete's entry after the measurement has been made. Note you must enter a value with the button on the filar before you DEL. Otherwise you will not be able to continue.

5.0 Maintenance

5.1 Introduction

The **HV-1000Z** requires very minimal maintenance. However, to increase the life of the Microhardness tester, it is suggested that the unit be covered when not in use.

5.2 Cleaning outside cabinet

The cabinet should be cleaned occasionally with a moistened cloth. Do not use any chemicals or cleaning abrasives.


6.0 Trouble Shooting

More extensive trouble shooting, repair guides, video's, parts list are provided online at www.metallographic.com or


<http://www.metallographic.com/PACE-service/MHT-service.html>

Problem	Cause	Solution
No power or function	a. Unit is disconnected from main electrical power supply b. Main power switch is off c. Blown fuse	a. Verify electrical source and connection. b. Turn on main power switch. c. Replace fuse
Indenter does not move	a. Unit needs to be reset b. Internal damage	a. Turn off power and restart b. Call service center.
Chipped indent	Broken indenter	Replace indenter
Indenter not in alignment with objective	Objective not centered on indenter	-Align objective -If grossly out of alignment the indenter may need to be rotated in 90 degree increments for Vickers and 180 degrees for Knoop indenters
Indent not symmetric	Indenter may need to be rotated	-Rotate indenter 90 degree increments for Vickers and 180 degrees for Knoop indenters
Indenter not indenting properly	Indenter balancing pin out of position (see image below)	-Place dislodged part back into position (see below)



Align this into position





7.0 Spare Parts






Part no.	Description	Image
	Electrical components	
MNT-1050	HV-1000Z control board	
MHV2-E-CB	MHV-2000 control board	
MHT-010	MHT driver control board	
MHT-011	MHT driver control input board	
MHT-012	MHT indenter motor	
MHT-013	MHT turret motor	
MHT-014	MHT 110/220 volt transformer	






Part no.	Description	Image
	Electrical components	
MHT-E-LH	MHT lamp housing	
MHT-Bulb	MHT light bulbs (each)	
811-881	PC-RS232 software cable	
811-882	PC RS-232 to USB software cable	
MHT-E-PRI	MHT Printer-1	
MHT-PRI2	MHT Printer-2	
CORD-110	110V USA power cord	
CORD-220R	220V round prong power cord	
CORD-220F	220V flat prong power cord	

Part no.	Description	Image
Optical components		
MHT-001	MHT filar eyepieces	
823-311	MHT-10X objective	
823-331	MHT-40X objective	

Part no.	Description	Image
Camera components		
823-361	MHT 1X camera adapter (c-mount)	
MP50	5 MP digital camera	
Microhardness-Pro	Microhardness Pro software for measuring indent size	

Part no.	Description	Image
	Camera components	
MHT-003	MHT X-Y table w/o micrometers	
MHT-ENG	MHT micrometers (English units) (2/set)	
MHT-MET	MHT micrometers (Metric units) (2/set)	
MHT-M-VI	Vickers Indenter	
MHT-M-KI	Knoop Indenter	
MHT-M-IRS	Indenter retention screw	
MHV-S	Precision screw feed height adjustment unit for microhardness testers	
MHT-M-HAW	Height adjustment wheel	
MHT-FEET	MHT feet (4/pkg)	
823-902	Dust cover for MHT	

Part no.	Description	Image
	Camera components	
811-100-1	Printer paper rolls for MHT-1 printer (2.25-inch width)	
811-100-2	Printer paper rolls for MHT-2 printer (1.75-inch width)	
MHT-P-TPC	Turret plastic cover	
MHT-2000-W	MHV-2000 additional 1000 gram weight	
MHT-W	10 to 1000 gram weight stack for MHT testers	
MHT-ROD	Weight stack holder for MHT testers	

Part no.	Description	Image
	Fixturing vises	
823-741	MHT sample leveler	
MHT-BUB	Bubble Level	
MHT-004	MHT Fork-shaped test table	
MHT-005	MHT Thin specimen test table	
MHT-006	MHT Fine wire test table	

8.0 Microhardness Testing Basic

Microhardness testers are both mechanical and optical measuring tools. The indent is produced by applying a known load to the specimen and then measuring the size of the appropriate diagonals either optically or with image analysis software.

Microhardness is primarily determined with either a Knoop or Vickers indenter under test loads in the range of 1 to 2000 gram-force. Microhardness is used to measure the hardness of specific phases, small particles, and for brittle materials. Figure 6-1 shows the Knoop microhardness indents for a heat treated steel specimen.

Knoop hardness (HK) number is based on the size of the indent that a rhombic-based, pyramidal diamond indenter produces under a known applied load. The HK number is calculated by dividing the applied load (kilogram-force) by the projected area of the indentation (square millimeters).




Figure 6-1 Knoop hardness

indents in a hardened steel.

The Vickers hardness (HV) number is obtained by dividing the applied load in kilogram-force by the surface area of the indentation. The area of the indentation produced from the Vickers square-based pyramidal diamond is determined by the mean distance between the two diagonals of the indentation (Figure 6-2).




Figure 6-2 Vicker indent.