

Beta - Beta R10-R12 minnicross service manual

INDICE

1 MINICROSS R10 / MINICROSS R12

Thank you for your trust and have fun.

With this manual we wanted to give you the necessary information for a correct use and a good maintenance of your bike.

INDICE

2 INFORMATIONS ATTENTION

It is recommended, after the first hour of training, to check all the tightenings with particular attention to:

Footrests

Wheel spokes

Shock absorber

Engine bolts

Sprocket

INDICE

3 ECOLOGIC DRIVE

The noise and the pollution of every vehicle depends on how it is driven.

We strongly recommend you to drive steadily, without strong acceleration and deceleration.

During off road use do not damage the environment, avoid noise and everything that can disturb persons and animals.

Use a sport drive only on race circuits

SAFE DRIVE

this vehicle must only be run on racetracks and away from normal roads. Parents are responsible for the safety of children, therefore they must pay the utmost attention to them;

always wear your safety helmet, correctly fastened;

drive with your hands and feet in the correct drive position;

do not tow and avoid being towed by others vehicles;

use both brakes, take care when the road is wet, dirty, slippery;

do not start the engine in enclosed spaces.

Drive carefully, to preserve your own and the other lives.

Respect the nature. Always wear the helmet.

INDICE

4 SECTION 1 GENERAL INFORMATION

Main parts 8

Vehicle identification data..... 9

Hand drive controls 10

Technical data 11, 13

Electrical diagram 14

SECTION 2 OPERATION AND USE

Checks and maintenance before

and after off-road use 16

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Fueling operations	17
Recommended lubricants and liquids	18
Breaking in	19
Startup	20
SECTION 3 MAINTENANCE AND CHECKS	
Crankcase oil	22
Air filter.....	23
Spark plug	25
Brakes	26
Checks after cleaning.....	27
Maintenance schedule	28

INDICE

5 SECTION 4 ADJUSTMENTS

Adjustment of brake	30
Adjustment of idling speed.....	31
Adjustment of gas clearance	31
Check and adjustment of steering gear	32
Tightening the chain.....	33

SECTION 5 WHAT TO DO IN AN EMERGENCY

Trouble shooting.....	36,37,38
-----------------------	----------

ALPHABETICAL INDEX

Index	40
-------------	----

BETAMOTOR S.p.A. reserves the right to change the data and features described in this manual and to modify its products at any time.

7 GENERAL INFORMATION

INDEX

Main parts

Vehicle identification data

Hand drive controls

Technical data

Electrical diagrams

CHAPTER 1 SECTION 1

8 GENERAL INFORMATION

MAIN PARTS

- 1 Gasoline tank plug
- 2 Air filter
- 3 Stand
- 4 Fuel tap
- 5 Fuel tank
- 6 Kick-starter
- 7 Silencer
- 8 Muffler

- 9 Fork
- 10 Saddle
- 11 Rear mudguard
- 12 Front mudguard
- 13 Swingarm
- 14 Shock absorber

9 GENERAL INFORMATION

VEHICLE IDENTIFICATION DATA

Frame identification

The identification data A are stamped on the the steering tube, r.h. side, on model R10, and on the chassis, r.h. side, on model R12.

Motor identification

The identification data of the engine B are stamped on the rear part of the engine assembly.

10 GENERAL INFORMATION

HAND DRIVE CONTROLS

- 1 Front brake lever
- 2 Throttle control
- 3 Engine stop push button