

MZ - MZ_BK_15PS_Manual_de_intretinere

Index

FOREWORD

The IFA motor vehicle from the nationally owned vehicle industry of the German Democratic Republic, to which these operating instructions belong, has been designed by experienced engineers according to the latest state of the art and manufactured by our workers with the best possible material with all due care. It should help the owner and driver in their professional work and also bring them joy in their free time.

To make this possible, the vehicle must be reliable and safe to operate. The manufacturer has tried to create all the prerequisites for this - and yet the reliability and service life of any vehicle depends decisively on correct operation and maintenance. Ask in a workshop why vehicles are there for repair - in most cases it can be proven that the repair case could have been avoided or postponed for a very long time if the driver had treated the vehicle in accordance with the instructions in the operating instructions. Therefore, observing every single regulation is in the driver's own interest - and therefore the small effort to familiarize yourself with these regulations before starting the vehicle is worthwhile, and every hour spent on maintenance work is also worthwhile, which cannot be done without a certain amount of time. Don't forget that every motor vehicle represents valuable national property, and preserving it for as long as possible is not only a personal advantage but also a national duty!

Obering. Siegfried Rauch

Technical Director

at VEB Forschungs- und Entwicklungswerk Karl-Marx-Stadt

Operating Instructions for the MZ Motorcycle BK 350 <http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>

1 of 176 02.11.2008 23:08

TABLE OF CONTENTS

1 Technical Data

1.1 Engine

1.2 Clutch

1.3 Transmission

1.4 Brakes

1.5 Wheels

1.6 Suspension

1.7 Steering

1.8 Electrical System

1.9 Frame

1.10 Chassis

1.11 Dimensions and Weights

1.12 Filling Quantities

1.13 Engine Characteristic Curves

2 Description

2.1 Engine

2.1.1 Crankshaft

2.1.2 Crankcase

2.1.3 Cylinder and Cylinder Head

2.1.4 Piston and Piston Pin

2.1.5 Alternator with Flat Regulator and Breaker

2.1.6 Ignition Coils

2.1.7 Carburetor and Air Filter

2.1.8 Clutch

2.2 Transmission

2.2.1 Housing and Intermediate Flange Operating Instructions for the MZ Motorcycle BK 350
<http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>

2 of 176 02.11.2008 23:08

2.2.2 Wheels and Shafts

2.2.3 Shift Automatic and Cam Roller

2.2.4 Kick Starter

2.2.5 Electrical Neutral Indicator Switch

2.2.6 Speedometer Drive

2.3 Drive

2.3.1 Front Rubber Joint

2.3.2 Cardan Shaft with Universal Joint

2.3.3 Rear Wheel Drive Housing with Pinion and Ring Gear

2.4 Chassis

2.4.1 Frame

2.4.2 Telescopic Fork

2.4.3 Rear Wheel Suspension

2.4.4 Brakes

2.4.5 Front and Rear Wheel Axles

2.4.6 Saddle, Kickstand, Footrests, Fuel Tank

2.4.7 Electrical System

2.4.8 Accessories

2.4.9 Steering Lock

2.5.0 Tools

2.5.1 Mounting a Sidecar

3 Operating Instructions

3.1 Arrangement and Purpose of the Operating Levers

3.1.1 Fuel Tap

3.1.2 Starter Flap

3.1.3 Throttle Twist Grip

3.1.4 Ignition and Light Switch

3.1.5 Dimmer Switch and Signal Button

3.1.6 Clutch Lever

3.1.7 Kick Starter

3.1.8 Foot Shift Lever

3.1.9 Foot Brake Lever and Footrests Operating Instructions for the MZ Motorcycle BK 350
<http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>

3 of 176 02.11.2008 23:08

- 3.1.10 Hand Brake Lever
 - 3.1.11 Kickstand
 - 3.1.12 Thigh Cushion Adjustment
 - 3.2 Proper Operation
 - 3.2.1 Starting (Cold Start)
 - 3.2.2 Warm Start
 - 3.2.3 Starting with or without a Discharged Battery
 - 3.2.4 Starting and Shifting Up
 - 3.2.5 Shifting Down
 - 3.2.6 Stopping
 - 3.2.7 Break-in Period
 - 3.2.8 Wheel Removal and Installation
 - 3.2.9 Tire Change
 - 4 Maintenance Instructions
 - 4.1 What Needs to be Done?
 - 4.1.1 Before the First Ride
 - 4.1.2 Daily
 - 4.1.3 After the First 500 km
 - 4.1.4 After Every 1000 km
 - 4.1.5 After Every 2000 km
 - 4.1.6 After Every 5000 km
 - 4.1.7 After Every 10000 km
 - 4.1.8 Seasonal Maintenance Work
 - 4.2 Performing Maintenance Work
 - 4.2.1 Lubrication
 - 4.2.2 Air Filter Cleaning
 - 4.2.3 Spark Plug Maintenance
 - 4.2.4 Fuel Tap Cleaning
 - 4.2.5 Checking, Cleaning, and Adjusting the Carburetors
 - 4.2.6 Checking the Electrical System
 - 4.2.6.1 Testing Alternator and Regulator
 - 4.2.6.2 Breaker Maintenance Operating Instructions for the MZ Motorcycle BK 350
- <http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>
- 4 of 176 02.11.2008 23:08
- 4.2.6.3 Check Ignition Timing
 - 4.2.6.4 General Maintenance Work on the Electrical System
 - 4.2.6.5 Battery Maintenance
 - 4.2.7 Checking and Removing Residue Buildup in the Engine
 - 4.2.8 Cleaning the Exhaust System
 - 4.3 Troubleshooting Guide
 - 4.3.1 Engine Does Not Start
 - 4.3.2 Fuel Runs Out of the Drain Holes in the Clutch Housing After Priming, But the Engine Does Not Start
 - 4.3.3 The Ignition is Switched On, But the Charging Control and Neutral Indicator Lamp Do Not Light Up
 - 4.3.4 Ignition Switched On, But There is No Spark at the Spark Plug or Only a Very Weak Spark
 - 4.3.5 A Strong Spark Jumps Across at the Spark Plug, But the Engine Does Not Start

- 4.3.6 Engine Starts, But Only Fires on the Left Cylinder
- 4.3.7 Engine Does Not Start in Very Cold Weather or Stalls Again After Starting
- 4.3.8 Engine Cannot be Adjusted to Idle Speed
- 4.3.9 Charging Control Lamp Does Not Extinguish After Starting the Engine
- 4.3.10 Battery is Not Charged Sufficiently
- 4.3.11 Engine Misses in the Upper Speed Range

5 Repair Instructions

5.1 Engine Group

- 5.1.1 Engine Removal
- 5.1.2 Blocking the Transmission
- 5.1.3 Replacing Clutch Plate or Clutch Pressure Springs
- 5.1.4 Changing Speedometer Drive
- 5.1.5 Removing Alternator
- 5.1.6 Making Centrifugal Weights Move Freely
- 5.1.7 Adjusting Ignition
- 5.1.8 Removing Cylinders and Pistons for Decarbonization

5.2 Drive Group

- 5.2.1 Removing Rear Wheel Drive

5.3 Chassis Group

- 5.3.1 Replacing Bushings in Telescopic Fork

5.3.2 Dismantling Shock Absorbers Operating Instructions for the MZ Motorcycle BK 350

<http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>

5 of 176 02.11.2008 23:08

- 5.3.3 Replacing Bushings in the Rear Wheel Suspension
- 5.3.4 Adjusting Steering Bearing
- 5.3.5 Adjusting Headlight

6. Spare Parts Procurement and Technical Service

6.1 IFA Warranty Provisions

6.2 IFA Contract Workshops for Motorcycles BK 350

6.3 Warranty Provisions for the Vehicle Electrical Production of IKA

6.4 Directory of IKA Auto Electrical Services

Wiring Diagram

Lubrication Plan

Exploded View Engine

Exploded View Transmission

Exploded View Rear Wheel Drive Operating Instructions for the MZ Motorcycle BK 350

<http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>

6 of 176 02.11.2008 23:08

Image 1. Exploded View of the Engine 1 Technical Data 1.1 Engine

next point ; Index

Working Method Two-stroke Stroke 65 mm Bore 58 mm Operating Instructions for the MZ Motorcycle BK 350

<http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>

7 of 176 02.11.2008 23:08

Number of Cylinders and Arrangement Two-cylinder Boxer Engine Displacement $2 \times 171.7 \text{ cm}^3 = 343.4 \text{ cm}^3$

Compression Ratio 6.5 : 1 Compression Chamber 31 cm^3 Power at 5000 rpm 15 HP Maximum Torque at 3000 rpm 2.7

kgm Cooling Air (Wind) Valve Timing Suction with peak 120 degrees Crank Angle Suction without peak 104 degrees Crank Angle Scavenging 116 degrees Crank Angle Exhaust 136 degrees Crank Angle Carburetor Number 2 Make IFA BVF NB 22-7 Setting Air Funnel Diameter 22 mm Main Jet 95 Idle Jet 030 Operating Instructions for the MZ Motorcycle BK 350 <http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>

8 of 176 02.11.2008 23:08

Needle Jet 67 Needle Position III

Position of Idle Air Screw 2 ... 2½ turns open Throttle Slide Cutout 14 Float Level 21.5 mm Float Weight Without Needle 8.5 g Air Filter 115 mm Diameter Lubrication Mixture Lubrication (Mixing Ratio Oil : Fuel 1 : 25) Ignition Type Battery Ignition Spark Plug Isolator M 14-225 Thread Length 10 mm Electrode Gap 0.55 mm Breaker Contact Gap 0.4 mm Ignition Timing Adjustment Automatic by Centrifugal Weights Pre-Ignition 3...3.5 mm BTDC with fully opened Centrifugal Weights Ignition Coil Number 2 Firing Order in Both Cylinders Simultaneously Operating Instructions for the MZ Motorcycle BK 350 <http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>

9 of 176 02.11.2008 23:08

Piston Si 20 Oversizes for Cyl.-Ø 58; 58.25; 58.50; 58.75; 59 mm Weight, Naked 191 g Piston Rings 3 per Piston Type Compression Rings Crankshaft Bearing Number 2 Type Front WJL 25, Rear 6305 Connecting Rod Bearing Double Roller, Without Cage

1.2 Clutch

next point ; Index

Type Single-disc Dry Clutch Lining 'Original Coswig', Pressed onto Driven Disc Number of Pressure Springs 6 Operating Instructions for the MZ Motorcycle BK 350 <http://www.mz-b.de/miraculis/aw/mz/text/bk15b/bk15b.html>

10 of 176 02.11.2008 23:08