

Benelli - Tornado Tre 1130 def

TORNADO TRE 1130 User Manual

Tornado Tre 1130

Tornado Tre 1130

1 General Information	1
1.1 Symbology	2
1.2 Identification Data	3
2 Safety Information	5
2.1 Safety	5
2.1.1 Motorcycle Modification and Alignment Personalization	5
2.1.2 General Safety Rules	6
2.1.3 Vehicle Load	8
2.1.4 Vehicle Use in Competitions	9
2.1.5 Tips for Safe Driving	9
2.1.6 Protective Clothing	12
2.1.7 Suggestions for Theft Prevention	13
2.2 Safety Visual and Acoustic Signals	14
3 Controls and Instruments	15
3.1 Position of Controls and Instruments	15
3.2 Side Stand	16
3.3 Left Handlebar Controls	17
3.4 Right Handlebar Controls	19
3.5 Main Switch and Steering Lock	21
3.6 Gearshift Control	23
3.7 Instruments and Warning Lights	24
3.7.1 Multifunction Display	25
4 Use	26
4.1 Motorcycle Use	26
4.2 Pre-Ride Checks	27
4.3 Break-in Period	29
4.4 Display Function Selections	30
4.5 Clock Adjustment	31
4.6 Motorcycle Stopping	32
4.7 Rider Seat Removal	33
4.8 Passenger Seat Removal	33
4.9 Passenger Tail Removal	34
4.10 Refueling	35
4.11 Engine Starting	37
4.12 Improving our Driving Capabilities	38
5 Adjustments	39
5.1 List of Adjustments	39

5.2 Synoptic Table of Adjustments	41
5.3 Adjustments that can be Performed by the User	42
5.3.1 Front Brake Lever Adjustment..	42
5.3.2 Rearview Mirror Adjustment	42
5.4 Adjustments that Must be Performed by an Authorized Benelli Workshop	43
5.4.1 Clutch Lever Play	43
5.5 Front Suspension Adjustment	44
5.5.1 Spring Preload Adjustment.....	45
5.5.2 Rebound Adjustment	45
5.5.3 Compression Adjustment	46
5.6 Rear Suspension Adjustment	47
5.6.1 Spring Preload Adjustment	49
5.6.2 Rebound Adjustment	49
5.6.3 Compression Adjustment	50
5.6.4 High Speed Compression Adjustment....	50
6 Maintenance	52
6.1 Maintenance and Control Tables	52
6.2 Tools and Accessories Provided with the Equipment	62
6.3 Lubricant and Fluid Table	63
6.4 Engine Oil - Level Check	64
6.4.1 Engine Oil - Level Restoration ..	65
6.5 Coolant Level Check	67
6.5.1 Coolant Level Restoration	68
6.6 Brake Pads Wear Check	70
6.7 Brake Control Fluid Level Check	71
6.8 Tires and Rims - Check	73
6.8.1 Rims and Wheel Check	75
6.9 Chain - Cleaning and Lubrication Check	76
6.9.1 Cleaning	77
6.9.2 Lubrication	77
6.10 Idle Speed - Check	78
6.11 Fuse Replacement	79
6.12 Battery	81
6.13 Motorcycle Cleaning	82
6.14 Extended Stop Period	84
7 Technical Information	85
7.1 Technical Data	85
8.1 Power Control System.....	91
8.1.1 Power Control System Activation	92

Tornado Tre 1130

General Information

Dear Customer:

We invite you to read this Manual before using your new TORNADO TRE 1130.

This manual contains important information for the safe use of the motorcycle and for its maintenance in efficient condition. Keep it in the appropriate document holder.

In any case, remember that TORNADO TRE 1130 is a high-performance motorcycle that requires careful and precise driving.

Avoid pushing the motorcycle to its limit if you are not sure of your ability to maneuver it, and whenever you are riding on public roads or roads open to the public, strictly respect the rules of the Highway Code.

Always remember to wear a homologated helmet, of your size, and always correctly fastened.

In addition, we recommend that you always wear appropriate protective clothing.

1.1 Symbolology

To make the reading of the most important information clearer and faster, we have used the following symbols:

Danger Warns that there is an intrinsic serious danger that could cause personal injury and even fatal accidents if the warnings provided are not taken into account.

Warning Warns that there is a danger that could cause personal injury and accidents, even fatal, if the warnings provided are not taken into account.

Caution Reminds of a safety measure to be followed or an unsafe action to be avoided in order not to run the risk of personal injury or damage to the motorcycle.

Benelli Q.J. s.r.l. reserves the right to modify its products and this manual at any time.

In cases where there is a discrepancy between what is established in the Manual and the specific equipment of your Motorcycle, do not hesitate to download the updated version of the Manual from the website www.benelli.com, or contact Benelli Customer Service at +39 0721.418740, which will send you the updated version.

Tornado Tre 1130

3

4 2) engine registration number

1.2 Identification Data

1. chassis registration number
2. engine registration number
3. homologation data

It is advisable to record the data in the spaces below.

Chassis Number ZBN _____

Engine Number _____

Color Code _____

Key Number _____

Motorcycle Identification

The motorcycle is identified by the chassis registration number.

Key Identification

A key is provided, with four copies, to be used both for starting and for operating all locks. Keep the spare copies in a safe place.

Knowledge of the key identification number is essential in case it is necessary to request a duplicate key as a spare part.

Color Combination Identification

The color code is essential for ordering bodywork spare parts. This code can be viewed on the plates located under the seat.

Spare Parts Order

To order spare parts, in addition to the chassis registration number, it may be necessary to indicate the engine registration number, the color code and the key identification number.

3) homologation data

1) chassis registration number

key identification number

Color code plates

Tornado Tre 1130

5

6 2 Safety Information

2.1 Safety

2.1.1 Motorcycle Modification and Alignment Personalization

CAUTION It is absolutely forbidden to tamper with the motorcycle, modifying its mechanical components or replacing them with non-original spare parts. These actions can not only invalidate the vehicle's approval, preventing its use on public roads, but can also cause serious damage to the user and the vehicle itself. Benelli Q.J. is not responsible for any damage to people or objects caused by any modifications made to the original conditions of the motorcycle.

You can personalize the alignment of the TORNADO TRE 1130 suspensions by intervening on the appropriate adjustments. This operation is absolutely discouraged unless the user is completely sure of his technical knowledge. Modifying the alignment can impair the safe use of the motorcycle and therefore should only be performed by experienced people. In cases where you want to personalize the alignment of the motorcycle based on personal needs, we recommend contacting an Authorized Benelli Workshop, the list of which can be found on the Benelli Q.J. Website www.benelli.com or by calling Benelli Customer Service at +39 0721.418740.

2.1.2 General Safety Rules

Before starting to drive, make sure you know well the operating principles of the controls, the characteristics, I