

## Beta - Beta Minitrial 50 service manual

### INDICE

#### MINITRIAL 50

Thank you for your trust and have fun.

With this manual we wanted to give you the necessary information for correct use and good maintenance of your motorcycle.

### INDICE

#### ATTENTION

It is recommended, after the first hour of training, to check all the tightening with particular attention to:

Footrests

Shock absorber cover

Wheel spokes

Shock absorber

Engine bolts

Crown

Engine under tray

### INDICE

#### ECOLOGIC DRIVE

The noise and the pollution of every vehicle depends on how it is driven.

We strongly recommend you to drive steadily, without strong acceleration and deceleration.

During off road use do not damage the environment, avoid noise and everything that can disturb persons and animals.

Use a sport drive only on race circuits

#### SAFE DRIVE

this vehicle must only be run on racetracks and away from normal roads. Parents are responsible for the safety of children, therefore they must pay the utmost attention to them;

always wear your safety helmet, correctly fastened;

drive with your hands and feet in the correct drive position;

use both brakes;

take care when the road is wet, dirty, slippery;

do not start the engine in enclosed spaces.

Drive carefully, to preserve your own and the other lives.

Respect the nature. Always wear the helmet.

### INDICE

#### SECTION 1 GENERAL INFORMATION

# BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Main parts .....	8
Vehicle identification data.....	9
Hand drive controls .....	10
Technical data .....	11, 12
Electrical diagram .....	13
SECTION 2 OPERATION AND USE	
Checks and maintenance	
before and after use .....	16
Fueling operations .....	17
Recommended lubricants and liquids .....	18
Breaking in .....	19
Startup .....	20
SECTION 3 MAINTENANCE AND CHECKS	
Gearbox oil .....	22
Air filter.....	23
Spark plug .....	25
Brakes .....	26
Checks after cleaning.....	27
Maintenance schedule .....	28

## INDICE

### SECTION 4 ADJUSTMENTS

Adjustment of brake .....	30
Adjustment of idling speed.....	32
Adjustment of gas clearance .....	32
Check and adjustment of steering gear .....	33
Tightening the chain.....	34
Adjustment of rear shock absorber .....	35

### SECTION 5 WHAT TO DO IN AN EMERGENCY

Trouble shooting .....	38, 39, 40
------------------------	------------

### ALPHABETICAL INDEX

Index .....	42
-------------	----

BETAMOTOR S.p.A. reserves the right to change the data and features described in this manual and to modify its products at any time.

## GENERAL INFORMATION

### INDEX

Main parts

Vehicle identification data

Hand drive controls

Technical data

Electrical diagrams

### CHAPTER 1 SECTION 1

## GENERAL INFORMATION

## MAIN PARTS

- 1 Gasoline tank plug
- 2 Air filter
- 3 Stand
- 4 Fuel tap
- 5 Fuel tank
- 6 Kick-starter
- 7 Silencer
- 8 Rear brake pedal
- 9 Fork
- 10 Fuel tank cover
- 11 Rear mudguard
- 12 Front mudguard
- 13 Fork
- 14 Muffler

## GENERAL INFORMATION

### VEHICLE IDENTIFICATION DATA

Frame identification

Identification data A are stamped on the front part of the chassis, r.h. side.

Motor identification

Motor identification data B are stamped on the rear part of the engine assembly.

## GENERAL INFORMATION

### HAND DRIVE CONTROLS

- 1 Front brake lever
- 2 Gas throttle
- 3 Engine stop push button