

## Atlant - STEED

Mopeds 50

expert22 for <http://rutracker.org>

Atlant Moto

### OPERATION MANUAL

#### CONTENTS:

- Safety precautions
- Description
- Control panel
- Ignition lock
- Start button
- Light switch
- Horn
- Turn signal activation
- Helmet fastener and luggage compartment for its storage
- Starting the engine
- Checking the moped before starting to move
- Moped operation
- Maintenance
- Technical characteristics
- Wiring diagram
- Maintenance schedule
- Warranty conditions

expert22 for <http://rutracker.org>

A word to the buyer. Your moped is a product manufactured using professional equipment from high-quality components. Equipped with an electronic ignition system, an electric starter, and its consumer properties are at the level of leading world manufacturers - an economical engine, low noise level, good acceleration dynamics and excellent handling. All these qualities are combined so that your moped becomes a high-tech and convenient conqueror of urban roads. This instruction provides detailed information about your moped - how to properly ride and service it.

The manufacturer hopes for your understanding regarding the possible discrepancy between the illustrations in this instruction and the actual moped; this is due to the constant modernization of production and differences in the configuration of models. Please read this instruction carefully and follow the recommendations to make your communication with the moped pleasant and mutually beneficial. We wish you good luck on the roads and enjoy using our products.

2

expert22 for <http://rutracker.org>

## Safety precautions:

1. Observe traffic rules and check the moped before starting to move.
2. Do not wear uncomfortable clothing that may affect safety.
3. Wear a helmet.
4. Exhaust gas can adversely affect your health; start the moped in a well-ventilated room.
5. Do not operate with one hand.
6. Sit in the middle of the seat while driving. Sitting at the very end of the seat can lead to the scooter overturning and an accident.

4

expert22 for <http://rutracker.org>

7. Easily turn your body when turning, otherwise this may lead to unstable control.

expert22 for <http://rutracker.org>

8. Sharp turning or braking can lead to an accident.
9. Be careful on uneven or damaged surfaces, slow down, relax your wrists and shoulders, and hold the handlebars firmly.
10. Do not park the moped near flammable objects.
11. Never overload the moped and secure transported items well.

## ATTENTION:

1. Do not place fabric items between the plastic cover and the engine, this may lead to a fire.
2. Do not carry foreign objects on the moped outside the luggage or rear compartment to avoid damaging the surface of the moped.

## DESCRIPTION:

5

expert22 for <http://rutracker.org>

expert22 for <http://rutracker.org>

## CONTROL PANEL

1. Odometer

The total mileage is shown in km. Black numbers on a white background show 100m.

2. Speedometer

Total number of kilometers km/h

3. High beam indicator

Lights up when high beam is on.

4. Turn signal indicator

Lights up when the turn signal is activated.

5. Fuel indicator

Shows the amount of fuel in the tank. It is recommended to use gasoline no lower than AI-92 grade.

expert22 for <http://rutracker.org>

## IGNITION LOCK

OFF: Position where you can remove the ignition key, while all moped electrical circuits are turned off.

ON: Working position of the lock, ignition and electrical circuit are turned on. The key is locked.

LOCK: Position in which the steering column is locked. To lock the steering wheel, you need to: turn the steering wheel to the left, press the key and turn it counterclockwise, remove the key. To unlock the steering wheel, you need to: insert the key into the slot and turn the key clockwise to the OFF position.

## START BUTTON

The start button will only work when the brake lever is depressed.

8

expert22 for <http://rutracker.org>

## LIGHT SWITCH

Has three positions.

OFF - Off: instrument panel lighting and all external lighting devices except the brake light and turn signals.

;00 - Parking lights on, low/high beam off.

- Parking lights and low/high beam on.

Attention - if the engine is stopped - parking lights and headlights will not work.

9

expert22 for <http://rutracker.org>