

CFMoto - CFMoto ATV Goes 520, 520 Max. Owner_s Manual. French

SUMMARY

SAFETY	P2-3
IDENTIFICATION NUMBER	P 4
LOCATION AND FUNCTION OF PARTS	P 5-11
VEHICLE PREPARATION	P 11
LOADING	P 12
DRIVING	P 12
STARTING THE ENGINE	P 13
BREAK-IN	P 14
MAINTENANCE SCHEDULE	P 15
MAINTENANCE	P16-23
ELECTRICAL SYSTEM	P 24-25
CLEANING THE VEHICLE	P26
STORAGE	P 26
SPECIFICATIONS	P 27
WARRANTY	P 28-30

SAFETY

Thank you for reading this manual carefully before using the vehicle.

An ATV is not a toy and its use can be dangerous. The handling of an ATV is different from that of other vehicles, including motorcycles and cars. If you do not take the necessary precautions, a collision or rollover can occur quickly, even during routine maneuvers such as taking a turn or when driving on slopes or over obstacles.

Heed the caution and safety messages appearing in the manual.

GOES 520 and 520 MAX vehicles must be driven by users over 16 years old with the appropriate license.

ATVs approved according to 2002/24 (European standard) for authorized circulation on public roads must be equipped with all accessories required by law:

Mirrors Brake light
Turn signals Headlight
Speedometer Rear lighting
Horn License plate

SAFETY SAFETY

Please check the vehicle before use.

Respect the age of use.

Do not allow a child to use this vehicle.

Wear clothing suitable for the vehicle and a helmet.

Do not exceed a speed that does not allow you to remain in control of your vehicle.

Do not modify the components of the vehicle under penalty of losing the vehicle's approval and the manufacturer's warranty.

Respect the maintenance periods under penalty of losing the manufacturer's warranty.

Do not overload the vehicle abnormally.

Remember that alcohol, drugs, fatigue and inattention can considerably reduce your ability to make good decisions and drive well.

Do not go beyond your limits. Trying to push your limits is one of the main causes of ATV accidents.

Heat

Always stop the engine before leaving the machine. When parking the machine, note the following points: the engine and the exhaust pipe may be hot. Park the machine in a place where pedestrians and children are not likely to touch it.

Ventilation

Never start or let the engine run in an enclosed space.

Exhaust gases are toxic and can cause fainting and death in a short time. Always use your machine in a place with adequate ventilation.

Gasoline is highly flammable

- Always turn off the engine when refueling with gasoline.
- When refueling, be careful not to spill gasoline on the engine or the exhaust pipe.
- Never refuel while smoking or near a open flame.

In case of accident

If you swallow gasoline or a lot of gasoline vapor, or if you accidentally get it in your eyes, consult your doctor immediately. If you spill gasoline on your skin or clothes, wash it off immediately with soap and water and change your clothes.

Protection

Always wear a helmet, gloves, boots, pants and a jacket for motorcycle riding.

IDENTIFICATION NUMBERS

The serial number and the engine number are necessary for the registration of your vehicle. Write the numbers in the boxes below.

IDENTIFICATION NUMBERS

(1) Vehicle Identification Number (VIN)

(2) Vehicle Model Number

(3) Engine Identification Number

LOCATION AND FUNCTION OF PARTS

Left handlebar controls

(1) Power limiter in 4x4 Lock mode (4-wheel drive)

In the case of use in 4x4 mode with differential lock, the vehicle speed is limited.

If conditions require more driving power, press the button (1).

(2) Light switch

In this position, the lights are off.

In this position, the parking lights are on.

In this position, the low beams and parking lights are on.

(3) Turn signal switch

Push to the left: left turn signal in service.

Push to the right: right turn signal in service.

(4) Horn button

LOCATION AND FUNCTION OF PARTS

(5) Low beam / high beam switch

In this position, the low beams are on.

Press the switch to turn on the high beams. Press the switch again to return to the low beam position.

(6) Engine start button

To start the engine, press the start button (6), with the gearbox in neutral and the starter switch in the "ON" position.

LOCATION AND FUNCTION OF PARTS

Dashboard indicators

(1) 2WD / 4WD indicator (6) Reverse gear indicator

(2) Left turn signal indicator (7) Parking brake indicator

(3) Short gear indicator (8) Right turn signal indicator

(4) Long gear indicator (9) Power limiter indicator

(5) Neutral indicator (10) High beam indicator

* Function of the 2WD / 4WD indicator

The drive wheel indicator has 3 positions:

In this position, it indicates that the ATV is in 2-wheel drive (2WD)

In this position, it indicates that the ATV is in 4-wheel drive (4WD)

In this position, it indicates that the ATV is in 4-wheel drive with differential lock (4WD LOCK).

LOCATION AND FUNCTION OF PARTS

Dashboard

(1) Engine temperature indicator

When the temperature indicator is in the white "C" sector, it means that the temperature is normal. The red sector on the "H" side indicates that the temperature is too high. In this case stop the engine until the temperature of the coolant drops. In case of overheating, consult a dealer.

(2) Tachometer

Indicates the vehicle speed in Km/h.

(3) Odometer

Indicates the total mileage of the vehicle.

(4) Fuel gauge

Indicates the fuel level in the tank.

LOCATION AND FUNCTION OF PARTS

Starter switch

(1) Key switch

The key switch positions are:

"ON" The engine can be started, the headlights and the rear light can be turned on. The key cannot be removed.

LOCATION AND FUNCTION OF PARTS

Braking controls

Front brakes

The front brakes are applied by squeezing the brake lever "1" which is located on the right handle.

Rear brakes

The rear brake is applied by squeezing the brake lever "2" which is located on the left handle.

Brake pedal

The brake pedal "3" activates the entire braking system front and rear.

Parking brake

The gear selector lever is equipped with a parking brake (see page 14).

LOCATION AND FUNCTION OF PARTS

Gear lever

The gear selector lever (1) is located on the left side of the vehicle.

5 positions are possible:

"L" low gear

"H" high gear

"N" neutral

"R" reverse

"P" parking

The lever has a locking system, to change gears it is therefore necessary to press the brake pedal.

The change of the different positions is carried out as follows:

Shifting gears with the engine above idle speed idle or the vehicle is moving could damage the transmission.

To change gears, stop the vehicle and let the engine idling. Always put the transmission in position

"P" when the vehicle is stopped.

LOCATION AND FUNCTION OF PARTS

2WD / 4WD / 4WD DIFF-LOCK control

This ATV is equipped with a disengageable front axle (2 or 4-wheel drive) as well as a differential lock. Choose the appropriate mode depending on the terrain and conditions.

In 2-wheel drive mode (2WD): Power is supplied to the wheels rear wheels only.

In 4-wheel drive mode (4WD): Power is supplied to the wheels rear and front.

In 4-wheel drive mode and differential lock (4WD LOCK):

Power is supplied to all 4 wheels and all wheels rotate at the same speed.

Switch from 2WD mode to 4WD

Stop the vehicle and press switch (2) to 4WD. When the ATV is in 4WD mode