

## Husaberg - te\_125\_eu

### OWNER'S MANUAL

TE 125 EU

TE 250 EU

TE 250 AUS

TE 250 USA

TE 300 EU

TE 300 AUS

TE 300 USA

2013

Art. no. 3802032en

### DEAR HUSABERG CUSTOMER 1

DEARHUSABERGCUSTOMER Congratulations on your decision to purchase a HUSABERG motorcycle. You are now the owner of a state-of-the-art sports motorcycle that will give you enormous pleasure if you service and maintain it accordingly.

We wish you a lot of enjoyment in riding this vehicle.

Enter the serial numbers of your vehicle below.

Chassis number (p. 12) Dealer's stamp

Engine number (p. 12)

Key number (TE EU/AUS) (p. 12)

The Owner's Manual contained the latest information for this model at the time of going to print. Slight deviations resulting from con-

tinuing development and design can, however, not be completely excluded.

All specifications are non-binding. HUSABERG, a division of KTM Sportmotorcycle AG (referred to below as HUSABERG) specifically

reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc.,

without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular

model without prior notice. HUSABERG accepts no liability for delivery options, deviations from illustrations and descriptions or mis-

prints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of delivery.

© 2012 KTM-Sportmotorcycle AG / Division HUSABERG, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright

owner.

ISO 9001(12 100 6061)

Within the meaning of the international quality management standard ISO 9001, HUSABERG uses quality assurance processes that lead to the maximum possible quality of the products.

Issued by: TÜV Management Service

# BL Motorcycles Ltd

Professional Workshop Manual - English Translation

KTM-Sportmotorcycle AG / Division HUSABERG

5230 Mattighofen, Austria

TABLE OF CONTENTS 2

TABLE OF CONTENTS

|                                                 |    |
|-------------------------------------------------|----|
| 1 MEANS OF REPRESENTATION .....                 | 5  |
| 1.1 Symbols used .....                          | 5  |
| 1.2 Formats used.....                           | 5  |
| 2 SAFETY ADVICE.....                            | 6  |
| 2.1 Use definition - intended use .....         | 6  |
| 2.2 Safety advice.....                          | 6  |
| 2.3 Degrees of risk and symbols.....            | 6  |
| 2.4 Tampering warning.....                      | 6  |
| 2.5 Safe operation .....                        | 7  |
| 2.6 Protective clothing .....                   | 7  |
| 2.7 Work rules.....                             | 7  |
| 2.8 Environment.....                            | 7  |
| 2.9 Owner's Manual .....                        | 8  |
| 3 IMPORTANT NOTES.....                          | 9  |
| 3.1 Warranty .....                              | 9  |
| 3.2 Operating and auxiliary substances .....    | 9  |
| 3.3 Spare parts, accessories .....              | 9  |
| 3.4 Service .....                               | 9  |
| 3.5 Figures .....                               | 9  |
| 3.6 Customer service.....                       | 9  |
| 4 VIEW OF VEHICLE .....                         | 10 |
| 4.1 View of vehicle, front left (example) ..... | 10 |
| 4.2 View of vehicle, rear right (example) ..... | 11 |
| 5 SERIAL NUMBERS .....                          | 12 |
| 5.1 Chassis number .....                        | 12 |
| 5.2 Type label .....                            | 12 |
| 5.3 Key number (TE EU/AUS).....                 | 12 |
| 5.4 Engine number .....                         | 12 |
| 5.5 Fork part number .....                      | 12 |
| 5.6 Shock absorber part number .....            | 13 |
| 6 CONTROLS.....                                 | 14 |
| 6.1 Clutch lever.....                           | 14 |
| 6.2 Hand brake lever.....                       | 14 |
| 6.3 Throttle grip .....                         | 14 |
| 6.4 Kill switch (TE EU/AUS) .....               | 14 |
| 6.5 Kill switch (TE USA) .....                  | 14 |
| 6.6 Horn button (TE EU/AUS).....                | 15 |
| 6.7 Light switch (TE EU/AUS).....               | 15 |
| 6.8 Light switch (TE USA) .....                 | 15 |
| 6.9 Turn signal switch (TE EU/AUS) .....        | 15 |
| 6.10 Emergency OFF switch (TE AUS).....         | 15 |

|                                                                     |    |
|---------------------------------------------------------------------|----|
| 6.11 Electric starter button (TE 250/300 EU/USA)....                | 16 |
| 6.12 Electric starter button (TE AUS) .....                         | 16 |
| 6.13 Overview of indicator lamps (TE EU/AUS).....                   | 16 |
| 6.14 Speedometer .....                                              | 16 |
| 6.14.1 Speedometer overview.....                                    | 16 |
| 6.14.2 Activation and test.....                                     | 16 |
| 6.14.3 Tripmaster switch .....                                      | 17 |
| 6.14.4 Setting kilometers or miles .....                            | 17 |
| 6.14.5 Adjusting the speedometer functions .....                    | 17 |
| 6.14.6 Setting the clock .....                                      | 18 |
| 6.14.7 Querying lap time .....                                      | 18 |
| 6.14.8 Display mode SPEED (speed).....                              | 19 |
| 6.14.9 Display mode SPEED/H (operating hours).....                  | 19 |
| 6.14.10 Display mode SPEED/CLK (clock).....                         | 19 |
| 6.14.11 Display mode SPEED/LAP (lap time).....                      | 19 |
| 6.14.12 Display mode SPEED/ODO (odometer) .....                     | 20 |
| 6.14.13 Display mode SPEED/TR1 (trip master 1).....                 | 20 |
| 6.14.14 Display mode SPEED/TR2 (trip master 2).....                 | 20 |
| 6.14.15 Display mode SPEED/A1 (average speed 1) ...                 | 21 |
| 6.14.16 Display mode SPEED/A2 (average speed 2) ...                 | 21 |
| 6.14.17 Display mode SPEED/S1 (stop watch 1).....                   | 21 |
| 6.14.18 Display mode SPEED/S2 (stop watch 2).....                   | 21 |
| 6.14.19 Table of functions.....                                     | 22 |
| 6.14.20 Table of conditions and menu activation .....               | 22 |
| 6.15 Opening the filler cap.....                                    | 22 |
| 6.16 Closing the filler cap .....                                   | 23 |
| 6.17 Fuel tap .....                                                 | 23 |
| 6.18 Choke .....                                                    | 23 |
| 6.19 Shift lever .....                                              | 24 |
| 6.20 Kick starter .....                                             | 24 |
| 6.21 Foot brake lever .....                                         | 24 |
| 6.22 Side stand.....                                                | 24 |
| 6.23 Steering lock (TE EU/AUS).....                                 | 25 |
| 6.24 Locking the steering (TE EU/AUS) .....                         | 25 |
| 6.25 Unlocking the steering (TE EU/AUS).....                        | 25 |
| 7 PREPARING FOR USE.....                                            | 26 |
| 7.1 Advice on first use .....                                       | 26 |
| 7.2 Running in the engine .....                                     | 27 |
| 7.3 Preparing the vehicle for difficult riding<br>conditions .....  | 27 |
| 7.4 Preparing for rides on dry sand.....                            | 28 |
| 7.5 Preparing for rides on wet sand .....                           | 28 |
| 7.6 Preparing for rides on wet and muddy<br>surfaces.....           | 29 |
| 7.7 Preparing for rides at high temperature and<br>slow speed ..... | 29 |

|                                                                              |    |
|------------------------------------------------------------------------------|----|
| 7.8 Preparing for rides at low temperature and in snow.....                  | 30 |
| 8 RIDING INSTRUCTIONS.....                                                   | 31 |
| 8.1 Checks and maintenance steps when preparing for use .....                | 31 |
| 8.2 Starting.....                                                            | 31 |
| 8.3 Starting off.....                                                        | 32 |
| 8.4 Shifting, riding .....                                                   | 32 |
| 8.5 Braking.....                                                             | 32 |
| 8.6 Stopping, parking.....                                                   | 33 |
| 8.7 Transport .....                                                          | 33 |
| 8.8 Refueling .....                                                          | 34 |
| 9 SERVICE SCHEDULE .....                                                     | 35 |
| 9.1 Service schedule.....                                                    | 35 |
| 9.2 Service work (as additional order) .....                                 | 36 |
| 10 TUNING THE CHASSIS .....                                                  | 37 |
| 10.1 Checking the basic chassis setting with the rider's weight.....         | 37 |
| 10.2 Compression damping of shock absorber .....                             | 37 |
| 10.3 Adjusting the low-speed compression damping of the shock absorber ..... | 37 |
| 10.4 Adjusting the high-speed compression damping of the shock absorber..... | 38 |
| 10.5 Adjusting the rebound damping of the shock absorber.....                | 38 |
| 10.6 Measuring the sag of the unloaded rear wheel....                        | 39 |
| 10.7 Checking the static sag of the shock absorber....                       | 39 |
| 10.8 Checking the riding sag of the shock absorber....                       | 40 |
| 10.9 Adjusting the spring preload of the shock absorberx.....                | 40 |
| 10.10 Adjusting the riding sag x.....                                        | 41 |
| 10.11 Checking the basic setting of the fork .....                           | 41 |
| 10.12 Adjusting the compression damping of the fork .....                    | 42 |
| 10.13 Adjusting the rebound damping of the fork.....                         | 42 |
| 10.14 Handlebar position.....                                                | 42 |