

Piaggio - nrg_power_purejet

Technical Specifications

Motorcycle Manual Text Translation

(Follows a series of special characters - ignored)

This instruction is intended to guide you in serviceable and safely ride your scooter, give guideline to user and recommend regular maintenance! If you have problems that cannot be solved, consult your nearest dealer. Do shall keep this manual handy. (Keep manual on a safe place)

Downloaded from www.Manualslib.com manuals search engine

THE INSTRUCTIONS ARE INTENDED TO ASSIST YOU TO DRIVE A VEHICLE. FOR SAFETY AND RELIABILITY, GIVE THESE INSTRUCTIONS TO WHOEVER USES THE VEHICLE, AND TO ANY SUBSEQUENT OWNER. This would allow us to continue improving designs and products.

Downloaded from www.Manualslib.com manuals search engine

NOTES:

All data and illustrations are based on the latest product information at the time of publication.

Modifications or significant changes in product specifications or equipment may occur.

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

USAGE AND MAINTENANCE

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

WARNING:#####
#####READ

WARNING:#####
#####CAREFULLY

WARNING:#####
#####SAFETY INSTRUCTIONS

WARNING:#####
#####PERIODIC MAINTENANCE

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

WARNING:#####
#####TROUBLESHOOTING MAINTENANCE

Downloaded from www.Manualslib.com manuals search engine

Technical Specifications

Downloaded from www.Manualslib.com manuals search engine

01_01 WARNING/CAUTION/NOTE

WARNING/CAUTION/NOTE

EXPLANATION (REFERENCE TO LOCATION)

FOR USERS (CONSUMERS)

FOR TECHNICIANS

EXAMPLES OF LOCATION AND STYLE

LOCATION ON AN ASSEMBLY

SAFETY ATTENTION AND ALERT

01_02 RIGHT/LEFT/Front/REAR

DESCRIPTION

Right (Direction that the machine is proceeding)

Left (Direction that the machine is proceeding)

Front View

Rear View

Downloaded from www.Manualslib.com manuals search engine

01_03 TOOL/METER AND LUBRICANT/SPECIFICATION

TOOL/METER/LUBRICANT

TOOL NAME

LUBRICANT (Specified Lubricant for cooled vehicles)

TORQUE WRENCH

FUEL LEVEL (Specified Fuel for cooled vehicles)

THERMOMETER (Specified Lubricant for cooled vehicles)

DIESEL OIL (Specified Lubricant for cooled vehicles)

[Diagram listing parts]

REMARKS: The illustration in the book is just a guide, because of continuous design and developments, illustrations are liable to change without any prior announcement for all models. The values shown by the meter are average readings, and should be used as a reference. The actual conditions can vary depending on the vehicle conditions!

0.5-1.0: Refer to the model and level of cooled vehicles.

FOR REFERENCE

Always think Safety! What could happen when working? Always wear safety equipment including safety glasses. The location of safety equipment is very important. Check it, before you start your work!

Downloaded from www.Manualslib.com manuals search engine

For those of you who understand the guidelines you will have more trust, as well as you will always feel safe. The

incorrect handling and maintenance, can lead to accidents.

Always read the manual before assembly/ repair