

Beta - Beta REV3 owners manual

INSTRUCTION MANUAL
INSTRUCTION MANUAL
INSTRUCTION MANUAL
INSTRUCTION MANUAL
INSTRUCTION MANUAL DE INSTRUCCIONES
MANUEL DINSTRUCTIONS

INFORMATION ON PRIVACY PROTECTION

With reference to Law 31/12/1996 n. 675 on the protection of persons with respect to the processing of personal data, we inform you of the following:

- 1) The data provided by you will be entered, with your consent, into our customer database, which can be used for any commercial information in the interest of customers and market surveys;
- 2) The provision of the data entered in the "Delivery slip for the 1-year warranty" is necessary to be able to provide normal warranty services;
- 3) The processing of the data provided by you will be based on the principles of correctness, lawfulness and transparency provided for by current legislation;
- 4) You may at any time assert the rights recognized by article 13 of law n. 675/96, by contacting:

INFORMATION ON LAW N. 122 OF 05/02/1992

Based on law n.122 of 05/02/1992, for any maintenance or repair operation other than the replacement of filters, lubricating oils or cooling liquids, it is recommended to rely on one of our authorized dealers.

BETAMOTOR S.p.A. 50067 Rignano sull'Arno - (FI) ITALY Pian dellisola 72.

37GBREV-3

Thank you for choosing BETA. Wishing you a lots of good biking!

This manual will give you the information you need to use your motorcycle correctly and to keep it in excellent condition.

BETAMOTOR S.p.A. reserves the right to change the data and features described in this manual and to modify its products at any time.

38GB

ATTENTION

After the first training hour, check all the tightenings and in a particular manner:

Footboard supports
Front and rear brake disks
Wheel rims
Shock absorber bolt
Engine bolts and nuts
Crown

39

INDEX

SECTION 1: GENERAL INFORMATION

Main parts	42
Vehicle identification data.....	42

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Instrument panel and controls.....	42
Technical data	43
Electrical diagram	44
SECTION 2: OPERATION AND USE	
Check and maintenance before and after off-road use	46
Fueling	46
Recommended lubricants and liquids	47
Breaking in	47
Startup	48
SECTION 3: MAINTENANCE AND CHECKS	
Gearbox oil	50
Brake pump oil	51
Clutch pump oil	53
Fork oil	54
Air filter	56
Spark plug	57
Front brake	58
Rear brake	59
Liquid coolant	60
Silencer	60
Carburetor	61
Valve petals	61
Checks after cleaning	62
Maintenance schedule	62
SECTION 4: ADJUSTMENTS	