

## CFMoto - CFMoto ATV JourneyMan Gladiator X8. Owner\_s Manual. Czech

Journeyman Europe CZ 1

Instruction and Maintenance Manual

JourneyMan Gladiator X-8  
All Terrain Vehicle

Variants: X8-EFI all types

Note: Some information contained in this manual may vary depending on the specific model of the machine.

Photos and illustrations are for illustrative purposes only. Complete technical data can be found in the Technical Certificate or CoC list issued for each individual machine. In case of doubt, contact the brand representative. Changes reserved.

### INTRODUCTION

Congratulations on purchasing a Journey Man Gladiator - All Terrain Vehicle (hereinafter ATV). We are proud to offer you this product designed and manufactured to the highest standards and according to strict quality standards. We are confident that you will enjoy its premium design, reliability, comfortable ride and safety.

This manual is intended for owners and operators of the ATV, familiarizing them with the operating characteristics and many features and functions that the ATV offers. The manual also includes information on ATV care and maintenance. Please read this manual carefully. The information contained in this manual, warning labels and other elements supplied with the ATV will help you understand the safe use and maintenance of the ATV. Make sure you understand everything and follow the instructions and warnings in this manual.

This ATV is not designed for commercial use, ATV rentals and similar industries, or for racing activities. It is designed for trouble-free transport of two people and luggage on roads and in light terrain. We do not provide any warranties on the life and reliability of the machine if these conditions are not observed.

### IMPORTANT SAFETY WARNING

Part of the manual is the "Safety Instructions - Basic Instructions for Safe Use of ATV" guide. Always follow the safety rules in this guide.

Journeyman Europe CZ 2

### MACHINE IDENTIFICATION NUMBERS

Please record the identification numbers of your ATV here. Remove the spare key and store it in a safe place. A duplicate of your key can only be made by matching a new key with your existing key, so if both keys are lost, the ignition switch and complete lock set must be replaced.

A. Machine VIN: \_\_\_\_\_

It is located on the crossmember under the machine seat.

B. Engine serial number: \_\_\_\_\_

It is located on the left side of the engine under the plastic cover.

C. Machine model designation: \_\_\_\_\_

It is located on the identification plate above the right wheel.

### FEATURES

#### Electrical Switches and Controls

##### A. - Lights Switch

The light switch consists of four positions.

When the switch is in the front position, the high beams and rear tail light are on.

When the switch is in the middle - front position, the low beams and rear tail light are on.

When the switch is in the middle - rear position, all lights are off.

When the switch is in the rear position, the side lights and rear tail light are on.

### WARNING

Do not use the lights for more than 10 minutes after turning off the engine. The battery may be discharged to the point that the machine will not start. If this happens, remove the battery and recharge it.

Journeyman Europe CZ 3

##### B. - Starting

Press this button if you want to start the engine.

##### C. - Turn Signal Switches

Press the switch to , the left turn signal turns on and the indicator light illuminates

Press the switch to , the right turn signal turns on and the indicator light illuminates

Switching the switch to the middle position turns off the turned on turn signal and its indicator light

##### D. Hazard Light Switch

Press this button to activate the hazard lights.

##### E. - Horn

Press the button to sound the horn.

##### F. Engine kill switch

Press the button to disconnect the engine ignition. Pressing it again reactivates the ignition.

##### H. Override - disconnecter of the limiter (not shown)

It is located on the front side of the combined switch. The top speed is limited in 4WD-LOCK mode. If conditions require higher engine power while driving, press and hold this switch to limit the speed limiting function in 4WD-LOCK mode. Releasing the switch restores the speed limiting function. While the switch is depressed, the override indicator light is on.

## WARNING

Activating the override disconnecter while the throttle lever is depressed can cause loss of control of the machine, which can lead to serious injury or death.

## 2. 4WD Gearshift Buttons

This controller shifts 4WD and 4WD LOCK. See the "4WD Shifting" section for more information.

## 3. Throttle Lever

Use this lever to accelerate and move the machine.

## Brakes

### Front Brake Lever

The brake lever is located on the right side of the handlebars. Use the front brakes by pushing towards the handlebars.

### Brake Pedal and Rear Brake Lever

The brake pedal is located on the right side of the machine and the brake lever is located on the left side of the handlebars. Use the rear brakes by depressing the pedal or pushing the lever towards the handlebars. Note: In the EEC version, these two controls control all brakes simultaneously.

## WARNING

Using an ATV with wet brakes can lead to insufficient braking, which can cause an accident. Never use the ATV with wet brakes.

Always check the brake lever and fluid reservoir before riding. If it is empty, the lever should be hard to operate. Any moisture may indicate a possible crack in the fluid reservoir or low fluid level in the reservoir. Therefore, it must be checked before driving. Contact your dealer for diagnosis and repair.

Always keep the space under the brake pedal clean. If contaminated, the pedal may become blocked, which may cause an accident.

## Journeyman Europe CZ 4

### Brake fluid

Check the brake fluid level in the front and rear reservoirs before each use of the ATV. The front reservoir is located on the right side of the handlebars. The rear is near the rear brake pedal in front of the right rear wheel.

The fluid level in the front reservoir is visible through the transparent window on the side of the reservoir. If the level is lower than the "lower" line, add the same type of brake fluid to the reservoir.

## WARNING

An overfilled reservoir can cause the brakes to seize, lock or burn out, which can lead to serious injury or death. Keep brake fluid at the recommended level. Do not overfill.

## CAUTION

When checking the brake fluid, the ATV must be on the ground with the handlebars straightened. If the fluid level is low, add only DOT3 brake fluid. Do not overfill.

### WARNING

Never store or use a partially used container of brake fluid. Brake fluid accepts moisture, meaning it rapidly absorbs moisture from the air. This causes a decrease in the boiling point of the brake fluid, which can lead to weakened brakes and cause an accident resulting in serious injury. Always discard the remainder after opening the brake fluid container.

### Parking brake

When parking, turn off the engine and move the transmission control lever to the parking position. Never shift or unshift using excessive force. This could damage the gears and steering components.

### CAUTION

It is not possible to use the ATV with the parking gear engaged. If you want to move and start the machine, always disengage the parking gear first. Attempting to engage parking gear while driving will cause transmission failure and may lead to an accident resulting in serious injury or death.

### WARNING

Never leave the ATV parked on a hill without securing it. Always chock the wheels when parking downhill to prevent the machine from moving on its own. Another option is to park the ATV along the contours of the hill. Never park on a hill with a trailer. Excessive force is applied to the parking gear in this case and there is a risk of gear failure.

### Fuel tank

The fuel tank cap is located under the plastic cover on the rear of the machine. Open the fuel tank cap by turning it counterclockwise. Close the fuel tank cap by turning it clockwise. Do not overtighten.

### Fuel safety

### WARNING

- Gasoline is a highly flammable substance under certain circumstances.
- Always be extremely careful when handling gasoline.
- Always refuel with the engine off, outdoors or in a well-ventilated area.
- Do not fill a plastic gasoline can when it is placed on the carrier. Static electricity between the carrier and the can may cause a spark.
- Do not smoke or handle open flames when refueling or near where gasoline is stored. - Do not overfill the fuel tank. Do not fill to the brim.
- In case of gasoline splashes on skin or clothing, wash skin thoroughly with soap and change clothes.
- Never start or run the ATV in an enclosed space. Gasoline fumes are poisonous and can quickly cause loss of consciousness or death.

### Journeyman Europe CZ 5

### WARNING

The engine exhaust from this product contains chemicals known to cause cancer, birth defects or other reproductive harm. Operate the ATV only outdoors or in a well-ventilated area.

### Automatic transmission control lever

The control lever is located on the left side of the machine.

L: slow gear (L)

H: fast gear (H)

N: neutral (N)

R: reverse (R)

P: parking position (P)

Shifting to position (R) requires the use of the left brake lever or, preferably, the brake pedal to unlock the mechanism. When disengaging from position (R), it is necessary to use the left brake lever or brake pedal to unlock the mechanism. It is also necessary to press the act