

BSA - SECTION K

D14/4 SERVICE TOOLS K1

INDEX

Page

FLYWHEEL BOLSTER	K2
FLYWHEEL PUNCH	K2
FLYWHEEL STRIPPING BARS (2)	K2
CLUTCH SPRING COMPRESSOR	K2
SMALL-END BEARING EXTRACTOR	K2
REAR DAMPER TOOL	K3
WHEEL BEARING RETAINER PEG SPANNER	K3
ENGINE SPROCKET EXTRACTOR	K3
FORK LEG REMOVAL TOOL	K4
OIL SEAL EXTRACTOR PUNCH	K4
OIL SEAL ASSEMBLY TOOL	K4
OIL SEAL HOLDER TOOLS	K5

D14/4 SERVICE TOOLS K2

FIG. K1.

61-3791 Small-end Bearing Extractor.

FIG. K2.

61-3206 Flywheel Bolster.

61-3209 Flywheel Punch.

61-3208 Flywheel Stripping Bars (2).

FIG. K3.

61-3191 Clutch Spring Compressor.

D14/4 SERVICE TOOLS K3

FIG. F4.

61-3644 Wheel Bearing Retainer Peg Spanner.

FIG. K5.

61-3796 Engine Sprocket Extractor.

FIG. K6.

61-5064 Rear Damper Tool.

D14/4 SERVICE TOOLS K4

FRONT FORKS

FIG. K7.

61-3824 Fork leg removal tool.

FIG. K8.

Oil seal extractor

punch No. 61-3006.

FIG. K9.

Oil seal assembly
tool No. 61-3007.

D14/4 SERVICE TOOLS K5

FIG. K10.

61-3633 Fork Leg Oil Seal Holder Tool.

FIG. K11.

Oil seal holder fitting and
removal tool No. 61-3005.