

Husaberg - Husaberg__04_Owners_Manual

OWNERS MANUAL

MANUEL DUTILISATION 04

Edition 2004

TABLE OF CONTENTS

- 1 -

ENGLISHPage

INTRODUCTION	2
Important limited warranty and limited guarantee information	4
SERIAL NUMBER LOCATIONS	5
Chassis number	5
Engine-Number	5
OPERATION INSTRUMENTS	6
Clutch lever	6
Hand decompression lever	6
Hand brake lever	6
Short circuit button	6
Combination switch	7
Flasher switch	7
Ignition lock	7
Headlamp switch (USA)	7
Indicator lamps	8
Starter button	8
Emergency OFF switch (Australia)	8
Electronic speedometer	8
Tripmaster-switch	9
Setting the clock	13
Activating/deactivating the display modes	13
Kilometers or miles	14
Filler cap	15
Fuel taps	15
Choke	15
Hot start device	15
Shift lever	16
Kickstarter	16
Foot brake pedal	16
Side stand	16
Compression damping of fork	17
Rebound damping of fork	17
Damping action during compression of shock absorber	18
Rebound damping of shock absorber	19
Steering lock	19
TIPS AND WARNINGS FOR STARTING THE MOTORCYCLE	20

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Instructions for initial operation	20
Running in the Husaberg models	20
DRIVING INSTRUCTIONS	21
Check the following before each start	21
Starting when the engine is cold	22
Starting when the engine is warm	22
What to do when the engine is flooded	22
Starting off	22
Shifting/Riding	23
Braking	23
Stopping and parking	24
Fuel	24
PERIODIC MAINTENANCE SCHEDULE 2004	26
MAINTENANCE WORK ON CHASSIS AND ENGINE ..	30
Checking and adjusting the steering head bearing ..	30
Breather plug front fork	31
Cleaning the dust sleeves of the telescopic fork ..	31
Basic suspension setup for the weight of the driver ..	32
Checking the shock absorber and spring	32
Determining the static sag of the shock absorber ..	32
Determining the riding sag of the shock absorber ..	32
Checking the basic setup of the telescopic fork ..	33
Changing the spring preload on the telescopic fork ..	33
Page	
Replacing fork springs	33
How to change the handlebar position	34
Changing the spring preloading of the shock absorber ..	34
Check chain tension	35
Correct chain tension	35
Chain maintenance	36
Chain wear	36
General information about Husaberg disc brakes ..	37
Changing the basic position the hand brake lever (FC, FE) ..	38
Changing the basic position the hand brake lever (FS) ..	38
Checking the brake fluid level - front brake	38
Refilling the front brake fluid reservoir	38
Checking the front brake pads	39
Replacing the front brake pads (FC/FE)	39
Replacing the front brake pads (FS)	39
Changing the basic position of the foot brake pedal ..	40
Check the rear brake fluid level	40
Refilling the rear brake fluid reservoir	40
Checking the rear brake pads	41
Replacing the rear brake pads	41
Dismounting and mounting the front wheel	42

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Dismounting and mounting the rear wheel	43
Checking the shock absorption rubbers in the rear hub .	44
Checking spoke tension	44
Tires, air pressure	45
Check/set distance of the magnetic sensor	45
Battery	46
Charging the battery	46
Fuse (FE/FS)	47
Replacing headlight lamp/parking light lamp	47
Cooling system	48
Checking the coolant level	48
Bleeding the cooling system	49
Replacing the glassfiber yarn packing of the silencer .	49
Cleaning the spark arrester	49
Cleaning the air filter	50
Checking the adjustment of the hand decompression release cable	50
Adjusting the throttle cables	50
Changing the original position of the clutch lever . .	51
Checking the oil level of the hydraulic clutch	51
Bleeding of the hydraulic clutch	51
Carburetor Adjust idling	52
Basic information on carburetor wear	52
Adjusting the mixture control screw	52
Checking the float level (float height)	53
Draining the float chamber of the carburetor	53
Oil Circuit	53
Checking the engine oil level	54
Engine oil	54
Changing the engine oil	54
Cleaning the oil screen	54
Changing the oil filter	55
TROUBLESHOOTING	56
CLEANING, CONSERVATION, STORAGE	58
TECHNICAL DATA - ENGINE	59
TECHNICAL DATA - CHASSIS	61
HEAD WORD INDEX	64
WIRING DIAGRAMM	Appendix

INTRODUCTION

- 2 -

ENGLISH

IMPORTANT

WE STRONGLY SUGGEST THAT YOU READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE GOING ON YOUR FIRST RIDE. IT CONTAINS A GREAT DEAL OF INFORMATION AND ADVICE WHICH WILL HELP YOU USE AND HANDLE YOUR BIKE PROPERLY.

IN YOUR OWN INTEREST, PLEASE PAY PARTICULAR ATTENTION TO NOTICES THAT ARE MARKED AS

FOLLOWS:

WARNING:

IGNORING THESE INSTRUCTIONS, CAN ENDANGER YOUR BODY AND YOUR LIFE.

CAUTION: IGNORING THESE INSTRUCTIONS COULD CAUSE DAMAGE TO PARTS OF YOUR MOTORCYCLE OR THAT THE MOTOR-CYCLE IS NOT ROAD-SAFE ANYMORE.

NOTE: USEFUL INFORMATION ON HANDLING AND SERVICING YOUR MOTORCYCLE.

Please insert the serial numbers of your motorcycle in the boxes below

Frame number:

Motor number:

Stamp of dealer:

HUSABERG RESERVES THE RIGHT TO MODIFY ANY EQUIPMENT , TECHNICAL SPECIFICATIONS , COLORS , MATERIALS , SERVICES OFFERED AND RENDERED , AND THE LIKE SO AS TO ADAPT THEM TO LOCAL CONDITIONS WITHOUT PREVIOUS ANNOUNCEMENT AND WITHOUT GIVING REASONS , OR TO CANCEL ANY OF THE ABOVE ITEMS WITHOUT SUBSTITUTING THEM WITH OTHERS . IT SHALL BE ACCEPTABLE TO STOP MANUFACTURING A CERTAIN MODEL WITHOUT PREVIOUS ANNOUNCEMENT .

The exhaust system on this vehicle has no owner serviceable parts. Should there be an increase in noise or damage to any component relating to the noise reduction system, replacement parts should be fitted by an Authorised dealer.

Tampering with noise control system prohibited

Owners are warned that the law may prohibit:

(a) The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; and

(b) the use of the vehicle after such device or element of design has been removed or rendered inoperative