

## Beta - Beta ARK owners

1

### 2 ECOLOGICAL DRIVING WARNINGS ON THE USE OF THE VEHICLE ARK L.C. ARK A.C.

Thank You for choosing BETA. Wishing you lots of good biking!

This manual will give you the information you need to use your motorcycle correctly and to keep it in excellent condition. ARK L.C. ARK A.C.

Thank you for your trust and have fun.

With this booklet we wanted to give you the information necessary for proper use and good maintenance of your motorcycle.

The vehicle must be equipped with: license plate, registration certificate, road tax and insurance.

The minimum age for driving is 14 years.

The transport of passengers, animals and objects not secured to the vehicle, which "protrude" from the vehicle's dimensions and which exceed the load expected by the Manufacturer is prohibited.

The helmet is mandatory.

Modifications to the engine or other parts that may lead to an increase in power and therefore speed (speed allowed 45 km/h), is punished by law with severe penalties, including the confiscation of the vehicle.

ATTENTION! Modifications and tampering during the warranty period relieve the Manufacturer from any responsibility and invalidate the warranty.

Each vehicle with an internal combustion engine produces more or less noise (noise pollution) and more or less smoke from the exhaust (air pollution) depending on the type of driving adopted.

The reduction, as much as possible, of these conditions is now a duty for all, therefore avoid full-throttle starts, sudden and unnecessary accelerations and sudden and equally unnecessary braking, thus limiting excessive noise and smoke, premature wear of tires and mechanical parts of the vehicle and saving considerably on fuel consumption.

3

### 4 SAFE DRIVE

The noise and the pollution of every vehicle depends on how it is driven. We strongly recommend You to drive steadily, without strong acceleration and deceleration.

WARNING! BETAMOTOR S.p.A Any modification and tampering of the vehicle will invalidate the warranty.

Drive carefully, to preserve your own life and the lives of others. Always wear a safety helmet!

### ECOLOGICAL DRIVE

#### SAFE DRIVING

Obey the Highway Code;

always wear an approved and fastened helmet;

always keep the protective visor clean;

wear clothes without dangling ends;

do not travel with sharp or fragile objects in your pocket;

adjust the rearview mirror correctly;

always drive seated and with both hands on the handlebars and feet on the footrests;

never be distracted or get distracted while driving;

do not eat, drink, smoke, use a mobile phone, etc... while driving;

do not listen to music with "headphones" while driving;

never travel paired with other vehicles;  
do not tow or be towed by other vehicles;  
Always maintain a safe distance;  
travel with the lights (low beam) even during the day;  
do not stop sitting on the scooter on the stand;  
do not start with the scooter on the stand;  
do not remove the stand with the front/march of the vehicle downhill;  
wheelies, serpentines, swaying, are very dangerous for you, for others and for your scooter;  
on dry road without gravel or sand, use both brakes, one alone can cause dangerous and uncontrollable skidding;  
when braking, use both brakes, thus obtaining a stop of the vehicle in shorter spaces;  
on wet roads, drive carefully and at moderate speed: use the brakes with greater sensitivity;  
do not start the engine in enclosed spaces.

5

6 Obey the Highway Code;

always wear your safety helmet, correctly fastened;  
keep your visor clean;  
wear clothes which do not flap about;  
do not ride with fragile or pointed objects in your pocket;  
adjust your mirrors correctly;  
drive with your hands and feet in the correct position;  
always concentrate when you drive;  
do not eat, drink, smoke, use the cellular phone, etc when you drive;  
never listen to music with headphones on while driving;  
avoid riding beside another vehicle;  
avoid towing or being towed by other vehicles;  
maintain a safe distance from other vehicles;  
always use the lights (even in daylight);  
do not sit on the scooter on the stand;  
do not start drive off with the scooter on the stand;  
do not use the stand when the vehicle is on sloping ground;  
do not pull the stand down when the vehicle is on sloping ground;  
adventurous games such as wheelies and deliberate skidding are dangerous.  
use both the brakes (front first);  
take care when the road is wet, dirty, slippery;  
do not start the engine in enclosed spaces.

SAFE DRIVING

MANUAL SECTIONS

SECT. A GENERAL INFORMATION

SECT. B KNOWING THE VEHICLE

SECT. C OPERATION AND USE

SECT. D MAINTENANCE

SECT. E ADJUSTMENT

SECT. F ELECTRICAL PARTS

### SECT. G WHAT TO DO IN AN EMERGENCY

ATTENTION! It is advisable to contact Betamotor Dealers and Retailers as much as possible, found on the Yellow Pages YELLOW PAGES under the heading "Motorcycles", for interventions where a certain experience in the mechanical and electrical field is essential.

Driving carefully in compliance with the Highway Code and always wearing a helmet are demonstrations of profound civility...

7

### 8SECT. TOPICS PAGE

A General information 10

Supply 10

Load 10

Tires 12

Accessories 14

B Vehicle knowledge 16

Main elements 16

Vehicle identification data 18

Dashboard and controls 20

Keys and locks 22

Technical data 24

Electrical system 26

C Operation and use 28

Running in 28

Recommended lubricants and liquids 28

Electric start 30

Pedal start (kick-starter) 30

Departure 30

Braking 30

Engine stop 30

Engine coolant filling 32

Fuel supply 34

Mixer oil supply 36

Checks before departure 37

D Maintenance and controls 38

Scheduled maintenance 38

Tool compartment 40

Body removal 40

### SECT. TOPICS PAGE

Transmission oil 48

Filters: oil and fuel 50

Spark plug 52

Exhaust 54

Front brake 56

Pad replacement 58

Rear brake 60  
Rear wheel shaft play check 62  
Battery 64  
Long vehicle inactivity 67  
After a long period of inactivity 67  
E Adjustments 68  
Brake lever adjustment 68  
Accelerator play adjustment 70  
Minimum adjustment 70  
Steering play control and adjustment 72  
Shock absorber adjustment 74  
F Electrical parts 76  
Double front headlight 78  
Rear light 79  
Direction indicators 80  
Dashboard bulbs 82  
Electrical system 86  
G Faults - Anomalous operation 88  
Fuel depletion 88  
Mixer oil depletion 88  
Flat battery 88  
Troubleshooting 90

SECT. A GENERAL INFORMATION

SECT. B KNOWING THE VEHICLE

SECT. C OPERATION AND USE

SECT. D MAINTENANCE

SECT. E ADJUSTMENT

SECT. F ELECTRICAL PARTS

SECT. G WHAT TO DO IN AN EMERGENCY

MANUAL SECTIONS

INDEX

WARNING: Contact our dealers in case of problems.

Drive carefully and follow road regulations, always wear your helmet. These precautions are signs of civil and civic-minded behaviour.

9

10SECT. CONTENTS PAGE

A General information 11

Supply 11

Load 11

Tyres 13

Accessories 15

B Vehicle knowledge 17

Main parts 17

Vehicle identification data 19

Instrument panel and control	21
Keys	23
Technical data	25
Electrical system	27
C Operation and use	29
Running in	29
Recommended lubricants and coolant	29
Electric starter	31
Kick-starter	31
Moving off	31
Braking	31
Stop the engine	31
Liquid coolant (L.C. engines)	33
Refueling	35
Injection system oil	36
Checks to do before starting	37
D Maintenance and checks	39
Maintenance schedule	39
Glovebox	41
Removal of body parts	41
SECT. CONTENTS PAGE	
Transmission box oil	49
Oil and fuel filter	51
Spark plug	53
Silencer	55
Front brake	57
Replacing the pads	59
Rear brake	61
Checking rear wheel play	62
Check battery	65
Long period of inactivity	67
After a long period of inactivity	67
E Adjustments	69
Brakes lever adjustment	69
Throttle adjustment	71
Idle speed adjustment	71
Steering play checking and adjusting	72
Rear suspension adjustment	74
F Electrical parts	77
Double front headlight	77
Rear light	79
Direction indicators	80
Dashboard	83
Wiring diagram	86
G What to do in an emergency	89

Lack of fuel 89  
Lack of injection system oil 89  
Battery discharged 89  
Troubleshooting 91  
INDEX

### A GENERAL INFORMATION

#### SUPPLY

The scooter is supplied ready for use, however it is recommended to carry out some simple checks before using it on the road:

- check the correct tire pressure (when refueling for the first time);
- check the oil level of the automatic mixer and transmission;
- check the engine coolant level.

The standard equipment includes: the user and maintenance manual and the tool set in fig. 1 (spark plug wrench, double-use screwdriver) inserted in a plastic bag in the compartment under the saddle.

#### LOAD

This vehicle does not allow the transport of passengers (art. 122 T.U.).

Total weight (scooter + driver) in running order: 160 ÷ 180 Kg.

Absolutely do not transport bulky or too heavy objects, which could affect the stability of the scooter.

Do not carry objects that protrude from the vehicle or cover the lighting and signaling devices.

The helmet should be housed in the special compartment under the saddle, with the part of the shell facing down.

Fig. 1

11

#### 12SUPPLY

The scooter is supplied ready to use, but we suggest some simple checks before using it.

- check the tyre pressure;
- check the transmission oil level and the autolube oil level.
- check the coolant level (in the models equipped with a water cooled engine).

Attachments : owners manual and tool kit in a plastic bag located under the seat (Fig. 1).

#### LOAD

Do not carry large objects, do not cover the lights with these. You must be able to drive unhindered.

Under the seat there is