

Peugeot - vivacity

Notice d'utilisation

Owners manual

Bedienungsanleitung

Libretto d'istruzioni

Manual de utilización

Gebruikershandleiding

Instruktionsbok

Manual de proprietário

Käyttöohjekirja

Instruktionsbog

50 cm3

771155 ed2_motul.pmd 18/03/2009, 10:10 1Downloaded from www.Manualslib.com manuals search engine

FA

H

G

KCB

E

LJI

O

771155 ed2_motul.pmd 18/03/2009, 10:10 2Downloaded from www.Manualslib.com manuals search engine

FACB

EH

JI

LD

M

N

KO

771155 ed2_motul.pmd 18/03/2009, 10:10 3Downloaded from www.Manualslib.com manuals search engine

34

562

7

8

9345

2

7

101

1

213

3 4564

5

6

79

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

1011	
1213	
61A	
BCC	
771155 ed2_motul.pmd 18/03/2009, 10:10 4	Downloaded from www.Manualslib.com manuals search engine
O1415	
16	
17	
19	
2018	
D E	
771155 ed2_motul.pmd 18/03/2009, 10:10 5	Downloaded from www.Manualslib.com manuals search engine
20mm21	
23	
2422	
25	
F G28	
29	
28	
302627	
771155 ed2_motul.pmd 18/03/2009, 10:10 6	Downloaded from www.Manualslib.com manuals search engine
31	
32	
33	
34	
3536	
37	
38	
39	
40 40	
771155 ed2_motul.pmd 18/03/2009, 10:10 7	Downloaded from www.Manualslib.com manuals search engine
FR Sommaire	
Informations	8-9
Equipements	10
Tableau de bord	10
Tableau de bord électronique	10-11
Commutateur	1 1
Conduite	1 1
Mise en marche du moteur	12
Carburant / huile	12
Freins	12
Antivol	13
Batterie / Fusible	13
Pneumatiques	13
Eclairage / signalisation	14
Transpondeur	15

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Caractéristiques	15
GB Information	
Information	16-17
Equipment	18
Instrument panel	18
Electronic instrument panel	18-19
Switch	19
Driving	19
Starting the engine	20
Petrol / Oil	20
Braking	20
Integrated	21
Battery / Fuse	21
Tyres	21
Lighting / Signalling	22
Transponder	23
Specifications	23
DE Inhalt	
Informationen	24-25
Ausrüstung	26
Instrumententafel	26
Elektronische Instrumenteneinheit	26-27
Schalter	27
Fahren	27
Anlassen des Motors	28
Kraftstoff / Öle	28
Bremsen	28
Diebstahlschutz	29
Batterie / Sicherungen	29
Reifen	29
Beleuchtung / Anzeigen	30
Wegfahrsperre	31
Technische Daten	
31IT Sommario	
Informazioni	32-33
Equipaggiamenti	34
Quattro strumenti	34
Display elettronico	34-35
Interruttore	35
Guida	35
Messa in moto	36
Carburante / Olio	36
Freno	36
Antifurto	37
Batteria / Fusibile	37
Pneumatici	37
Illuminazione / Segnalazioni	38
Transponder	39
Caratteristiche	39
ES Sumario	

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Informaciones	40-41
Equipamiento	42
Panel de instrumentos	42
Visualizador electrónico	42-43
Conmutador	43
Conducción	43
Puesta en marcha del motor	44
Carburante / Aceite	44
Frenos	44
Bateria / Fusible	45
Alumbrado / Señalización	46
Transpondeur	47
Características	47
NL Inhoud	
Informatie	48-49
Uitrusting	50
Cockpit	50
Elektronisch display	50-51
Schakelaar	51
Besturing	51
Starten van de motor	52
Benzine / Olie	52
Remmen	52
Accu / De zekering	53
Verlichting / Lichtsignalen	54
Technische gegevens	55
771155 ed2_motul.pmd 18/03/2009, 10:10 8Downloaded from www.Manualslib.com manuals search engine	
FrançaisEnglishDeutschItalianoEspañolNesderlandsSwedenPortugueseFinnishDanish	
7SE Innehållsförteckning	
Allmänna informationer	56-57
Utrustning	58
Instrumentpanel	58
Elektronisk display	58-59
Omkastare	59
Körning	59
Start av motorn	60
Bränsle / Olje	60
Bromsar	60
Stöldskyddsanordning	61
Däck	61
Belysning / Signalering	62
Batteri / Säkring	61

Translation:

User manual

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Owners manual
Operating instructions
Instruction booklet
User manual
User guide
Instruction manual
Owner's manual
User manual
Instruction manual

50 cm3

FR Contents

Information	8-9
Equipment	10
Dashboard	10
Electronic dashboard	10-11
Switch	1 1
Driving	1 1
Starting the engine	12
Fuel / oil	12
Brakes	12
Theft protection	13
Battery / Fuse	13
Tires	13
Lighting / signaling	14
Transponder	15
Specifications	15

GB Information

Information	16-17
Equipment	18
Instrument panel	18
Electronic instrument panel	18-19
Switch	19
Driving	19
Starting the engine	20
Petrol / Oil	20
Braking	20
Integrated	21
Battery / Fuse	21
Tyres	21
Lighting / Signalling	22
Transponder	23
Specifications	23

DE Content

Information	24-25
-------------------	-------

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Equipment	26
Instrument panel	26
Electronic instrument unit	26-27
Switch	27
Driving	27
Starting the engine	28
Fuel / Oils	28
Brakes	28
Theft protection	29
Battery / Fuses	29
Reifen	29
Lighting / Indicators	30
Immobilizer	31
Technical specifications	31
IT Summary	
Information	32-33
Equipment	34
Four instruments	34
Electronic display	34-35
Switch	35
Driving	35
Starting	36
Fuel / Oil	36
Brake	36
Anti-theft	37
Battery / Fuse	37
Pneumatici	37
Lighting / Signals	38
Transponder	39
Features	39
ES Summary	
Information	40-41
Equipment	42
Instrument panel	42
Electronic display	42-43
Switch	43
Driving	43
Starting the engine	44
Fuel / Oil	44
Brakes	44
Anti-theft	45
Battery / Fuse	45
Tires	45
Lighting / Signaling	46
Transponder	47
Features	47

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

NL Content

Information	48-49
Equipment	50
Cockpit	50
Electronic display	50-51
Switch	51
Steering	51
Starting the engine	52
Petrol / Oil	52
Brakes	52
Anti-theft system	53
Battery / The fuse	53
Banden	53
Lighting / Light signals	54
Transponder	55
Technical data	55

7SE Contents

General information	56-57
Equipment	58
Instrument panel	58
Electronic display	58-59
Switch	59
Driving	59
Starting the engine	60
Fuel / Oil	60
Brakes	60
Theft protection device	61
Battery / Fuse	61
Tires	61
Lighting / Signaling	62