

## Benelli - c.Racer-2011

Manuale Uso e Manutenzione - Owners Manual  
Manuel d'Utilisateur - Benutzer Handbuch - Manual Usuario  
Uso e Manutenzione Manual 2011

3
4
5 INDEX GENERAL INFORMATION
7
8
9
11
11
11
12
14
15
15
18
19
20
21
21
22
23
25
27
29
30
31
32
32
1
1.1
1.2
2
2.1
2.1.1
2.1.2
2.1.3
2.1.4
2.1.5
2.1.6

2.1.7

2.2

3

3.1

3.2

3.3

3.4

3.5

3.6

3.7

3.7.1

4

4.1 General Information

Symbols

Identification Data

Safety Information

Safety

Motorcycle Modification and Suspension Customization

General Safety Rules

Vehicle Load

Use of the Vehicle in Competitions

Tips for Safe Riding

Protective Clothing

Theft Prevention Tips

Safety - Visual and Acoustic Signals

Controls and Instruments

Control and Instrument Positions

Side Stand

Left Handlebar Controls

Right Handlebar Controls

Ignition Switch and Steering Lock

Gearshift Control

Instrumentation and Indicator Lights

Multifunction Display

Use

Motorcycle Use

33

35

36

39

40

41

41

42

44

45	
46	
46	
48	
49	
49	
49	
50	
50	
51	
52	
53	
554.2	
4.3	
4.4	
4.5	
4.6	
4.7	
4.7.1	
4.8	
4.9	
4.10	
5	
5.1	
5.2	
5.3	
5.3.1	
5.3.2	
5.3.3	
5.3.4	
5.3.5	
5.3.6	
5.4	
5.4.1	Checks Before Use
	Run-in
	Display Function Selection
	Clock Adjustment
	Motorcycle Stop
	Rider Seat Removal
	Passenger Seat Removal
	Refueling
	Engine Starting
	Improving Our Riding Skills
	Adjustments
	List of Adjustments

Adjustment Summary Table  
Adjustments That Can Be Made by the User  
Front Brake Lever Adjustment  
Rearview Mirror Adjustment  
Headlight Adjustment  
Engine Idle Speed Adjustment  
Headlight Bulb Replacement  
Clutch Lever Adjustment  
Rear Suspension Adjustment  
Rear Suspension Spring Preload Adjustment

## 6 INDEX GENERAL INFORMATION

55  
56  
57  
57  
58  
60  
60  
70  
71  
72  
74  
75  
77  
78  
80  
825.4.2  
5.5  
5.5.1  
5.5.2  
5.5.36  
6.1  
6.2  
6.3  
6.3.1  
6.4  
6.4.1  
6.5  
6.6  
6.7  
6.7.1 Hydraulic Braking Device Adjustment in Rear Suspension Extension  
Front Suspension Adjustment  
Front Suspension Spring Preload Adjustment  
Hydraulic Braking Device Adjustment in Front Suspension Extension  
Hydraulic Braking Device Adjustment in Front Suspension Compression

Maintenance

Maintenance and Inspection Tables

Lubricant and Fluid Table

Engine Oil - Level Check

Engine Oil - Level Restoration

Coolant - Expansion Tank Level Check

Coolant - Level Restoration

Brake Pads - Wear Check

Brake Fluid - Level Check

Tires and Rims - Check

Rim and Wheel Check

83

84

84

85

86

88

89

91

92

93

936.8

6.8.1

6.8.2

6.9

6.10

6.11

6.12

6.13

6.14

7

7.1Chain - Cleaning and Lubrication Check

Cleaning

Lubrication

Idle Speed - Check

Fuse Replacement

Battery

Motorcycle Cleaning

Prolonged Stop Period

Power Control

Technical Information

Technical Data

7Dear Customer,

We invite you to read this Manual before using your new Café Racer 1130.

It contains important information for safe use of the motorcycle and for maintaining its efficiency.

Remember, however, that the CAFÉ RACER 1130 is a high-performance motorcycle that requires careful and skillful driving.

Refrain from pushing the motorcycle to its limits unless you are more than sure of your ability to manage the vehicle and, in any case, when traveling on public roads or roads open to the public, strictly respect the rules of the Highway Code.

Always remember to wear an approved helmet, of your size, and always correctly fastened.

We also advise you to always wear adequate protective clothing.

### 1 GENERAL INFORMATION GENERAL INFORMATION

To make the information of particular importance clearer and immediately readable, we have used the following symbols:

**Danger** Warns that there is a serious intrinsic danger that could lead to personal injury and even fatal accidents if the warnings provided are not followed.

**Warning** Warns that there is a danger that can cause personal injury and even fatal accidents if the warnings provided are not followed.

**Caution** Reminds you of a safety practice to follow or an unsafe activity to avoid if you don't want to risk personal injury or damage to the motorcycle.

Benelli Q.J. s.r.l. reserves the right to modify its products and this Manual at any time.

If you find any discrepancies between what is reported in the Manual and the specific configuration of your Motorcycle, do not hesitate to download the updated version of the Manual from the website [www.benelli.com](http://www.benelli.com).

#### 1.1 SYMBOLS GENERAL INFORMATION

91. Chassis serial number

2. Engine serial number

3. Approval data

We recommend that you note the main data in the spaces below.

Chassis Number ZBN \_ \_ \_ \_ \_

Engine Number \_ \_ \_ \_ \_

Color Code \_ \_ \_ \_ \_

Key Number \_ \_ \_ \_ \_

#### 1.2 IDENTIFICATION DATA

2) engine serial number GENERAL INFORMATION

xxxxxxxxxxx

xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx

xxxxxxxxxxx

1) chassis serial number

3) approval data

10Key identification number

Labels

Color code

Motorcycle Identification

The motorcycle is identified by the chassis serial number.

Key Identification

A key is provided in four copies to be used both for starting and for operating all locks.

Keep the spare copies in a safe place. Knowing the key identification number is essential if it is necessary to request a duplicate replacement key.

Color Combination Identification

The color code is essential for ordering body spare parts.

This code can be read on the labels located under the seat.

Spare parts order

To order spare parts, in addition to the chassis serial number, it may be necessary to indicate the engine serial number, the color code and the key identification number.

## 1.2 IDENTIFICATION DATA