

## Benelli - Trek 11-7-11

Owner's Manual - Usage and Maintenance Manual

Manuel d'Utilisateur - Benutzer Handbuch - Manual Usuario

Usage and Maintenance Manual 2011

3

4

5 INDEX GENERAL INFORMATION

7

89

11

11

11

1214161719202122222324262830

31

3233331

1.1

1.2

2

2.1

2.1.1

2.1.2

2.1.3

2.1.4

2.1.5

2.1.6

2.1.7

2.2

3

3.1

3.2

3.3

3.4

3.5

3.6

3.7

3.7.1

4

4.1 General Information

Symbols

Identification Data

Safety Information

Safety

# BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Motorcycle Modification and Suspension Customization

General Safety Rules

Vehicle Load

Vehicle Use in Competitions

Tips for Safe Riding

Protective Clothing

Theft Prevention Tips

Safety - Visual and Acoustic Signals

Controls and Instruments

Controls and Instruments Position

Side Stand

Left Handlebar Controls

Right Handlebar Controls

Ignition Switch and Steering Lock

Gear Shift Control

Instrumentation and Warning Lights

Multifunction Display

Use

Motorcycle Use34

36

37

40

41

42

43

45

46

47

47

49

50

50

50

51

51

52

53

53

544.2

4.3

4.4

4.5

4.6

4.7

4.8

|       |   |
|-------|---|
| 4.9   |   |
| 4.10  |   |
| 5     |   |
| 5.1   |   |
| 5.2   |   |
| 5.3   |   |
| 5.3.1 |   |
| 5.3.2 |   |
| 5.3.3 |   |
| 5.3.4 |   |
| 5.3.5 |   |
| 5.3.6 |   |
| 5.3.7 |   |
| 5.3.8 | Checks Before Use                           |
|       | Break-in Period                             |
|       | Display Function Selection                  |
|       | Clock Adjustment                            |
|       | Motorcycle Parking                          |
|       | Rider Seat Removal                          |
|       | Fueling                                     |
|       | Engine Starting                             |
|       | Improving Our Riding Skills                 |
|       | Adjustments                                 |
|       | Adjustment List                             |
|       | Adjustment Summary Table                    |
|       | Adjustments That Can Be Made by the User    |
|       | Front Brake Lever Adjustment                |
|       | Rearview Mirror Adjustment                  |
|       | Headlight Adjustment                        |
|       | Engine Idle Speed Adjustment                |
|       | Headlight Bulb Replacement                  |
|       | Clutch Lever Adjustment only for Tre 899 K  |
|       | Clutch Lever Adjustment only for Tre 1130 K |
|       | Fairing Adjustment                          |
| 6     | INDEX GENERAL INFORMATION                   |
| 55    |   |
| 57    |   |
| 57    |   |
| 59    |   |
| 60    |   |
| 60    |   |
| 61    |   |
| 62    |   |
| 62    |   |
| 72    |   |

|  |  |
|--|--|
| 73   |  |
| 74   |  |
| 76   |  |
| 77   |  |
| 79   |  |
| 805.4  |  |
| 5.4.1  |  |
| 5.4.2  |  |
| 5.5  |  |
| 5.5.1  |  |
| 5.5.2  |  |
| 5.5.3  |  |
| 6  |  |
| 6.1  |  |
| 6.2  |  |
| 6.3  |  |
| 6.3.1  |  |
| 6.4  |  |
| 6.4.1  |  |
| 6.5  |  |
| 6.6Rear Suspension Adjustment                                    |  |
| Rear Suspension Spring Preload Adjustment                        |  |
| Rear Suspension Rebound Damping Hydraulic Device Adjustment      |  |
| Front Suspension Adjustment                                      |  |
| Front Suspension Spring Preload Adjustment                       |  |
| Front Suspension Rebound Damping Hydraulic Device Adjustment     |  |
| Front Suspension Compression Damping Hydraulic Device Adjustment |  |
| Maintenance  |  |
| Maintenance and Inspection Schedules                             |  |
| Lubricants and Fluids Table                                      |  |
| Engine Oil - Level Check   |  |
| Engine Oil - Level Restoration                                   |  |
| Coolant - Reservoir Level Check                                  |  |
| Coolant - Level Restoration                                      |  |
| Brake Pads - Wear Check  |  |
| Brake Fluid - Level Check82                                      |  |
| 84   |  |
| 85   |  |
| 86   |  |
| 86   |  |
| 87   |  |
| 88   |  |
| 90   |  |
| 91   |  |
| 93   |  |

94

95

95

101

1016.7

6.7.1

6.8

6.8.1

6.8.2

6.9

6.10

6.11

6.12

6.13

6.14

7

7.1

7

7.2Tires and Wheels - Inspection

Wheels Inspection and Wheel

Chain - Inspection, Cleaning and Lubrication

Cleaning

Lubrication

Idle Speed - Check

Fuses Replacement

Battery

Motorcycle Cleaning

Extended Parking Period

Power Control

Technical Information Tre 899 K

Technical Data

Technical Information Tre 1130 K

Technical Data

7Dear Customer,

We invite you to read this Manual before using your new Benelli Tre K.

It contains important information for safe motorcycle use and its efficient maintenance.

Remember, however, that the BENELLI TRE K is a high-performance motorcycle that requires careful and skillful riding.

Refrain from pushing the motorcycle to its limit if you are not more than sure of your ability to manage the vehicle and, in any case,

when driving on public roads or roads open to the public, scrupulously respect the rules of the Road Code.

Always remember to wear an approved helmet, of your size, and always correctly fastened.

We also advise you to always wear adequate protective clothing.

## 1 GENERAL INFORMATION

### GENERAL INFORMATION

To make the information of particular importance clearer and easier to read, we have used the following symbols:

**Danger** Warns that there is a serious intrinsic hazard that could lead to personal injury and fatal accidents if the warnings provided are not followed.

**Warning** Warns that there is a hazard that can cause personal injury and fatal accidents if the warnings provided are not followed.

**Caution** Reminds you of a safety practice to follow or an unsafe activity to avoid if you do not want to run the risk of personal injury or damage to the motorcycle.

Benelli Q.J. s.r.l. reserves the right to modify its products and this Manual at any time.

If you find any discrepancies between what is stated in the Manual and the specific set-up of your Motorcycle, do not hesitate to download

the updated version of the Manual from the website [www.benelli.com](http://www.benelli.com).

### 1.1 SYMBOLS

#### GENERAL INFORMATION

91. Chassis serial number

2. Engine serial number

3. Approval data

It is advisable to note the main data in the spaces below.

Chassis Number ZBN \_\_\_\_\_

Engine Number \_\_\_\_\_

Color Code \_\_\_\_\_

Key Number \_\_\_\_\_

### 1.2 IDENTIFICATION DATA

2) engine serial number

#### GENERAL INFORMATION

xxxxxxxxxxxx

xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx

xxxxxxxxxxxx

1) chassis serial number

3) approval data

10key identification number

Nameplates

color code

Motorcycle identification

The motorcycle is identified by the frame serial number.

Key identification

A key is provided in four copies to be used both for starting and for operating all locks.

Keep spare copies in a safe place. Knowing the key identification number is essential if it is necessary to request a duplicate of the spare key.

Color combination identification

The color code is essential for ordering body spare parts.

This code can be read on the nameplates located under the seat.

## Spare parts order

To order spare parts, in addition to the frame serial number, it may be necessary to indicate the engine serial number, the color code and the key identification number.

## GENERAL INFORMATION

### 1.2 IDENTIFICATION DATA