

Husaberg - Husaberg__04_General_Service_Manual

REPAIR MANUAL 04

Edition 2004

PREFACE

This manual contains detailed instructions on repairing the engine. It was prepared according to the state of the art for this model series. We reserve the right to make modifications based on technical progress without making the respective corrections in this repair manual.

This manual does not contain a description of general shop or working methods. It does not include safety rules generally observed in workshops and is based on the assumption that the work is performed by a mechanic who has completed his vocational training.

Please read the entire manual before starting to work.

WARNING: failing to observe these instructions can be dangerous to life and limb.

CAUTION: failing to observe these instructions may damage the motorcycle/engine components or impair the motorcycle's traffic safety.

NOTE: provides useful information.

Only use ORIGINAL HUSABERG SPARE PARTS if parts need to be replaced.

The engine will only continue to operate safely if the prescribed service work is performed regularly and professionally.

Subject to changes in construction and design.

Cby HUSABERG All rights reserved

INDEX

A
B
C
D
E
F
G
H
I
J
K
L
M

NGENERAL INFORMATION

DISMOUNTING AND MOUNTING THE ENGINE

DISASSEMBLING THE ENGINE

SERVICING THE INDIVIDUAL PARTS

ASSEMBLING THE ENGINE

ELECTRIC SYSTEM	
FUEL SYSTEM	
TROUBLESHOOTING	
TECHNICAL SPECIFICATIONS	
PERIODIC MAINTENANCE SCHEDULE	
WIRING DIAGRAMS	
TABLE OF CONTENTS	

GENERAL INFORMATION

Oil circuit	A1
Engine oil	A1
Checking the oil level	A1
Changing the engine oil	A2
Cleaning the oil screen	A2
Changing the oil filter	A3
Checking the oil level in the hydraulic clutch	A4
Bleeding the clutch	A4
Cleaning	A5
Preservation for winter operation	A5
Storage	A5
Special tools	A6

DISMOUNTING AND MOUNTING THE ENGINE

Dismounting the engine	B1
Mounting the engine	B5
Bleeding the cooling system	B9
Adjusting the decompression cable	B9
Adjusting the throttle cable	B9

DISASSEMBLING THE ENGINE

Blocking the engine	C1
Removing the rotor	C2
Removing the pressure relief valve	C2
Removing the clutch	C3
Removing inner clutch hub	C4
Removing primary pinion and the idler shaft gear	C4
Removing the oil pump	C5
Removing the chain tensioner	C6
Separating the timing chain	C6
Removing the cylinder head	C7
Separating the housing	C7
Removing the crankshaft	C8
Removing the transmission	C8
Removing the idler shaft	C9

SERVICING THE INDIVIDUAL PARTS

Important	D1
Left housing half	D1
Right housing half	D2
Pressure relief valve	D3
Clutch cover	D3
Crankshaft	D4
Press out the crank pin	D5
Press in the crank pin	D6
Checking the crankshaft journal	D7
Outer dimension of the crankshaft webs	D7
Balancing the axial clearance of the crankshaft ..	D8
Nikasil cylinder coating	D9
Measuring the piston and cylinder liner, determining the piston mounting clearance	D9
Checking the piston	D10
Checking the piston ring end gap	D10
Checking the oil pump for wear	D10
Cylinder head top section	D11
Cylinder head	D12
Camshaft	D14
Timing chain tensioner	D15
Timing train	D15
Checking the clutch for wear	D16
Checking the kickstarter for wear	D17
Shift mechanism	D18
Assembling the main shaft (four-speed)	D19
Assembling the main shaft (six-speed)	D20
Assembling the countershaft (four/six-speed) ..	D21
Starter drive	D22
Checking the freewheel	D22
Checking the freewheel hub	D22

ASSEMBLING THE ENGINE

Mounting the idler shaft	E1
Mounting the crankshaft	E2
Mounting the cylinder head	E4
Mounting the timing chain	E5
Mounting the timing chain tensioner	E7
Adjusting the valve clearance	E7
Mounting the oil pump	E8
Mounting the shift mechanism	E8
Mounting the kickstarter shaft	E9
Mounting the clutch	E9
Mounting the clutch cover	E11
Mounting the pressure relief valve	E13

Mounting rotor and pick upE13

ELECTRIC SYSTEM

Checking for loss of currentF1
Dismounting/mounting the batteryF1
Charging the batteryF1
Filling the batteryF2
Checking the starterF2
Checking the starter relayF3
Checking the main fuseF3
Checking the voltage regulatorF4
Kokusan 4K3B dynamic generator valuesF4
Troubleshooting in the ignition systemF5
CDI unitF6
Checking the ignition coilF6
Ignition systemF7
Checking the stator and pulse generatorF7
Replacing the stator in FC models (Kokusan 4K-3A) .. F7
Replacing the stator in FE and FS models (Kokusan 4K-3B) . .F7
Static ignition values Kokusan 4K-3A/BF8
Static generator values Kokusan 4K3BF10

FUEL SYSTEM

KEIHIN FCR-MX 39/41G1
Disassembling the carburetorG2
Choke slide and hot start knobG5
Accelerator pumpG5
Jet needleG5
Float needle valveG5
Throttle slideG6
Assembling the carburetorG6
Adjusting the throttle sensor positionG10
Checking the throttle sensorG11
Dismounting and mounting the throttle sensor ..G11
Adjusting the idleG12
Checking/adjusting the float heightG13

TROUBLESHOOTING

TroubleshootingH1

TECHNICAL SPECIFICATIONS

Engine 450, 501I1
Carburetor 450, 501I1
Engine 550, 650I2
Carburetor 550, 650I2

Chassis	I3
Engine torques	I4
Chassis torques	I5
Mounting clearances, engine wear limits	I6

PERIODIC MAINTENANCE SCHEDULE

FC 450, 550/4	J1
FE 450 - 650e/6, FS 450, 650e/6	J2
Additional work - driver	J3
Additional work - workshop	J4

WIRING DIAGRAMS

FC models	K1
FE models	K2
FE	