

Peugeot - tweet_workshop_manual

Sales division
Technical network leadership
WORKSHOP MANUAL

Downloaded from www.Manualslib.com manuals search engine
Downloaded from www.Manualslib.com manuals search engine

TABLE OF CONTENTS

Reproduction or translation, even partial, is forbidden without the written consent of Peugeot Motorcycles

TABLE OF CONTENTS	
TABLE OF CONTENTS.....	1
PRODUCTS DANGER SYMBOLS USED.....	4
CHARACTERISTICS.....	6
Engine.....	6
Capacities.....	6
Chassis.....	7
Dimensions and weight.....	7
Tyres.....	7
Brakes.....	8
SERVICE SCHEDULE AND COMMISSIONING.....	9
Battery preparation (Except battery without maintenance)*.....	11
New machine preparation.....	11
SPECIAL IMPORTANT POINTS.....	12
TIGHTENING TORQUES.....	13
Engine part.....	13
Body panels.....	13
Cycle part.....	14
Standard.....	14
SPECIAL TOOLS.....	15
Standard tools.....	16
LOCATION OF COMPONENTS.....	17
BODY PANELS.....	18
Location of body components.....	18
Body component sequence of disassembly.....	19
Removal of the storage compartment.....	20
Removal of the rear cover assembly.....	20
Removal of the front top shield panel.....	21
Removal of the front lower shield pannel.....	21
Removal of the rear shield panel.....	22
Removal of the footboard.....	23

BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Removal of handlebar fairing.....23

Downloaded from www.Manualslib.com manuals search engine

TABLE OF CONTENTS

Reproduction or translation, even partial, is forbidden without the written consent of Peugeot Motorcycles

SERVICE OPERATIONS.....	24
Changing the engine oil.....	24
Draining the relay box.....	25
Replacing the air filter.....	26
Removal of the spark plug.....	27
Idle setting.....	27
Transmission.....	27
Removal of the drive pulley.....	28
Removal of the driven pulley.....	28
Changing the drive pulley bearings.....	29
Checking the drive belt.....	29
Checking the thickness of the clutch linings.....	30
Removal of the clutch lining assembly.....	30
Refitting the clutch lining assembly.....	31
Installing the valve clearance.....	32
Checking the valve clearance.....	33
Brake pad wear.....	34
Replacing the brake pads.....	34
Checking the brake fluid level.....	36
Rear brake linings 50 cc.....	36
Removal of the fuel filter.....	38
Draining the front fork.....	39
STEERING/FORK.....	41
Changing the front fork seals.....	41
The fork and its components.....	42
Removal of the fork.....	45
Replacing the bearings of the steering system.....	46
Steering headset cups.....	46
Fork cone.....	46
Installing the fork.....	47
Steering system tightening method.....	47
Downloaded from www.Manualslib.com manuals search engine	