

## Peugeot - vclic\_workshop\_manual

Sales division

Technical network leadership

WORKSHOP MANUAL

Downloaded from [www.Manualslib.com](http://www.Manualslib.com) manuals search engine

Workshop manual

Technical network leadership Reproduction or translation, even partial, is forbidden without the written consent of

Peugeot Motocycles Downloaded from [www.Manualslib.com](http://www.Manualslib.com) manuals search engine

TABLE OF CONTENTS

TABLE OF CONTENTS.....	1
CHARACTERISTICS.....	3
Engine.....	3
Capacities.....	3
Chassis.....	4
Dimensions and weight.....	4
Tyres.....	4
Brakes.....	5
SERVICE SCHEDULE AND COMMISSIONING.....	6
Check.....	6
Change.....	6
Check and lubricate.....	6
Test machine.....	6
Battery preparation (Except battery without maintenance)*.....	6
Checks before handing over to the customer.....	7
SPECIAL IMPORTANT POINTS.....	8
Oil and fuel.....	8
Starting up after overhauling the engine.....	8
TIGHTENING TORQUES.....	9
Engine part.....	9
Body panels.....	9
Cycle part.....	10
Standard.....	10
INSTRUMENT PANEL.....	11
Analog functions (hands).....	11
ELECTRICITY.....	12
Fuses and energy distribution.....	12
Location of components.....	12
BODY PANELS.....	13
Location of body components.....	13
Body component sequence of disassembly.....	14
Removal of the storage compartment.....	15
Removal of the grab handle.....	15

# BL Motorcycles Ltd

Professional Workshop Manual - English Translation

Removal of the central cover panel.....	15
Removal of the lower side fairings.....	16
Removal of the side fairings.....	16
Removal of the footboard.....	16
Removal of the taillight.....	17

Downloaded from  
www.Manualslib.com manuals search engine

## TABLE OF CONTENTS

2

Reproduction or translation, even partial, is forbidden without the written consent of Peugeot Motorcycles  
Removal of the splash guard.....17

Removal of the front top cover panel.....	18
Removal of the front mudguard.....	19
Removal of the front shield panel.....	19
Removal of the rear shield panel.....	20
Removal of the under body panel.....	20
Removal of a headlight bulb.....	21
Removal of a taillight bulb.....	21
Removal of a turnsignal light.....	22
WORKING ON THE ENGINE WITHOUT REMOVING THE ENGINE.....	23
Removal of the air filter foam.....	23
Removal of the transmission filter.....	23
Removal of the fuel filter.....	23
Removal of the pulsair filter.....	24
Removal of the pulsair reed valve.....	24
Removal of the spark plug.....	24
Removal of the carburettor.....	24
Installing the valve clearance.....	25
Removal of the exhaust system.....	25
Removal of the cylinder head.....	26
Removal of the cylinder / piston.....	26
MISCELLANEOUS OPERATIONS.....	27
Removal of the engine.....	27
Removal of the battery.....	27
Removal of the starter motor relay.....	