


## SERVICE POINTS OF REMOVAL

### 1. REMOVAL OF QUARTER WINDOW GUIDE PLATE

- (1) Remove the two rivets attaching the hardtop weatherstrip and the quarter window guide plate to the hardtop using a 1/8" diameter drill bit.
- (2) Remove the two bolts attaching the quarter window guide plate to the hardtop.
- (3) Separate the quarter window guide plate from the hardtop.



### 2. REMOVAL OF REAR RAIL INNER WEATHERSTRIP

Using a 1/8" diameter drill bit drill out the rivets.

## SERVICE POINTS OF INSTALLATION

### 2. INSTALLATION OF REAR RAIL INNER WEATHERSTRIP

**Rivet: All aluminum 1/8" x .250 in. Dome head**

### 1. INSTALLATION OF QUARTER WINDOW GUIDE PLATE

- (1) Install the guide plate to the hardtop.
- (2) Align the guide plate to the hardtop with the rivet holes and install the rivets.

**Rivet: All aluminum 1/8" x .625 in. Dome head**

- (3) Install the bolts to attach the guide plate to the hardtop.

**Standard value: 9 - 12 Nm (80 - 106 in.lb.)**

# WINDSHIELD HEADER POWER LATCH SYSTEM REMOVAL AND INSTALLATION

**NOTE**  
Hardtop must be open before removal.


**CAUTION:**  
Adjustment or replacement of these components requires that the hardtop ECU be run through Auto-configuration (Refer to Diagnostics and Testing, in this section).

## Pre-removal Operation

- Removal of Header Garnish (Refer to GROUP 52, in this Manual.)

## Post-installation Operation

- Adjustment of Header Latch System (Refer to SERVICE ADJUSTMENT PROCEDURES, in this section.)
- Installation of Header Garnish (Refer to GROUP 52, in this Manual.)



## Latch housing removal steps

1. Drive motor harness connector
2. Switch harness connector
3. Switch harness connector
4. Bolt
5. Cotter pin
6. Clevis pin
8. Latch housing

## Latch drive motor removal steps

1. Drive motor harness connector
2. Switch harness connector
3. Switch harness connector
4. Bolt
5. Cotter pin
6. Clevis pin
8. Latch housing
9. Bolt

## Latch removal steps


15. Drive motor
10. Switch harness connector
11. Nut
12. Screw
13. Latch
14. Clip

## Header latch garnish removal step

16. Header latch garnish

## Actuator removal steps

7. Actuator
14. Clip



## INSPECTION

### DRIVE MOTOR

1. Connect the battery directly to the motor connector and check that the motor spins freely.
2. Reverse the polarity and check that the motor spins freely in the opposite direction.

**Standard value:** Motor spins freely without ratcheting, clicking or whining.

**ON-CAR LATCH INSPECTION**


1. Open the retractable hardtop.
2. Remove the left and right header latch garnishes.
3. Inspect the ramp surface of both latches for wear or indentation.

**Standard value: Ramp surface flat with no sign of wear penetrating over 1 mm (.039 in.), or cracks to the plastic covering, as shown in the illustration.**

**NOTE**



The header latch ramp portion is designed to have some free-play vertically and horizontally within the latch body, and may vary. Excessive play can be compensated for by shimming down the latch body from the windshield header (refer to **SERVICE ADJUSTMENT PROCEDURES**, in this section).

4. Reinstall both header latch garnishes.



# WINDSHIELD HEADER POWER LATCH SYSTEM


## DISASSEMBLY AND REASSEMBLY



### Disassembly steps

1. Position switch
2. Latch switch
3. Unlatch switch

## HARDTOP AND HARD TONNEAU CONTROL SWITCH REMOVAL AND INSTALLATION



### Removal step

1. Switch

## INSPECTION

### INSPECTION OF HARDTOP AND HARD TONNEAU CONTROL SWITCH

#### NOTE


- (1) When either the hardtop or hard tonneau "CLOSE"/"OPEN" switch is pressed, and the hardtop or hard tonneau LED blinks, and the chime sounds twice the normal rate, this may indicate there is a system malfunction.
- (2) The hardtop ECU will not operate properly, or at all, if battery voltage is less than 10 volts or higher than 16 volts.

#### 1. ON-CAR INSPECTION

- Set the parking brake.
- Make sure the gear selector lever is in "P" (PARK) (A/T), or neutral (M/T).
- Start the engine.

- (1) Press the hardtop switch on the "OPEN" side.

With hardtop initially fully open:



- No response from hardtop system should be noticed when the switch is pressed.

With hardtop initially fully closed:

- The LED to the left of the switch should blink, and the chime sound at a rate of 1 cycle per second. The quarter windows and door windows should open, and the header latches should unlatch.
- If the switch LED appears to be working, but the hardtop system does not respond to the switch inputs, refer to **Diagnostics and Testing** in this section.
- If the switch LED does not appear to be working, and the hardtop system does react to the switch inputs, perform the switch inspection in Step 2.


(2) Press the hardtop switch on the “CLOSED” side.

With hardtop initially fully closed:

- No response should be noticed when the switch is pressed.

With hardtop initially fully open:

- The LED to the left of the switch should blink, and the chime sound at a rate of 1 cycle per second. And, the tonneau latches release.
- If the switch LED appears to be working, but the hardtop system does not respond to the switch inputs, see **Diagnostics and Testing** in this section.
- If the switch LED does not appear to be working, and the hardtop system does react to the switch inputs, perform the switch inspection in Step 2.



(3) Press the hard tonneau switch on the “CLOSE” side.

With hard tonneau initially fully closed:

- No response should be noticed when the switch is pressed.

With hard tonneau initially fully open:

- The LED to the right of the switch should blink, and the chime sound at a rate of 1 cycle per second. And, the tonneau begin to close.
- If the switch LED appears to be working, but hardtop system does not respond to the switch inputs, refer to **Diagnostics and Testing** in this section.
- If the switch LED does not appear to be working, and the hardtop system does react to the switch inputs, perform the switch inspection in Step 2.

(4) Press the hard tonneau switch on the “OPEN” side.

With hard tonneau initially fully opened:


- No response from hardtop system should be noticed when the switch is pressed.

**NOTE**

Depending on the position of the hard tonneau, the tonneau latches may release again, and the tonneau may continue to open.

With hard tonneau initially fully closed:

- The LED to the right of the switch should blink, and the chime sound at a rate of 1 cycle per second. And, the hard tonneau latches should release.
- If the switch LED appears to be working, but the hardtop system does not respond to the switch inputs, refer to **Diagnostics and Testing** in this section.
- If the switch LED does not appear to be working, and the hardtop system does react to the switch inputs, perform the switch inspection in Step 2.

**2. OFF-CAR INSPECTION**

Operate the switch to check the continuity between the terminals.

Terminal		OPEN	CLOSE
Switch position			
Hardtop Switch	3	○	
	4	○	○
	11		○
Hard tonneau switch	4	○	○
	9	○	○
	10	○	

Switch Illumination (incandescent bulbs)	1	○
	5	○

**NOTE**


○—○ indicates that there is continuity between the terminals.

**INSPECTION OF SWITCH LEDs**

The switch LEDs must be tested using the **Pinpoint Tests** in **Diagnostics and Testing** in this section.

## CHIME MODULE AND TURN-SIGNAL AND HAZARD FLASHER UNIT (SPYDER-UNIQUE RELOCATION)

### REMOVAL AND INSTALLATION




#### Removal step

1. Chime module



## OBJECT-IN-TRUNK SENSOR REMOVAL AND INSTALLATION



### Removal steps

1. Connection
2. Object-in-trunk sensor

## INSPECTION

### INSPECTION OF OBJECT-IN-TRUNK SENSOR

#### NOTE


- (1) Check under the object-in-trunk sensor for items that could be causing the backing board to bow (this will activate the sensor). Look for items in and around the tool trays that may be higher than the tray; items on top of the original equipment spare tire; or the spare tire itself that it is properly placed in the tire well. If these are noted, remove or rearrange them.
- (2) Check the sensor's harness connector pins that they are not bent or damaged, then reconnect it.
  - Try operating the hardtop system again. If the hardtop system still fails to operate, refer to the VISUAL INSPECTION below.

#### 1. VISUAL INSPECTION

Inspect for physical damage to the carpet covering, sensor substrate, and the backing board.


#### Standard value: No visible evidence of damage

- Replace the sensor if it is damaged.
- If there is no apparent physical damage, go to Step 2.



## 2. ELECTRICAL TEST

(1) Place the object-in-trunk sensor face up on a clean, flat work surface.



(2) Check the object-in-trunk sensor for continuity while pressing and not pressing on the ACTIVE AREA with your finger (not your hand) as shown in the illustration.

### Standard value:

Measured terminal	Continuity	
	No pressure (open)	Pressure (closed)
Between terminals 1 and 2	[0 - 3 $\Omega$ : 20°C (68° F)]	[0 - 3 $\Omega$ : 20°C (68° F)]
Between terminals 1 and 3	No continuity	[10 - 50 $\Omega$ : 20°C (68° F)]
Between terminals 2 and 3	No continuity	[10 - 50 $\Omega$ : 20°C (68° F)]

(3) If the continuity is outside the standard value, replace the object-in-trunk sensor.

# HARDTOP ELECTRONIC CONTROL UNIT (ECU)

## REMOVAL AND INSTALLATION

### Pre-removal and Post-installation Operation


- Removal and Installation of Front Trunk Trim and Hydraulic Line Cover (Refer to GROUP 52-Trims, in this Manual.)

### CAUTION:

Replacement of this component requires the new ECU be run through Auto-configuration (Refer to Diagnostics and Testing, in this section).


### NOTE:

The ECU must be grounded properly. Otherwise, electrical noise may be caused on the analog inputs.



### Removal steps of ECU (Electronic control unit)

- ◆◆ ◆◆ 1. Electrical connector
- ◆◆ ◆◆ 2. Electrical connector
- ◆◆ ◆◆ 3. Electrical connector
- 4. ECU



## SERVICE POINTS OF REMOVAL

### 1. 2. 3. REMOVAL OF ECU ELECTRICAL CONNECTOR

- (1) Insert the screwdriver into the slot, as shown in the illustration. Twist the screwdriver to disengage the slide on the connector.
- (2) Move the slide to the left, and disengage the connector from the ECU.

## SERVICE POINT OF INSTALLATION

### 3. 2. 1. INSTALLATION OF ECU ELECTRICAL CONNECTOR







Engage the electrical connector to the ECU, and move the slide to the right until it stops.

**BODY DIMENSIONS AND MEASUREMENTS  
METHODS**

REFER TO THE MITSUBISHI 3000GT BODY REPAIR  
MANUAL FOR INFORMATION ON:

- HOW BODY DIMENSIONS ARE INDICATED
- INDICATION OF REFERENCE DIMENSIONS
- MEASUREMENT POINTS


8



No.	Measurement points	Diameters	No.	Measurement points	Diameters	No.	Measurement points	Diameters
1	Center of front fender mounting hole	6.6 mm (.26 in.)	5	Rear seat belt retractor D-ring attaching point	11.1 mm (.44 in.)	9	Notch on front pillar (lower)	--
2	Front pillar and roof connection	--	6	Rear pillar and quarter panel connection	--	10	Lock pillar reference point	--
3	Outside of quarter panel	--	7	Center of rear light mounting hole	□ 8.5mm (□ .33 in.)			
4	Front seat belt retractor D-Ring attaching point	11.1 mm (.44 in.)	8	Notch on front pillar (upper)	--			

# BODY STRUCTURE

## MITSUBISHI INSTALLED PARTS




### NOTE


Drivers and passenger doors are Spyder-unique due to strengthening components.

The new Spyder-unique door must be drilled to accept the Spyder-unique wire harness grommet. Use the procedure below.

1. Layout and mark the hole location as shown here.
2. Use a 32 mm hole saw to make the hole.
3. Clean up all drill shavings inside and outside the door.
4. Apply primer and let dry. Apply paint and let dry.
5. Install the door.



**END VIEW**

**BODY STRUCTURE****ASC INCORPORATED INSTALLED PARTS**

**BODY STRUCTURE****ASC INCORPORATED INSTALLED PARTS**


Bracket assembly - topstack cylinder mounting

Support - cylinder mounting


Filler - quarter panel extension


Bracket - quarter window inner


Bracket assembly - quarter window outer






**BODY STRUCTURE****ASC INCORPORATED INSTALLED PARTS**

**BODY STRUCTURE****ASC INCORPORATED INSTALLED PARTS**

**BODY STRUCTURE****ASC INCORPORATED INSTALLED PARTS**

**BODY STRUCTURE****ASC INCORPORATED INSTALLED PARTS**

---


# EXTERIOR

## CONTENTS

<b>AERO PARTS</b> .....	<b>2</b>	<b>REAR BUMPER</b> .....	<b>11</b>
Side Air Dam .....	5	Rear Bumper Extension .....	11
Tonneau Spoiler .....	2	<b>REAR LOCK COVER</b> .....	<b>2, 5</b>
<b>MOULDINGS</b> .....	<b>9</b>	<b>SPYDER DECAL</b> .....	<b>12, 13</b>
Drip Moulding .....	9		
Quarter Belt Moulding .....	9		

## AERO PARTS AND REAR LOCK COVER

### REMOVAL AND INSTALLATION




#### Rear spoiler removal steps

- ◄► ►◄ 1. Rear spoiler

#### Rear lock cover removal steps

- ◄► ►◄ 2. Emblem



## SERVICE POINT OF REMOVAL

### 1. REMOVAL OF REAR SPOILER

- (1) Remove high mounted stop light (refer to 54-25, in this Manual.)
- (2) Snip off the stop light harness connector at the spoiler as shown in the illustration.

#### NOTE

Retain the connector with the cut off wires for reinstallation.

- (3) Open the hard tonneau. Pull the stop light wire harness grommet out from the tonneau and pull out the remaining wire.
- (4) Remove the bolts attaching the spoiler, and separate the spoiler from the vehicle.

## SERVICE POINT OF INSTALLATION

### 1. INSTALLATION OF REAR SPOILER

- (1) Using adhesive tape, attach a 1.52 m (5 ft.) length of 16 ga. bell wire, or similarly stiff wire to the gathered ends of the stop light wire harness.

#### NOTE

This wire will be used to fish the stop light harness wire back through the spoiler.

- (2) Route the fish wire back up through the tonneau and close the tonneau.
- (3) Place a protective cover on the hard tonneau large enough to lay the spoiler face down on it.

#### NOTE

Be sure the tonneau and the spoiler are clean to prevent scratches.

- (4) Place the spoiler face down on the protective cover.
- (5) Fish the wire harness back through the spoiler.
- (6) Install the spoiler to the tonneau.
- (7) Open the tonneau making sure the spoiler will stay in place.
- (8) Install the attaching bolts.


**Standard value: 6 - 8 Nm (53 - 71 in. lb.)**

- (9) Remove the fish wire.
- (10) Reattach the stop light connector to the harness in the spoiler using the **RECOMMENDED WIRE REPAIR** procedure (refer to **GROUP 42, Diagnostics and Testing**, in this Manual.)

#### NOTE

The harness wires must be installed to their respective wire colors. Otherwise, the stop light will not operate.

- (11) Install the stop light.
- (12) Test the stop light operation by applying the service brakes.



## SERVICE POINT OF REMOVAL

### 2. REMOVAL OF EMBLEM

- (1) Use an infrared lamp, or equivalent, to warm the emblem. This will soften the pressure sensitive double-sided tape behind it. Use a plastic moulding tool to pry off the emblem while the tape is warm and pliable. Discard the removed emblem.



#### CAUTION

**Do not overheat the emblem as it could damage the rear panel garnish.**

- (2) Use a plastic moulding tool to carefully scrape off any remaining tape.
- (3) Wipe the application surface of the rear garnish panel with a clean cloth dampened with degreaser (3M ATD Part No. 8906, or equivalent).

#### NOTE

After wiping the surface, allow the degreaser to evaporate for 3 minutes.



## SERVICE POINT OF INSTALLATION

### 2. INSTALLATION OF EMBLEM

- (1) Place a new emblem into the garnish hole.
- (2) Align the emblem so that it is parallel to the top edge of the rear garnish.
- (3) Using a grease pencil or piece of adhesive tape, accurately mark the bottom of the emblem on the garnish.
- (4) Remove the emblem from the garnish hole and peel off its paper backing.
- (5) Reinstall the emblem and align it to the mark or tape. Press firmly.
- (6) Remove the marks or tape.






## AERO PART

## REMOVAL AND INSTALLATION

**Pre-removal and Post-installation Operation**


- Removal and Installation of Front Splash Shield (Refer to GROUP 42 Fender, in this Manual.)
- Removal and Installation of Lock Pillar Louvred Vent




This portion has been removed to accommodate the Spyder-unique body structure

**Side air dam removal**

- ↔ ↔ 1. Side air dam

**SERVICE POINT OF REMOVAL****1. REMOVAL OF SIDE AIR DAM**


- (1) Remove the side air dam mounting nuts.
- (2) Affix protective tape to the periphery of the side air dam.




- (3) Insert a fishing line [0.8 mm (.03 in.)] between the body and the side air dam, and grip each end of the fishing line. Cut through the adhesive material by pulling the fishing line in a sawing motion and remove the side air dam.
- (4) When the side air dam is fastened with a clip or bolt, pull the side air dam toward you to remove the clip or bolt.

**Caution**


1. To reuse the side air dam, remove it by pulling the fishing line along the body so as not to damage the side edges of the side air dam.
2. If it is hard to cut through the adhesive material, heat it to approximately 40°C (104°F).



- (5) Use an infrared lamp, or equivalent, to heat the pressure sensitive double-sided tape remaining on the body to 40 to 60°C (104 to 140°F) for 5 to 15 minutes.



- (6) Use a resin spatula to scrape off the pressure sensitive tape.



- (7) Wipe the application surface of the body with a clean cloth dampened with degreaser (3M ATD Part No. 8906, or equivalent).

**NOTE**


After wiping the surface, allow the degreaser to evaporate for 3 minutes.

## SERVICE POINT OF INSTALLATION


### 1. INSTALLATION OF SIDE AIR DAM

Adhesion of Pressure Sensitive Double-sided Tape to Side Garnish (For Reuse)

- (1) Use an infrared lamp, or equivalent, to heat the pressure sensitive double-sided tape to 40 to 60°C (104 to 140°F) for 5 to 10 minutes.




- (2) Using a resin spatula or gasket scraper, scrape off the pressure sensitive double-sided tape.  
(3) If the pressure sensitive double-sided tape remains on the side air dam, repeat Steps (1) and (2).




- (4) Use a cloth dampened with degreaser (3M ATD Part No. 8906, or equivalent) to wipe the side air dam clean.  
(5) Scrape the old adhesive slightly.

**Caution**

**Do not scrape off all the old adhesive.**





- (6) Affix the pressure sensitive adhesive tape to the side air dam as shown in the illustration.

**Adhesive tape: 3M ATD Part No. 6382, or equivalent**

- (7) Apply adhesive to the air dam as shown in the illustration.

**Adhesive: 3M ATD Part No. 8609 SUPER FAST URETHANE, or equivalent**

#### Installation of Side Garnish

- (1) Remove the paper backing from the double-sided adhesive tape.
- (2) With its clips and bolts aligned with the respective holes in the body, install the side air dam to the body.

#### NOTE

If it is difficult to affix the adhesive tape on the side air dam to the body, heat the application surface of the body and the adhesive surface of the side air dam before installing it.


Body . . . . .40 to 60°C (104 to 140°F)

Side air dam . . . . .20 to 30°C (68 to 86°)

- (3) Apply pressure fully to the side air dam.

# MOULDINGS

## REMOVAL AND INSTALLATION



### Pre-removal and Post-installation Operation



- Removal and Installation of Lower Portion of Windshield Header Weatherstrip from A-pillar Weatherstrip Holder (Refer to GROUP 42, in this Manual.)
- Removal and Installation of A-pillar Weatherstrip Holder (Refer to GROUP 42, in this Manual.)

### Drip moulding removal step

1. Drip moulding

### Pre-removal and Post-installation Operation

- Matchmark Quarter Window Guides to Body
- Removal and Installation of Quarter Window Guides (Refer to GROUP 42 - Quarter Window, in this Manual.)



### Quarter belt moulding removal steps

2. Retainer
3. Screw
4. Quarter belt moulding

**SERVICE POINT OF REMOVAL****3. REMOVAL OF QUARTER BELT MOULDING SCREW**

Remove the inboard portion of the weatherstrip from the vehicle, or use an angled screwdriver to remove the attaching screws.


**SERVICE POINT OF INSTALLATION****3. INSTALLATION OF QUARTER BELT MOULDING SCREW**

Install the attaching screws using an angled screwdriver, or if the weatherstrip was removed, reattach it.

## REAR BUMPER UPPER EXTENSION REMOVAL AND INSTALLATION

### Pre-removal and Post-installation Operation




- Removal and Installation of Side and Rear Trunk Trim (Refer to GROUP 52, in this Manual.)
- Removal and Installation of Rear Combination Light (Refer to GROUP 54, Vol. 1 of the Service Manual.)



### Rear bumper upper extension removal

1. Rear bumper upper extension

## SPYDER-UNIQUE MITSUBISHI DECAL PLACEMENT






### SPYDER VR4 AND SPYDER SL




# SPYDER-UNIQUE DECALS

## PLACEMENT



### SPYDER VR4 ONLY

Edge of "M" must line up with combination light



### SPYDER SL ONLY

---

**NOTES**

# INTERIOR

## CONTENTS

<b>CARGO/HARDTOP STOWAGE AREA TRIM ..</b>	<b>15</b>	<b>QUARTER TRIM PANEL .....</b>	<b>13</b>
<b>CENTER CLOSEOUT PANEL .....</b>	<b>24</b>	<b>REAR SEAT, STRIKER AND REAR</b>	
<b>DIAGNOSTIC AND TESTING .....</b>	<b>2</b>	<b>SHelf PANEL .....</b>	<b>22</b>
Circuit Diagram (Self-dimming Mirror).....	5	<b>SEAT BELT .....</b>	<b>27</b>
Inspection and Verification .....	2	<b>SELF-DIMMING LIGHTED REARVIEW</b>	
Pinpoint Tests .....	4	<b>MIRROR .....</b>	<b>11</b>
Symptom Chart .....	3	Black-out Applique .....	11
Troubleshooting Hints .....	3	Mirror Garnish .....	11
<b>FRONT SEATS .....</b>	<b>18</b>	Mounting Button .....	11
Recline-angle Stop .....	18	<b>SERVICE ADJUSTMENT PROCEDURES .....</b>	<b>7</b>
<b>FRONT PILLAR TRIM .....</b>	<b>10</b>	Center Closeout Panel .....	8
<b>FRONT SEAT BELT GUIDE .....</b>	<b>20</b>	Quarter Trim Panels .....	9
<b>HEADER GARNISH .....</b>	<b>10</b>	Rear Seat Strikers .....	9
<b>HEADLINING .....</b>	<b>21</b>	Rear Shelf Panel .....	8

### WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to the service personnel (from inadvertent firing of the air bag) or to the driver (from rendering the SRS inoperative).
- (2) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- (3) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B - Supplemental Restraint System (SRS) and GROUP 00 - Maintenance Service, before beginning any service or maintenance of any component of the SRS or any SRS-related component.

#### NOTE

The SRS includes the following components: impact sensors, SRS diagnosis unit, SRS warning light, air bag module, clock spring and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (\*).

**INSPECTION AND VERIFICATION**

1. Verify the customer's original concern by operating the system to duplicate the concern.
2. Inspect to determine if any of the following mechanical or electrical concerns apply:

MECHANICAL	ELECTRICAL
<ul style="list-style-type: none"><li>• Damaged mirror.</li><li>• Damaged bracket.</li></ul>	<ul style="list-style-type: none"><li>• Blown fuse.</li><li>• Circuitry open or shorted.</li><li>• Damaged control switch.</li><li>• Damaged mirror.</li><li>• Damaged backup lamp switch.</li></ul>

3. If the inspection reveals obvious concern(s) that can be readily identified, service as required.
4. If the concern(s) remain after inspection, determine the symptom and go to the Symptom Chart.

**SYMPTOM CHART**

NOTE: REFER TO TROUBLE SHOOTING HINT FOLLOWING THE SYMPTOM CHART

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"><li>• Rear view mirror Auto-Dim inoperative.</li></ul>	<ul style="list-style-type: none"><li>• Circuitry open/shorted.</li><li>• Damaged mirror.</li><li>• Damaged backup lamp switch.</li></ul>	<ul style="list-style-type: none"><li>• Go to Pinpoint Test A.</li></ul>

**TROUBLESHOOTING HINTS****Pinpoint Test A**


Indicates that the self-dimming mirror will not dim properly. This may occur if circuits CR 5, CR 4, and/or CR 6 are open/shorted, mirror damaged, voltage on circuit CR 6 indicates that the vehicle is in Reverse which prohibits the mirror from dimming.

## PINPOINT TESTS

**TEST A**  
**REARVIEW MIRROR AUTO-DIM INOPERATIVE**

TEST STEP		RESULT	ACTION TO TAKE
<b>A-1</b>	<b>CHECK CIRCUIT CR 5 FOR SYSTEM VOLTAGE</b>		
<ul style="list-style-type: none"> <li>• Access and disconnect rearview mirror connector E-127.</li> <li>• Using Digital Volt/Ohm Meter (DVOM) set to DC volt, connect negative lead to a known good ground.</li> <li>• Connect the positive lead to pin 1 at rearview mirror connector E-127.</li> <li>• Turn ignition to ON position.</li> <li>• Read voltmeter.</li> </ul> <p>• <b>Is system voltage present?</b></p>		Yes	Go to <b>A-2</b> .
		No	Repair circuit CR 5. Restore vehicle. Retest system.
<b>A-2</b>	<b>CHECK CIRCUIT CR 4 FOR OPEN</b>		
<ul style="list-style-type: none"> <li>• Connector E-127 at rearview mirror disconnected.</li> <li>• Using DVOM set to ohm scale, connect negative lead to known good ground.</li> <li>• Connect positive lead to pin 2 at rearview mirror connector E-127.</li> <li>• Read ohmmeter.</li> </ul> <p>• <b>Is there 3 ohms or less?</b></p>		Yes	Go to <b>A-3</b> .
		No	Repair circuit CR 4. Restore vehicle. Retest system.
<b>A-3</b>	<b>CHECK CIRCUIT CR 6 FOR VOLTAGE</b>		
<ul style="list-style-type: none"> <li>• Connector E-127 at rearview mirror disconnected.</li> <li>• Using DVOM set to DC volt, connect negative lead to known good ground.</li> <li>• Connect the positive lead to pin 3 at rearview mirror connector E-127.</li> <li>• Turn ignition to ON position.</li> <li>• Make sure transaxle is in park (automatic) neutral (manual).</li> <li>• Read voltmeter.</li> </ul> <p>• <b>Is voltage present?</b></p>		Yes	Go to <b>A-4</b> .
		No	Replace rearview mirror. Restore vehicle. Retest system.
<b>A-4</b>	<b>CHECK CIRCUIT CR 6 AT BACK UP LAMP SWITCH</b>		
<ul style="list-style-type: none"> <li>• Connector E-127 at rearview mirror disconnected.</li> <li>• Access and disconnect connector B-25 (manual transaxle) B-26 (automatic transaxle).</li> <li>• Using DVOM set on DC volt, connect negative lead to known good ground.</li> <li>• Connect the positive lead to pin 1 (manual transaxle) pin 11 (automatic transaxle) at backup lamp switch.</li> <li>• Turn ignition to ON position.</li> <li>• Read voltmeter.</li> </ul> <p>• <b>Is voltage present?</b></p>		Yes	Repair circuit CR 6. Restore vehicle. Retest system.
		No	Refer to Volume 1 of Service Manual (for backup lamp switch adjustment or repair).

# SELF-DIMMING LIGHTED REARVIEW MIRROR CIRCUIT DIAGRAM



(B-25)

(B-26)

(C-30)



(C-77)

(C-82)


(F-11)

(F-25)


(F-46)



SELF-DIMMING LIGHTED REARVIEW MIRROR CIRCUIT DIAGRAM



C-78



C-82




E-45



E-116



E-127 \*





## SERVICE ADJUSTMENT PROCEDURES




- REAR SHELF PANEL
- CENTER CLOSEOUT PANEL
- QUARTER TRIM PANELS (POSITION)
- FLIPPER DOORS (POSITION)


### Description

The positions of the quarter trim panels in the vehicle are the foundation for all height, position or gap adjustments of the rear shelf panel, flipper doors, and center closeout panel. The only piece of trim that is not stationary is the center closeout panel. The center closeout rides on two cams and is mechanically actuated by linkage connected to the hardtop mechanism. As the hardtop opens the closeout panel moves backward to fill the gap at the front of the hard tonneau where the hardtop was. When the hardtop closes, the closeout panel moves forward.

All the subject parts, including the hard tonneau and flipper doors, must all be in alignment with each other in order to achieve the proper design positions. When one or more of these components are adjusted or replaced, the alignment of the other subject parts must be checked and readjusted if necessary. When adjusting or replacing the trim parts, the hardtop should be open (stowed) and the hard tonneau closed.


The hard tonneau **MUST** be adjusted correctly before attempting any adjustment of the trim parts. The hard tonneau flipper doors must be checked and readjusted, if necessary, after adjusting the other trim components. For adjustment of the flipper doors, refer to GROUP 42 - ADJUSTMENT OF HARD TONNEAU FLIPPER DOORS, in this Manual.






## REAR SHELF PANEL

1. Install the LH and RH quarter trim panels, except the top rear screws.
2. Loosen the attaching nuts and bolts for the rear shelf panel in order to align the rear shelf panel to the screw hole at the top of the quarter trim panel. The quarter trim panels determine the position of the rear shelf panel. Refer to QUARTER TRIM PANEL, in this section.
3. Tighten attaching nuts and bolts.



## CENTER CLOSEOUT PANEL

1. Close the hardtop and open the tonneau.
2. Loosen the jam-nut of the center closeout's LH and RH stops and back-off the stop several turns.
3. Open the hardtop and close the tonneau.




4. Move the center closeout panel rearward toward the hard tonneau until it stops.

### NOTE

The center closeout panel will move forward as the hardtop is being closed.

5. Close the hardtop then open it.
6. Using the LH and RH stops, adjust the center closeout to the hard tonneau as shown in the illustration.
7. Close the tonneau and check the gap.
8. Repeat Steps 3-7 to meet the Standard value, then tighten the jam-nuts.

**Standard value: 9 - 14 Nm (80 - 124 in.lb.)**




9. With the hardtop open, at one side, loosen the two bolts holding closeout panel actuator link to the closeout panel control link as shown in the illustration. Then draw the two components together to take up any looseness, and tighten the bolts. Repeat for the other side.

### NOTE

Taking out the looseness is necessary for proper consistent operation. Otherwise, the center closeout panel will not move consistently back and forth and side-to-side. This may cause an unacceptable rattle.

**Standard value: 9 - 14 Nm (80 - 124 in.lb.)**



5. Adjust the height of the center closeout panel, as necessary, as shown in the illustration.

#### NOTE


Because of the nature of the cams and mechanisms, the adjustment height of the center closeout panel in the forward position will be the same as the rearward position.

#### Guide assembly bolts

**Standard value: 9 - 12 Nm (80 - 106 in.lb.)**

#### Rear mounting bolts

**Standard value: 9 - 14 Nm (80 - 124 in.lb.)**




## REAR SEAT STRIKERS

#### NOTE

The rear shelf panel **MUST** be properly adjusted before attempting to adjust rear seat strikers.

1. With both rear seat backs installed, fold them forward.
2. Loosen the bolts holding the striker at one side enough to adjust the striker.
3. Raise the seat back while aligning it to the striker. Adjust the striker to align the seat back catch and lock the rear seat back in position. Then tighten the bolts.

**Standard value: 9 - 12 Nm (80 - 106 in.lb.)**




## QUARTER TRIM PANELS

The quarter trim panels are not necessarily designed to be adjusted. When adjustment is necessary, the attaching holes and the corresponding hole locations in the brackets or body structure may need to be redrilled.

## REMOVAL AND INSTALLATION

&lt;Interior&gt;

**Front pillar trim removal steps**

1. Clip
2. Front pillar trim

**Header garnish removal steps**


2. Front pillar trims
3. Sunvisor assemblies
4. Sunvisor holders
5. Header garnish
6. HomeLink™ Universal Transmitter

**NOTE**(1)  : Location of metallic clip

# <Self-dimming Lighted Rearview Mirror>


## **Pre-removal and Post-installation Operation**

- Removal and Installation of Header Garnish (Refer to P. 52-8, in this section.)



## **CAUTION:**

1. **DO NOT** use the coupe's mirror button location or the button itself.
2. Be sure the mirror mounting button used is in the Spyder-unique location and is designed to be used with the Spyder-unique lighted rearview mirror.



## **Self-dimming lighted rearview mirror removal steps**

1. Mirror electrical connector
2. Lower mirror garnish
3. Mirror set screw
4. Mirror
5. Black-out applique
6. Mirror mounting button

**SERVICE POINT OF REMOVAL****2. REMOVAL OF LOWER MIRROR GARNISH**

Grip the garnish with pliers and twist off the garnish to separate the adhesive bond.

**SERVICE POINTS OF INSTALLATION****6. 5. INSTALLATION OF BLACK-OUT APPLIQUE/INSTALLATION OF MIRROR MOUNTING BUTTON****NOTE**

- (1) The header garnish must be removed prior to installation.
- (2) For best results the windshield should be at least room temperature.


- 1. Using a clean, lint-free cloth dampened with isopropyl alcohol, clean the area of the windshield where the mounting button and black-out applique will go.
- 2. Peel back the lower half of the protective backing from the black-out applique (rounded end).
- 3. Apply the exposed portion around the existing Coupe button while peeling away the remaining backing. Use gentle but firm pressure to smooth out any air bubbles. Air bubbles can be removed easily by pricking them with a needle and smoothing them out.
- 4. Apply the mirror button in the opening in the applique. Use an adhesive specifically made for bonding mirror buttons to windshields. Follow the manufacturer's directions.

**2. INSTALLATION OF LOWER MIRROR GARNISH**

Use an adhesive suitable for bonding plastic to metal such as an acrylic-based two-part epoxy.

**Pre-removal and Post-installation Operation**


- Removal and Installation of Scuff Plate
- Open tonneau and leave open for removal and installation of Quarter Trim Panel.

**<Quarter trim panel>****Quarter trim panel removal steps**

- ◆◆ ◆◆ 1. Rear seat cushion
2. Front seat belt anchor plate mounting bolt
3. Screw
4. Courtesy light harness connector
5. Rear seat belt anchor plate mounting bolt
6. Quarter trim panel

**Disassembly steps**


- ◆◆ 7. Speaker cover
8. Bezel
9. Bezel
10. Courtesy light

**SERVICE POINT OF REMOVAL****1. REMOVAL OF REAR SEAT**

With the lever pulled forward, raise the seat cushion to remove it.

**SERVICE POINTS OF INSTALLATION****7. INSTALLATION OF SPEAKER COVER**


Note: The Spyder-unique quarter trim panel uses the opposite-handed coupe speaker cover. (The LH coupe speaker cover attaches to the RH quarter trim panel.)

**1. INSTALLATION OF REAR SEAT**

- (1) Fit the seat cushion attachment wire under the seat-backs securely.
- (2) Pass the rear seat belt buckles through the seat cushion.
- (3) Securely attach the seat cushion lock plate to the floor.




<Cargo/hardtop stowage area>



**Removal steps**

1. Object-in-trunk sensor harness connector
2. Object-in-trunk sensor
- ◆◆ ◆◆ 3. L.H. trunk trim panel
4. R.H. trunk trim panel
5. CD access door
6. Trunk center front panel
7. Hydraulic line cover
- ◆◆ ◆◆ 8. Trunk trim rear panel
9. CD changer tray
10. Luggage compartment floor box (L.H.)
- ◆◆ ◆◆ 11. Luggage compartment floor box (R.H.)




## SERVICE POINTS OF REMOVAL

### 3. REMOVAL OF LEFT HAND TRUNK TRIM PANEL


- (1) Detach the trim panel from the vehicle.
- (2) Open the hardtop halfway.
- (3) Secure both flipper doors to the tonneau in their retracted position with 2" wide, cloth reinforced, adhesive tape (such as a good quality duct tape or stranded packaging tape). This will relieve tension on the flipper door drive cable allowing easy removal and reinstallation of the cable clevis attached to the hardtop mechanism.

#### Caution

Stay clear of the flipper doors to prevent personal injury.




- (4) Remove the cotter pin and clevis pin securing the flipper door cable clevis to the hardtop mechanism.
- (5) Pull the cable through the trim panel to remove it.



### 7. REMOVAL OF TRUNK TRIM REAR PANEL

Remove the bolt attaching the hardtop down stop link to the bracket and remove the trim panel.



### 10. REMOVAL OF LUGGAGE COMPARTMENT FLOOR BOX

- (1) Disconnect the object-in-trunk sensor harness connector.
- (2) Using a small tool, release the tangs in the object-in-trunk sensor harness connector mounted on the floor box connector bracket. Then, remove the floor box.

## **SERVICE POINTS OF INSTALLATION**

### **10. INSTALLATION OF LUGGAGE COMPARTMENT FLOOR BOX**

- (1) Install the floor box.
- (2) Reinstall the object-in-trunk sensor harness connector in the floor box.
- (3) Reconnect the harness connector.

### **7. INSTALLATION OF TRUNK TRIM REAR PANEL**

Attach the trim, then install the hardtop down stop link to the bracket with the bolt.

**Standard value: 6 - 9 Nm (54 - 80 in.lb.)**


### **3. INSTALLATION OF LEFT HAND TRUNK TRIM PANEL**

- (1) Route the flipper door drive cable back through the trunk trim.
- (2) Reattach the cable clevis to the hardtop mechanism using the clevis pin and cotter pin.
- (3) Hold the flipper door securely and remove the adhesive tape.
- (4) Attach the trim panel to the vehicle.
- (5) Open or close the hardtop.

## FRONT SEATS


**Pre-removal and Post-installation Operation**

- Removal and Installation of Front Seat (Refer to GROUP 52A, in Volume 1.)




Front seat (passenger side shown - driver side similar)

<Vehicles with welded-on recline-angle stop>



<Vehicles with riveted-on recline-angle stop>

<Repair for vehicles with welded-on recline-angle stop>

**CAUTION:**

1. The LH and RH front seats have been modified with a recline-angle stop welded to the seat reclining adjuster assembly.
2. The recline-angle stop is not serviceable.
3. DO NOT attempt to repair the recline-angle stop. Replace the seat with a modified Spyder-unique seat, or repair the recline-angle stop by following the procedure in SERVICE POINTS OF REMOVAL and INSTALLATION OF RECLINE-ANGLE STOP, in this section.

**Removal steps**

- ◆◆◆ 1. Rivet
- ◆◆ 2. Recline-angle stop

FRONT SEAT  
SEAT P.  
52-20

## SERVICE POINT OF

### 1. REMOVAL OF RIVET

Use a 3/16 in. drill to remove

#### Caution

Be sure drill chips are completely removed from the area so that they do not get caught in the reclining adjuster.

## SERVICE POINTS OF INSTALLATION

### 2. INSTALLATION OF RECLINE-ANGLE STOP

#### Seats requiring no drilling for installation of seat recline-angle stop:

Install the seat recline-angle stop to the stop pin on the seat.

#### Seats requiring drilling for installation of seat recline-angle stop:

- (1) Grind or file the stop pin on the seat, if necessary, to install the seat recline-angle stop.
- (2) Install the seat recline-angle stop to the stop pin on the seat.
- (3) Recline the seat back to apply pressure on the recline-angle stop so that it seats against the seat reclining adjuster assembly.
- (4) Using a 3/16 in. drill, use the recline-angle stop as a drill guide and drill the hole for the rivet.

#### Caution


Be sure drill chips are completely removed by vacuuming the area so that they do not get caught in the seat reclining adjuster.

### 1. INSTALLATION OF RIVET

Rivet: 3/16" x .375 Protruding head

## SEAT BELT GUIDE

### DISASSEMBLY AND REASSEMBLY




#### Seat belt guide removal step

- ↔ 1. Seat belt guide

### SERVICE POINT OF REMOVAL

#### 1. REMOVAL OF SEAT BELT GUIDE

Using a screwdriver, release the retaining pin while pulling the seat belt guide out of the holder.




# HEADLINING

## REMOVAL AND INSTALLATION

**NOTE**

Open the hardtop halfway for removal and installation of headlining.


**Pre-removal Operation of LH and RH Front Rail Headlining Extensions**

- Removal of Front Rail Weatherstrip
- Removal of Front Rail Weatherstrip Holder (Refer to GROUP 42 - Weatherstrip, in this Manual.)

**Post-installation Operation of LH and RH Front Rail Headlining Extensions**

- Installation of Front Rail Weatherstrip (Refer to GROUP 42 - Weatherstrip, in this Manual.)
- Adjustment of Front Rail Weatherstrip (Refer to SERVICE ADJUSTMENT PROCEDURES, GROUP 42, in this Manual.)


**Headlining removal steps**

1. Front headlining
2. LH front rail headlining extension
3. RH front rail headlining extension
4. RH rear headlining
5. LH rear headlining
6. Center headlining
7. Temperature sensor harness connector
8. Backlite lower garnish

**NOTE**

(1) ◀ : Location of dual lock fastener

## REMOVAL AND INSTALLATION



- Removal and Installation of Center Closeout Panel (Refer to P.52-24, in this section).
- Removal of LH and RH Quarter Trim Panels (Refer to P.52-13, in this section).

- Rear Seat Striker Adjustment (Refer to SERVICE ADJUSTMENT PROCEDURES, in this section).
- Rear Shelf Panel Adjustment (Refer to SERVICE ADJUSTMENT PROCEDURES, in this section).
- Installation of LH and RH Quarter Trim Panels (Refer to P.52-13, in this section.)

**NOTE**  
Matchmark components before  
removal or disassembly.


◀ ▶   ▶ ◀

1. Rear seat cushion
2. Rear seat back

### 3. Nuts

#### 4. Striker






## SERVICE POINT OF REMOVAL

### 1. REMOVAL OF REAR SEAT

With the lever pulled forward, raise the lower seat cushion to remove it.



## SERVICE POINT OF INSTALLATION


### 1. INSTALLATION OF REAR SEAT

- (1) Fit the seat cushion attachment wire under the seat-backs securely.
- (2) Pass the rear seat belt buckles through the seat cushion.
- (3) Securely attach the seat cushion lock plate to the floor.

## CENTER CLOSEOUT PANEL REMOVAL AND INSTALLATION

**Post-installation Operation**


- Center Closeout Panel Adjustment (Refer to SERVICE ADJUSTMENT PROCEDURES, in this section.)

**Removal step**

1. Bolt

# DISASSEMBLY AND REASSEMBLY

<Center closeout panel>




**Disassembly step**

1. Nut

## DISASSEMBLY AND ASSEMBLY


## &lt;Mechanism&gt;



# SEAT BELT

## REMOVAL AND INSTALLATION

### <Front Seat Belt>



#### Pre-removal and Post-installation Operation

- Removal and Installation of Quarter Trim Panel (Refer to P.52-13, in this section).

#### Outer seat belt removal step

1. Outer seat belt

**CAUTION:**  
Do not interchange seat belts side-to-side or front-to-back.

### <Rear Seat Belt>


#### Pre-removal and Post-installation Operation

- Removal and Installation of Quarter Trim Panel (Refer to P.52-13, in this section).

#### Outer seat belt removal steps

1. Speaker
2. Outer seat belt

**CAUTION:**  
Do not interchange seat belts side-to-side or front-to-back.




---

**NOTES**

# CHASSIS ELECTRICAL

## CONTENTS


<b>CARGO/HARDTOP STOWAGE AREA LIGHT</b> .....	<b>22</b>	<b>GENERAL INFORMATION</b> .....	<b>2</b>
<b>CD CHANGER</b> .....	<b>15</b>	Cargo/Hardtop Stowage Area Lamp .....	4
<b>DIAGNOSTICS AND TESTING</b> .....	<b>5</b>	System .....	4
Circuit Diagrams .....	11	CD Changer .....	2
Cargo/hardtop Stowage Area Lamp .....	13	Motor Antenna .....	3
HomeLink™ Universal Transmitter .....	11	<b>HIGH MOUNTED STOP LIGHT</b> .....	<b>25</b>
Lighted Rearview Mirror (Map Lights) ..	12	<b>HOMELINK™ UNIVERSAL TRANSMITTER</b> ..	<b>19</b>
Inspection and Verification .....	5	<b>LIGHTED REAR VIEW MIRROR (MAP LIGHTS)</b> .....	<b>14</b>
Pinpoint Tests .....	7	<b>MOTOR ANTENNA AND RELAY</b> .....	<b>17</b>
Test A: Both Map Lights Inoperative with Switches .....	7	<b>QUARTER TRIM PANEL COURTESY LIGHT</b> ..	<b>20</b>
Test B: Map Light (One) Inoperative ....	8	<b>REAR COMBINATION LIGHTS</b> .....	<b>23</b>
Test C: Luggage Compartment Lamp Inoperative .....	9	<b>REAR SPEAKER</b> .....	<b>16</b>
Test D: Universal Transmitter (HomeLink™) Inoperative .....	10	<b>THEFT ALARM SYSTEM, LIGHT AUTOMATIC SHUT-OFF AND KEYLESS ENTRY RECEIVER ASSEMBLY (SPYDER-UNIQUE RELOCATION)</b> .....	<b>21</b>
Symptom Chart .....	6		
Troubleshooting Hints .....	6		

**CD CHANGER**


**NOTE**  
For diagnostics and testing refer to  
Volume 2 of the Service Manual.



## MOTOR ANTENNA



**NOTE**  
For diagnostics and testing refer to  
Volume 2 of the Service Manual.

**CARGO/HARDTOP STOWAGE AREA LAMP SYSTEM**

**NOTE**  
For Configuration Diagram refer to  
GROUP 42, in this Manual.

**INSPECTION AND VERIFICATION**

1. Verify the customer's original concern by operating the system to duplicate the concern.
2. Inspect to determine if any of the following mechanical or electrical concerns apply:

MECHANICAL	ELECTRICAL
<ul style="list-style-type: none"><li>• Damaged switches.</li><li>• Damaged mirror.</li></ul>	<ul style="list-style-type: none"><li>• Blown fuse.</li><li>• Circuitry open or shorted.</li><li>• Damaged switches.</li><li>• Damaged bulbs.</li><li>• Damaged lights.</li><li>• Damaged transmitter.</li><li>• Damaged mirror.</li><li>• Damaged battery.</li></ul>

3. If the inspection reveals obvious concern(s) that can be readily identified, service as required.
4. If the concern(s) remain after inspection, determine the symptom and go to the Symptom Chart.

## SYMPTOM CHART

**NOTE: AFTER DETERMINING THE SYMPTOM AND PINPOINT TEST REFER TO TROUBLESHOOTING HINTS FOLLOWING THE SYMPTOM CHART**

CONDITION	POSSIBLE CAUSE	ACTION
• Map lights (both) inoperative from switches.	• Circuitry open/shorted. • Damaged mirror.	• Go to Pinpoint Test A.
• Map lights (both) inoperative when doors are open.	• Circuitry open/shorted. • Damaged door switch.	• Refer to Volume 2 of Service Manual.
• Map light (one) inoperative.	• Damaged bulb. • Damaged mirror.	• Go to Pinpoint Test B.
• Luggage compartment light inoperative.	• Circuitry open/shorted. • Damaged light. • Damaged switch.	• Go to Pinpoint Test C.
• Universal transmitter HomeLink™ inoperative.	• Circuitry open/shorted. • Programmed wrong. • Damaged transmitter. • Low transmitter battery.	• Go to Pinpoint Test D.

## TROUBLESHOOTING HINTS

## Pinpoint Test A:

Indicates that both map lights are inoperative from map light switches. This may occur if system voltage is not supplied to circuit CR 5, ground not supplied by circuit CR 4, or damaged mirror.

Map lights (both) inoperative when doors are opened: Indicates that the map lights work from the map light switches, but not from the dome light switch, which indicates a problem in dome light circuits or door switch.

## Pinpoint Test B:

Indicates that one map light is operating which indicates that voltage and ground circuits must be good. This may occur if one bulb is burned out, or damaged mirror.

## Pinpoint Test C:

Indicates that the luggage compartment light does not come on when the hard tonneau is in the open position. This may occur if circuit CT 1, CT 2, are open/shorted, circuit CT 3 open, the switch damaged, bulb burnt out, or lamp damaged.

## Pinpoint Test D:

This test is to verify voltage to circuit CR 1 and circuit CR 4 for good ground. If both are present then the probable cause is damaged transmitter, programming procedure, or low battery in hand-held transmitter.

## PINPOINT TESTS

**TEST A**  
**BOTH MAP LIGHTS INOPERATIVE WITH SWITCHES**

TEST STEP		RESULT	ACTION TO TAKE
<b>A-1</b>	CHECK CIRCUIT CR 1 FOR SYSTEM VOLTAGE		
NOTE: Remove and inspect map light bulbs before continuing.  • Access and disconnect rearview mirror connector E-127. • Using Digital Volt/Ohm Meter (DVOM) set to DC volt, connect negative lead to a known good ground. • Connect the positive lead to pin 7 at rearview mirror connector E-127. • Read voltmeter.  • <b>Is system voltage present?</b>		Yes  No	► Go to <b>A-2</b> .  ► Repair circuit CR 1. Restore vehicle. Retest system.
<b>A-2</b>	CHECK CIRCUIT CR 4 FOR OPEN		
• Connector E-127 at rearview mirror disconnected. • Using DVOM set to ohm scale, connect negative lead to known good ground. • Connect positive lead to pin 2 at rearview mirror connector E-127. • Read ohmmeter.  • <b>Is there 3 ohms or less?</b>		Yes  No	► Replace rearview mirror. Restore vehicle. Retest system.  ► Repair circuit CR 4. Restore vehicle. Retest system.

## PINPOINT TESTS

TEST B  
MAP LIGHT (ONE) INOPERATIVE

TEST STEP		RESULT	ACTION TO TAKE
B-1	CHECK MAP LIGHT BULB		
<ul style="list-style-type: none"><li>• Access and remove suspect map light bulb.</li><li>• Inspect map light bulb.</li><li>• Is map light bulb good?</li></ul>		Yes	Replace rearview mirror. Restore vehicle. Retest system.
		No	Replace bulb. Restore vehicle. Retest system.

## PINPOINT TESTS

TEST C  
LUGGAGE COMPARTMENT LAMP INOPERATIVE

TEST STEP		RESULT	ACTION TO TAKE
<b>C-1</b>	CHECK CIRCUIT CT 2 AT LUGGAGE COMPARTMENT LAMP		
NOTE: Remove and inspect light bulb before continuing.  • Open hard tonneau. • Access cargo lamp connector F-08. • Using Digital Volt/Ohm Meter (DVOM) set to DC volt, connect negative lead to a known good ground. • Back probe and connect the positive lead to pin 1 at luggage compartment lamp connector F-08. • Read voltmeter.  • <b>Is system voltage present?</b>		Yes  No	► Go to <b>C-2</b> .  ► Go to <b>C-3</b> .
<b>C-2</b>	CHECK CIRCUIT CT 3 AT LUGGAGE COMPARTMENT LAMP		
• Hard tonneau open. • Disconnect luggage compartment lamp connector F-08. • Using DVOM set to DC volt, connect negative lead to pin 2 at luggage compartment lamp connector F-08. • Connect positive lead to pin 1 at luggage compartment lamp connector F-08. • Read voltmeter.  • <b>Is system voltage present?</b>		Yes  No	► Replace luggage compartment lamp. Restore vehicle. Retest system.  ► Repair circuit CT 3. Restore vehicle. Retest system.
<b>C-3</b>	CHECK CIRCUIT CT 2 AT LUGGAGE COMPARTMENT LAMP SWITCH		
• Hard tonneau open. • Access luggage compartment lamp switch connector F-116. • Using DVOM set to DC volt, connect negative lead to a known good ground. • Back probe and connect the positive lead to pin A at luggage compartment lamp switch connector F-116. • Read voltmeter.  • <b>Is system voltage present?</b>		Yes  No	► Repair circuit CT 2. Restore vehicle. Retest system.  ► Go to <b>C-4</b> .
<b>C-4</b>	CHECK CIRCUIT CT 1 AT LUGGAGE COMPARTMENT LAMP SWITCH		
• Access luggage compartment lamp switch. • Using DVOM set to DC volt, connect negative lead to a known good ground. • Connect positive lead to pin B at luggage compartment lamp switch connector F-116. • Read voltmeter.  • <b>Is system voltage present?</b>		Yes  No	► Replace luggage compartment lamp switch. Restore vehicle. Retest system.  ► Refer to Volume 2 of Service Manual (for repair of dome light circuit).






## PINPOINT TESTS

**TEST D**  
**UNIVERSAL TRANSMITTER (HOMELINK™) INOPERATIVE**


TEST STEP		RESULT	ACTION TO TAKE
<b>D-1</b>	CHECK CIRCUIT CR 1 FOR SYSTEM VOLTAGE		
NOTE: This test should only be done after CAREFULLY following HomeLink™ Universal Transmitter Training Techniques found in Section 00 of this Manual. <ul style="list-style-type: none"> <li>• Access and disconnect connector E-112 to the HomeLink™ Universal Transmitter.</li> <li>• Using Digital Volt/Ohm Meter (DVOM) set to DC volt, connect negative lead to a known good ground.</li> <li>• Connect the positive lead to pin A at HomeLink™ Universal Transmitter, connector E-112.</li> <li>• Read voltmeter.</li> </ul> <b>• Is system voltage present?</b>		Yes ► Go to <b>D-2</b> .  No ► Refer to Volume 2 of Service Manual, Lighting System (for dome light circuit repair).	
<b>D-2</b>	CHECK CIRCUIT CR 4 FOR OPEN		
<ul style="list-style-type: none"> <li>• Connector to HomeLink™ Universal Transmitter disconnected.</li> <li>• Using DVOM set to ohm scale, connect negative lead to known good ground.</li> <li>• Connect positive lead to pin B at HomeLink™ Universal Transmitter, connector E-112.</li> <li>• Read ohmmeter.</li> </ul> <b>• Is there 3 ohms or less?</b>		Yes ► Circuits check okay. Restore vehicle. Refer to HomeLink™ Universal Transmitter Training Techniques found in Section 00 of this Manual.  No ► Repair circuit CR 4. Restore vehicle. Retest system.	









## HomeLink™ UNIVERSAL TRANSMITTER CIRCUIT DIAGRAM




## LIGHTED REARVIEW MIRROR (MAP LIGHTS) CIRCUIT DIAGRAM



## CARGO/HARDTOP STOWAGE AREA LAMP CIRCUIT DIAGRAM



## LIGHTED REARVIEW MIRROR (MAP LIGHTS) REMOVAL AND INSTALLATION



### Removal steps


1. Bulb holder/switch assembly
2. Bulb socket
3. Bulb

## CD CHANGER


### REMOVAL AND INSTALLATION

#### Pre-removal and Post-installation Operation

- Removal and Installation of Trunk Center Front Panel and Hydraulic Line Cover (Refer to GROUP 52, in this Manual.)
- Removal and Installation of Hardtop ECU (Refer to GROUP 42, in this Manual.)
- Removal and Installation of LH Luggage Compartment Floor Box (Refer to GROUP 52, in this Manual.)



2 - 3 Nm  
18 - 27 in.lbs.



**NOTE**  
Refer to Volume 2 of the Service Manual for more information.

2 - 3 Nm  
18 - 27 in.lbs.

#### Removal steps

1. Cover
2. CD changer electrical connector
3. CD changer
4. CD changer bracket (front)
5. CD changer bracket (rear)

**NOTE:**  
Front and rear CD changer brackets are Spyder-unique. Use only Spyder-unique service parts.


## REAR SPEAKER REMOVAL AND INSTALLATION

**Pre-removal and Post-installation  
Operation**

- Removal and Installation of Quarter Trim Panel (Refer to GROUP 52, in this Manual.)

**NOTE**

Refer to Volume 2 of the Service Manual for more information.

**Removal steps**

1. Speaker
2. Electrical connector



## MOTOR ANTENNA AND RELAY REMOVAL AND INSTALLATION

### Pre-removal and Post-installation Operation of Motor Antenna

- Removal and Installation of Right Front Fender Front Splash Shield (Refer to GROUP 42 - Fender, in this Manual.)

### Pre-removal and Post-installation Operation of Motor Antenna Relay

- Removal and Installation of Glove Box and Cross Pipe Cover (Refer to GROUP 52A, in Volume1.)



**NOTE**  
Refer to Volume 2 of the Service Manual for more information.


### Removal steps of motor antenna

1. Ring nut
2. Outer garnish
3. Gasket
4. Antenna feeder cable and motor antenna connections

5. Nuts
6. Motor antenna
7. Antenna bracket
8. Isolator

### Removal steps of motor antenna relay

9. Relay harness electrical connector
10. Relay



## SERVICE POINT OF INSTALLATION

### 6. INSTALLATION OF MOTOR ANTENNA

- (1) Install the motor antenna.

#### NOTE

Do not tighten the nuts holding the motor antenna to the bracket.

- (2) Connect harness connectors and antenna feeder cable.
- (3) Install the outer garnish and gasket, and the ring nut.
- (4) Tighten the motor attaching nuts.

**Standard value: 5.6 - 8 Nm (50 - 71 in.lb.)**

- (5) Check operation of antenna by operating the radio.




## HomeLink™ UNIVERSAL TRANSMITTER

### REMOVAL AND INSTALLATION

**Pre-removal and Post-installation Operation**

- Removal and Installation of Header Garnish (Refer to GROUP 52, in this Manual.)

**Removal step**


1. HomeLink™ Universal Transmitter

## INSPECTION

### INSPECTION OF HomeLink™ UNIVERSAL TRANSMITTER

1. This unit cannot be inspected nor is any component inside serviceable. Refer to Diagnostics and Testing in this section; replace the unit if troubleshooting proves unsuccessful.

## QUARTER TRIM PANEL COURTESY LIGHT REMOVAL AND INSTALLATION



### Removal steps

- ◄►
1. Lens
  2. Bulb holder

### SERVICE POINT OF REMOVAL

#### 1. REMOVAL OF LENS


Use the tape-wrapped tip of a screwdriver to remove the lens.

# THEFT ALARM SYSTEM - LIGHT AUTOMATIC SHUT-OFF AND KEYLESS ENTRY RECEIVER ASSEMBLY (SPYDER-UNIQUE RELOCATION)

## REMOVAL AND INSTALLATION

### Pre-removal and Post-installation Operation

- Removal and Installation of LH Quarter Trim Panel (Refer to GROUP 52, in this Manual.)




**NOTE**  
Refer to Volume 2 of the Service Manual for more information.

### Removal steps

1. Keyless entry receiver assembly
2. Light automatic shut-off unit

## CARGO/HARDTOP STOWAGE AREA LIGHT REMOVAL AND INSTALLATION



### Removal steps

- ↔ 1. Lens
- ↔ 2. Bulb holder
- ↔ 3. Mercury switch

### SERVICE POINT OF REMOVAL

#### 1. REMOVAL OF LENS

Use the tape-wrapped tip of a screwdriver to remove the lens.


### SERVICE POINT OF INSTALLATION

#### 3. INSTALLATION OF MERCURY SWITCH

- (1) Be sure the wires of the switch are facing down.
- (2) Check the operation of the cargo area light system by opening and closing the hard tonneau.

# REAR COMBINATION LIGHTS

## REMOVAL, INSTALLATION AND MODIFICATION



### Pre-removal and Post-installation Operation


- Removal and Installation of Rear Trunk Trim (Refer to GROUP 52, in this Manual.)

### Rear combination light removal

- ◆◆ ◆◆ 1. Rear combination light

#### NOTE

- (1) Left and right 3000GT rear combination lights **MUST** be modified to accommodate the Spyder-unique body structure.
- (2) Remove rubber vent tubes on the rear of the lights before trimming, then, reinstall.



RIGHT REAR COMBINATION LIGHT SHOWN FROM REAR  
(LEFT SIDE OPPOSITE)


**SERVICE POINT OF REMOVAL****1. REMOVAL OF REAR COMBINATION LIGHT**

- (1) Open the hard tonneau.
- (2) Remove the nuts securing the combination light.
- (3) Close the hard tonneau.
- (4) Using the tape-wrapped tip of a screwdriver, remove the light.

**SERVICE POINT OF INSTALLATION****1. INSTALLATION OF REAR COMBINATION LIGHT**

- (1) Install the combination light.
- (2) Open the hard tonneau.
- (3) Install the nuts to secure the light.

## HIGH MOUNTED STOP LIGHT REMOVAL AND INSTALLATION



### Removal steps

1. High mounted stop light
2. High mounted stop light harness connector

---

**NOTES**



# HEATER, AIR CONDITIONING AND VENTILATION

## CONTENTS


INTERIOR TEMPERATURE SENSOR (SPYDER-UNIQUE RELOCATION) .....	2
Removal and installation .....	2

**NOTE**

When the hardtop is open, the in-car temperature sensor for the air conditioning is now reading the temperature inside the hardtop stowage area. Therefore, when using the A/C set the "MODE" to the desired selection and select the fan speed using "FAN". Set the temperature control ("TEMP") to a comfortable setting as required. The A/C system is not designed to cool the vehicle with the hardtop open.

## INTERIOR TEMPERATURE SENSOR (SPYDER-UNIQUE RELOCATION)

### REMOVAL AND INSTALLATION



**NOTE**  
Refer to GROUP 42, in this Manual  
for Configuration Diagram.  
See Volume 1 for more information.

#### Removal step




1. Interior temperature sensor

### SERVICE POINT OF REMOVAL

#### 1. REMOVAL OF INTERIOR TEMPERATURE SENSOR

Using a trim stick, remove the interior temperature sensor from the headlining.



NOTE: THE LISTINGS IN THIS INDEX ARE FOR VOLUME 3, SERVICE MANUAL SUPPLEMENT, FOR SPYDER RELATED COMPONENTS AND/OR CHANGES. IF ADDITIONAL BASE CAR INFORMATION IS NEEDED, REFER TO VOLUME 1 AND 2 OF THE SERVICE MANUAL.

## A

ABS CONTROL UNIT	
Spyder-unique Relocation	35-2
AERO PARTS	
Side Air Dam	51-5,8
Tonneau Spoiler	51-2

## B

BODY DIMENSIONS AND MEASUREMENT METHODS	42-264
BODY STRUCTURE	
ASC Incorporated Installed Parts	42-267
Mitsubishi Installed Parts	42-266

## C

CARGO/HARDTOP STOWAGE AREA LIGHT	54-22
CARGO/HARDTOP STOWAGE AREA TRIM	52-15
CD CHANGER	54-15
CENTER CLOSEOUT PANEL	52-24
CHIME MODULE AND TURN-SIGNAL AND HAZARD	
FLASHER UNIT	42-260

## D

DIAGNOSTICS AND TESTING (BODY)	42-15
AUTO-CONFIGURATION	42-17
CIRCUIT DIAGRAMS	
Chime Module	42-144
Data Link Connector (DLC)	42-148
Driver Door Power Window System	42-138
Hard Tonneau Latch System	42-137
Hardtop and Hard Tonneau Control Switch	42-142
Hardtop and Hard Tonneau Drive Motors	42-147
Header Latch System	42-136
LEDs	42-145
Object-in-trunk Sensor	42-143
Passenger Door Power Window System	42-140
Potentiometers	42-146
Power Quarter Window	42-135
Retractable Hardtop Power Distribution and Control	42-133
CONFIGURATION DIAGRAMS	
Interior	42-24
Luggage Compartment	42-26
Overall	42-23
DIAGNOSTIC TROUBLE CODE (DTC) IDENTIFICATION	
LIST	42-47
ECU CONNECTOR LOCATION AND TERMINAL	
DISENGAGEMENT	42-19-21
GROUNDING LOCATIONS	42-18
INSPECTION AND VERIFICATION	42-32
NOTES AND TERMS	42-16,17
PINPOINT TESTS	
No DTCs Present	42-49
With DTCs Present	42-75
RECOMMENDED WIRE REPAIR	42-22
RETRACTABLE HARDTOP OPERATION	42-29
SYMPTOM CHART	
No DTCs Present	42-33
With DTCs Present	42-35

## TROUBLE SHOOTING HINTS

No DTCs Present	42-41
With DTCs Present	42-43
WARNINGS AND CAUTIONS	42-15
WIRE COLOR CODES	42-28
DIAGNOSTICS AND TESTING (CHASSIS ELECTRICAL)	54-5
Circuit Diagrams	
Cargo/Hardtop Stowage Area Lamp	54-13
HomeLink™ Universal Transmitter	54-11
Lighted Rearview Mirror (Map Lights)	54-12
Inspection and Verification	54-5
Pinpoint Tests	54-7
Test A: Both Map Light Inoperative With Switches	54-7
Test B: Map Light (One) Inoperative	54-8
Test C: Luggage Compartment Lamp Inoperative	54-9
Test D: Universal Transmitter (HomeLink™) Inoperative	54-10
Symptom Chart	54-6
Troubleshooting Hints	54-6
DIAGNOSTICS AND TESTING (INTERIOR)	52-2
Circuit Diagrams (Self-dimming Mirror)	52-5
Inspection and Verification	52-2
Pinpoint Tests	52-4
Symptom Chart	52-3
Troubleshooting Hints	52-3
DOOR LOCATION PIN AND RECEIVER	42-240
DOOR WINDOW RELAYS	42-239

## E

ECS CONTROL UNIT	
Spyder-unique Relocation	33B-2
ELECTRONIC CONTROL UNIT (ECU), HARDTOP	42-263

## F

FENDER	42-219
FRONT PILLAR TRIM	52-10
FRONT SEAT BELT GUIDE	52-20
FRONT SEATS	52-18
Recline-angle Stop	52-18

## G

GENERAL DATA AND SPECIFICATIONS	00-28
General Specifications	00-28
GENERAL INFORMATION ABOUT THE RETRACTABLE	
HARDTOP SYSTEM	00-7
Battery, Low or Discharged	00-9
Battery, Over-charge	00-9
Cold Weather Driving	00-8
Object-in-trunk Sensor	00-8
Power Quarter Windows and Door Windows	00-8
GENERAL INFORMATION, (BODY)	42-3
Description	
About the Automatic Header Latch System	42-3
About the Hard Tonneau	42-3
About the Hardtop and Power Quarter Windows	42-3
About the Object-in-trunk Sensor	42-4
General Precautions	42-4
Overview	42-3
GENERAL INFORMATION, (CHASSIS ELECTRICAL)	54-2

Cargo/Hardtop Stowage Area Lamp System .....	54-4
CD Changer .....	54-2
Motor Antenna .....	54-3
GENERAL INFORMATION ON MANUAL OPERATION OF THE RETRACTABLE HARDTOP SYSTEM .....	00-16

## H

HARD TONNEAU .....	00-10
Normal Operation - Hard Tonneau .....	00-10
HARD TONNEAU HYDRAULIC SYSTEM PUMP/MOTOR .....	42-193
HARD TONNEAU HYDRAULIC SYSTEM PUMP/MOTOR AND CYLINDERS .....	42-190
HARD TONNEAU LATCH SYSTEM .....	42-188
HARD TONNEAU MECHANISM .....	42-186
HARD TONNEAU POSITION SENSOR (POTENTIOMETER) .....	42-195
HARD TONNEAU SEQUENCE OF OPERATION - CLOSING .....	42-8
HARD TONNEAU SEQUENCE OF OPERATION - OPENING .....	42-7
HARDTOP AND HARD TONNEAU CONTROL SWITCH .....	42-257
HARDTOP ELECTRONIC CONTROL UNIT (ECU) .....	42-263
HARDTOP SYSTEM .....	42-200
HEADER GARNISH .....	52-10
HEADLINING .....	52-21
HIGH MOUNTED STOP LIGHTS .....	54-25
HOMELINK™ UNIVERSAL TRANSMITTER .....	54-19
HOMELINK™ UNIVERSAL TRANSMITTER (GENERAL) .....	00-22
List of Tested Garage Door Openers .....	00-25
Proper Training Technique .....	00-22
Training Problem Diagnosis .....	00-23
Transmitter Compatibility .....	00-23
HYDRAULIC SYSTEM, HARD TONNEAU AND HARDTOP .....	42-214
HYDRAULIC SYSTEM BLEEDING .....	
Acceptable Levels of Trapped Air Bubbles .....	42-215
Hard Tonneau System Bleeding .....	42-216
Hardtop System Bleeding .....	42-216
Pre-bleeding Notes .....	42-215
HYDRAULIC SYSTEM DIAGRAMS .....	42-214

## I

INTERIOR TEMPERATURE SENSOR (SPYDER-UNIQUE RELOCATION) .....	55-2
INTRODUCTION (General) .....	00-2

## L

LIGHTED REAR VIEW MIRROR (MAP LIGHTS) .....	54-14
LUBRICATION AND MAINTENANCE .....	
Hydraulic System Fluid, Hard Tonneau and Hardtop .....	00-29
Lubricants - Greases .....	00-29
Maintenance Schedules .....	00-29
Severe Service .....	00-29

## M

MANUAL OPERATION - HARD TONNEAU .....	00-16
Closing the Hard Tonneau .....	00-17
Opening Hard Tonneau .....	00-16
MANUAL OPERATION - RETRACTABLE HARDTOP .....	00-17
Closing Retractable Hardtop .....	00-17
Opening Retractable Hardtop .....	00-19
MANUAL OPERATION - HEADER LATCHES .....	00-21
To Open or Close Header Latches .....	00-21
MOTOR ANTENNA AND RELAY .....	54-17

MOULDINGS .....	
Drip Moulding .....	51-9
Quarter Belt Moulding .....	51-9,10

## O

OBJECT-IN-TRUNK SENSOR .....	42-261
------------------------------	--------

## P

POLISHING THE RETRACTABLE HARDTOP AND HARD TONNEAU .....	00-22
PRECAUTIONS BEFORE SERVICE .....	00-27
Servicing the Electrical System .....	00-27
Vehicle Washing .....	00-27
PROTECTION, THEFT .....	00-6

## Q

QUARTER TRIM PANEL .....	52-13
QUARTER TRIM PANEL COURTESY LIGHT .....	54-20
QUARTER WINDOW SYSTEM .....	42-233
Drive Cable .....	42-235
Position Sensor .....	42-237
Window .....	42-233
QUICK TROUBLESHOOTING GUIDE FOR THE HARDTOP AND HARD TONNEAU .....	00-14
QUICK TROUBLESHOOTING GUIDE FOR THE HARD TONNEAU .....	00-11

## R

REAR BUMPER .....	51-11
Rear Bumper Extension .....	51-11
REAR COMBINATION LIGHTS .....	54-23
REAR LOCK COVER .....	51-2,5
REAR SEAT .....	52-12
REAR SEAT, STRIKER AND REAR SHELF PANEL .....	52-22
REAR SPEAKER .....	54-16
RECOMMENDED LUBRICANTS AND LUBRICANT CAPACITIES TABLE .....	00-30
Lubricant Capacities Table .....	00-30
Recommended Lubricants .....	00-30
RETRACTABLE HARDTOP .....	00-13
Air Conditioning - When Hardtop is Open .....	00-12
Normal Operation - Closing Retractable Hardtop .....	00-12
Normal Operation - Opening Retractable Hardtop .....	00-12
RETRACTABLE HARDTOP ASSEMBLY .....	42-200
RETRACTABLE HARDTOP, FRONT ROOF PANEL .....	42-197
RETRACTABLE HARDTOP HYDRAULIC SYSTEM PUMP/MOTOR .....	42-213
RETRACTABLE HARDTOP HYDRAULIC SYSTEM PUMP/MOTOR AND CYLINDERS .....	42-209
RETRACTABLE HARDTOP POSITION SENSOR (POTENTIOMETER) .....	42-207
RETRACTABLE HARDTOP SEQUENCE OF OPERATION CLOSING .....	42-6
RETRACTABLE HARDTOP SEQUENCE OF OPERATION - OPENING .....	42-5
ROOF GLASS .....	42-224
General .....	
Glass Wipe, Primers, Adhesive and Glass Installation Items .....	42-221
Replacement of Moulding (Bonding Type) .....	42-222
ROOFTOP CARRIER AND LUGGAGE RACK .....	00-13

**S**

SEAT BELT .....	52-27
SEALANT AND ADHESIVES .....	
Rear Roof Glass .....	42-10
Weatherstrips .....	42-10
SELF-DIMMING LIGHTED REAR VIEW MIRROR .....	52-11
Black-out Applique .....	52-11
Mirror Garnish .....	52-11
Mounting Button .....	52-11
SENSOR, INTERIOR TEMPERATURE (Auto A/C) .....	
Spyder-unique Relocation .....	55-2
SERVICE ADJUSTMENT PROCEDURES (BODY) .....	42-149
Door Locating Pin .....	42-181
Front Rail Weatherstrip and Holder .....	42-170
Hard Tonneau .....	42-171
Tonneau Flipper Doors .....	42-179
Tonneau Hinge .....	42-171
Tonneau Latches .....	42-171
Tonneau Manual Release System .....	42-178
Hard Tonneau Position Sensor (Potentiometer) .....	42-182
Power Quarter Window .....	42-162
Quarter Window .....	42-164
Quarter Window Cables, Synchronization of .....	42-163
Quarter Window Guiding System (Rudder) .....	42-166
Quarter Window Position Sensors .....	42-168
Retractable Hardtop Assembly .....	42-149
Retractable Hardtop Downstop .....	42-158
Downstop Height Adjustment .....	42-158
Downstop Lock Adjustment .....	42-159
Retractable Hardtop Position Sensor (Potentiometer) ..	42-182
Retractable Hardtop System, Adjustment of .....	42-151
Adjustment Points .....	42-157
Gap Between Front and Rear Roof Panels .....	42-153
Hardtop Flushness to Windshield Header .....	42-152
Hardtop Locator Pins .....	42-151
Hardtop Roof Crown .....	42-154
Hardtop Roof Lock-up Before Closing .....	42-152
Hardtop Upstops .....	42-151
Header Latch Garnishes .....	42-151
Weatherstrips, All Hardtop Related .....	42-151
Windshield Header Power Latch System .....	42-160
Latch Actuator Adjustment .....	42-160
Latch Height Adjustment .....	42-161
SERVICE ADJUSTMENT PROCEDURES (INTERIOR) .....	52-7
Center Closeout Panel .....	52-8
Quarter Trim .....	52-9
Rear Seat Strikers .....	52-9
Rear Shelf Panel .....	52-8
SPARE TIRE, JACK AND TOOL SET STORAGE .....	00-22
SPECIAL TOOLS (BODY) .....	42-12
SPECIFICATIONS (BODY) .....	42-9
General .....	42-8
Sealants and Adhesives .....	42-10
SPYDER CLEANING RECOMMENDATIONS .....	00-21
Exterior .....	00-21
About the Spyder Finish .....	00-21
Washing .....	00-22
Waxing .....	00-22
Interior .....	00-21
Hard Tonneau Pad .....	00-21
Headlining .....	00-21
SPYDER DECAL .....	51-12,13

**T**

THEFT-ALARM SYSTEM .....	00-13
THEFT ALARM SYSTEM, LIGHT AUTOMATIC SHUT-OFF AND KEYLESS ENTRY RECEIVER ASSEMBLE (SPYDER-UNIQUE RELOCATION) .....	54-21
THEFT PROTECTION .....	00-6

**V**

VEHICLE IDENTIFICATION .....	00-5
Vehicle Identification Code Chart Plate .....	00-5
Vehicle Identification Number Location .....	00-5

**W**

WEATHERSTRIPS .....	42-242
A-pillar Weatherstrip Holder .....	42-242
Front Rail .....	42-248
Front Rail Weatherstrip Holder .....	42-248
Hard Tonneau .....	42-246
Hardtop .....	42-250
Hardtop Weatherstrip Holder .....	42-250
Quarter Window Sash Seal .....	42-244
Rear Rail Inner .....	42-252
Windshield Header .....	42-242
Windshield Header Weatherstrip Holder .....	42-242
WINDSHIELD HEADER POWER LATCH SYSTEM .....	42-254



## Quick Reference Chart - Hatchback-To-Convertible Connector Changes

### ENGINE COMPARTMENT WIRING HARNESS

(Connector symbol A)

FOR MORE INFORMATION SEE THE APPROPRIATE CIRCUIT DIAGRAM IN VOLUME 1, 2, OR 3.

Vehicle system (Component)	Hatchback connector	Pin #	Convertible connector	Pin #	Comments
Convertible system	A-08X	not used	A-08X	-	60A Fusible link used for convertible

### INSTRUMENT PANEL AND FLOOR CONSOLE WIRING HARNESS

(Connector symbol D)

FOR MORE INFORMATION SEE THE APPROPRIATE CIRCUIT DIAGRAM IN VOLUME 1, 2, OR 3.

Vehicle system (Component)	Hatchback connector	Pin #	Convertible connector	Pin #	Comments
Active aero switch	D-29	--	Not used	--	not used in convertible
Active exhaust switch	D-38	--	Not used	--	not used in convertible
Telephone cable	D-46	--	Not used	--	not used in convertible

### INTERIOR WIRING HARNESS

(Connector symbol E)

FOR MORE INFORMATION SEE THE APPROPRIATE CIRCUIT DIAGRAM IN VOLUME 1, 2, OR 3.

Vehicle system (Component)	Hatchback connector	Pin #	Convertible connector	Pin #	Comments
Vanity mirror illumination (LH)	E-02	--	Not used	--	not used in convertible
Vanity mirror illumination (RH)	E-03	--	Not used	--	not used in convertible
Dome light	E-05	--	E-112	--	
Rear intermittent wiper relay	E-18	--	Not used	--	not used in convertible

### REAR WIRE HARNESS

(Connector symbol F)

FOR MORE INFORMATION SEE THE APPROPRIATE CIRCUIT DIAGRAM IN VOLUME 1, 2, OR 3.

Vehicle system (Component)	Hatchback connector	Pin #	Convertible connector	Pin #	Comments
Defogger (+)	F-02	1	E-120	1	
Rear wiper motor	F-03	--	Not used	--	not used in convertible
Defogger (-)	F-05	1	E-118	1	
ABS resistor	F-09	--	Not used	--	Note: connector in MMC body harness
ESC control unit	F-12 / F-13	--	Not used	--	Note: connectors in MMC body harness
Body wiring harness (LH) to body wiring harness (RH)	F-19 / F-20	--	Not used	--	not used in convertible

## Quick Reference Chart - Hatchback-To-Convertible Connector Changes

### REAR WIRE HARNESS (Continued) (Connector symbol F)

FOR MORE INFORMATION SEE THE APPROPRIATE CIRCUIT DIAGRAM IN VOLUME 1, 2, OR 3.

Vehicle system (Component)	Hatchback connector	Pin #	Convertible connector	Pin #	Comments
Luggage compartment lamp switch	F-22	1	F-116	B A	
Liftgate cylinder lock switch	F-23	--	--	--	not used in convertible
Liftgate switch	F-24	--	--	--	not used in convertible
Active exhaust control unit	F-26	--	--	--	not used in convertible
Active aero control unit	F-27 / F-28	--	--	--	not used in convertible
Active exhaust actuator assembly	F-29	--	--	--	not used in convertible
Motor antenna control unit	F-31	--	A-79	--	same connector relocated to front of vehicle
Body wiring harness (LH) and liftgate wiring harness	F-34	1 5	E-122	E A	
Body wiring harness (LH) and liftgate wiring harness	F-35	--	--	--	not used in convertible
Telephone	F-36 / F-37 F-38 / F-39	--	--	--	not used in convertible