












# Error Messages

This section lists the indicators and error messages that appear in the viewfinder and monitor.

 **Warning Icons**  
A flashing  in the monitor or  in the viewfinder indicates that a warning or error message can be displayed in the monitor by pressing the  button.

Indicator		Solution
Monitor	Viewfinder	
Lock lens aperture ring at minimum aperture (largest f/-number)	 (blinks)	Set lens aperture ring to minimum aperture (largest f-number).
Lens not attached	 (blinks)	<ul style="list-style-type: none"><li>• Attach non-IX NIKKOR lens.</li><li>• If non-CPU lens is attached, select mode M.</li></ul>
Shutter release disabled. Recharge battery.	 (blinks)	Turn camera off and recharge or replace battery.
This battery cannot be used. Choose battery designated for use in this camera.		Use Nikon-approved battery.
Initialization error. Turn camera off and then on again.	 /[E r r] (blinks)	Turn camera off, remove and replace battery, and then turn camera on again.
Battery level is low. Complete operation and turn camera off immediately.	—	End cleaning and turn camera off and recharge or replace battery.
Clock not set	—	Set camera clock.
No SD card inserted	(- E -)/  (blinks)	Turn camera off and confirm that card is correctly inserted.
Memory card is locked. Slide lock to “write” position.	 d (blinks)	Memory card is locked (write protected). Slide card write-protect switch to “write” position.
This memory card cannot be used. Card may be damaged. Insert another card.	 d/[E r r] (blinks)	<ul style="list-style-type: none"><li>• Use approved card.</li><li>• Format card. If problem persists, card may be damaged. Contact Nikon-authorized service representative.</li><li>• Error creating new folder. Delete files or insert new memory card.</li><li>• Insert new memory card.</li><li>• Eye-Fi card is still emitting wireless signal after <b>Disable</b> has been selected for <b>Eye-Fi upload</b>. To terminate wireless transmission, turn the camera off and remove the card.</li></ul>

